



***MG4***  
*ELECTRIC*

MG4 Owners Manual

<b>I Foreword</b> .....	<b>15</b>
<b>Introduction</b> .....	<b>16</b>
The Owner's Handbook .....	16
Announcement .....	16
Symbols Used .....	17
<b>Vehicle Identification Information</b> .....	<b>18</b>
Vehicle Identification Markings .....	18
Vehicle Identification Label .....	19
<b>Instructions for Use of Electric Vehicle</b> .....	<b>21</b>
Effects of Ambient Temperature .....	21
Instructions for High Voltage Battery Pack Recycling .....	21
Driving Range .....	22
Equalisation Charging .....	23
Intelligent Charging .....	23
Crash Outage Control .....	23
High Voltage System .....	24
Precautions in the Event of an Accident .....	27
<b>2 Instruments and Controls</b> .....	<b>29</b>

# CONTENTS

---

<b>Instrument Pack .....</b>	<b>30</b>
Instrument Message Display Operation .....	30
Message Centre.....	32
Warning Message.....	33
<b>Warning Lights and Indicators.....</b>	<b>35</b>
<b>Lights and Switches.....</b>	<b>47</b>
Master Light Switch.....	47
Headlamp Leveling Adjustment .....	49
Light Lever Switch .....	50
Direction Indicators .....	53
Rear Fog Lamps.....	54
Hazard Warning Lamps .....	54
<b>Wipers and Washers.....</b>	<b>55</b>
Front Windscreen Wiper and Washer Operation .....	55
Front Windscreen Wash and Wipe .....	56
Rear Windscreen Wash and Wipe.....	57
<b>Steering System .....</b>	<b>58</b>
Steering Wheel Position Adjustment.....	58
Electric Power Steering .....	58

Steering Mode Switching.....	59
<b>Horn.....</b>	<b>60</b>
<b>Power Socket .....</b>	<b>61</b>
Front Console Power Socket.....	61
Rear USB Port.....	61
<b>Wireless Charging System for Mobile Phones* .....</b>	<b>63</b>
Wireless Charging of Mobile Phones.....	63
<b>Rearview Mirrors .....</b>	<b>65</b>
Exterior Rearview Mirrors .....	65
Interior Rearview Mirror .....	67
<b>Sunvisor .....</b>	<b>69</b>
<b>Windows.....</b>	<b>70</b>
Power Operated Window Switch .....	70
Window Operation.....	71
<b>Interior Lighting .....</b>	<b>73</b>
Automatic Operation .....	73
<b>Driver Monitor System.....</b>	<b>74</b>
Indirect Driver Fatigue Reminder System.....	74

# CONTENTS

---

<b>Storage Devices</b> .....	<b>76</b>
Instructions for Use .....	76
Glove Box .....	76
Storage Box .....	77
Glasses Box .....	78
<b>Cup Holder</b> .....	<b>79</b>
Centre Console Cup Holder .....	79
<b>3 Air Conditioning</b> .....	<b>81</b>
<b>Ventilation</b> .....	<b>82</b>
A/C Filter .....	83
Vents .....	83
<b>A/C Control Panel</b> .....	<b>85</b>
Control Panel .....	85
A/C Control Shortcut .....	85
Defrost/Demist Button .....	85
Heated Rear Window Button .....	85
<b>Air Conditioning Control Interface</b> .....	<b>87</b>
Air Conditioning Control Interface - Connected Car * .....	87

System On/Off.....	87
Cooling On/Off.....	87
Auto Mode.....	88
Air Distribution Mode.....	88
Air Recirculation Mode.....	89
Economy Mode.....	90
Temperature Control.....	90
Blower Speed Control.....	90
<b>Infotainment System*</b> .....	<b>91</b>
Important Safety Information.....	91
Privacy and Data Sharing.....	92
Precautions for Screen Usage.....	92
Basic Operations.....	93
Bluetooth Phone.....	97
Entertainment.....	99
Vehicle-Mobile Phone Interconnection.....	105
MG Touchpoint .....	106
Vehicle Settings.....	106
Settings.....	106

# CONTENTS

---

<b>4 Seats and Restraints .....</b>	<b>109</b>
<b>Seats.....</b>	<b>110</b>
Seat Positions and Backrest Angle .....	110
Head Restraints.....	111
Front Seats .....	112
Rear Seats.....	114
Front Seat Heating Function* .....	115
<b>Seat Belts .....</b>	<b>116</b>
Protection Provided by Seat Belts .....	117
Wearing Seat Belts.....	118
Children and Seat Belts .....	121
Seat Belt Pre-tensioners.....	122
Seat Belt Checks, Maintenance and Replacement.....	124
<b>Airbag Supplementary Restraint System .....</b>	<b>127</b>
Overview .....	127
Airbag Deployment .....	129
Conditions in Which Airbags Will Not Deploy .....	132
Service and Replacement of Airbags.....	134
Disposal of Airbags.....	135

<b>Child Restraints .....</b>	<b>136</b>
Important Safety Instructions about Using Child Restraints .....	136
Fixing Child Restraints .....	140
Child Restraint Groups and Installation Position .....	143
<b>5 Starting and Driving .....</b>	<b>149</b>
<b>Keys .....</b>	<b>150</b>
Overview .....	150
Replacing the Smart Key Battery .....	152
<b>Child Proof Locks .....</b>	<b>154</b>
<b>Alarm System .....</b>	<b>155</b>
Power Immobiliser .....	155
Anti-theft System .....	156
Manual Tailgate .....	159
Emergency Tailgate Opening .....	160
<b>Starting and Stopping the Power System .....</b>	<b>162</b>
Starting the Power System .....	162
Switching the Power System OFF .....	163
<b>Economical and Environmental Driving .....</b>	<b>164</b>

# CONTENTS

---

Running-in.....	164
Environment Protection.....	164
Economic Driving.....	164
Driving in Special Environment.....	165
Check and Service.....	166
<b>Charging and Discharging Requirements .....</b>	<b>167</b>
Charging Your Vehicle at Home .....	169
Installed Charging Points.....	169
Home Charging Guide.....	169
Charging and Medical Condition Awareness .....	170
Charging Port .....	170
Electric Charging Identifier Label.....	172
Rapid Charging .....	175
Slow Charging.....	175
Charging Information.....	178
Equalisation Charging.....	179
Charging Times .....	180
Discharging.....	184
<b>Pedestrian Alert Control System .....</b>	<b>186</b>

<b>Electric Drive Transmission</b> .....	<b>187</b>
Instructions .....	187
Gear Shift Control.....	187
Driving Mode (Mode ) .....	189
Energy Regeneration.....	190
Energy Saving Mode.....	190
Protection Mode.....	191
<b>One-Pedal Function *</b> .....	<b>193</b>
<b>Brake System</b> .....	<b>194</b>
Overview .....	194
Parking Brake System - Electronic Parking Brake (EPB ) .....	195
Service Brake System.....	197
<b>Adaptive Cruise Control System</b> .....	<b>204</b>
Activation of Adaptive Cruise Control.....	204
Adaptive Cruise Target Following Distance Adjustment.....	206
Adaptive Cruise Target Speed Adjustment.....	206
Adaptive Cruise Pause/Standby .....	207
Automatic Deactivation of Adaptive Cruise .....	207
Adaptive Cruise Override .....	208

# CONTENTS

---

Adaptive Cruise Resume.....	208
Clearing Target Speed Memory.....	208
Special Driving Environments.....	209
<b>Driving Assist System .....</b>	<b>213</b>
Description of Front View Camera.....	213
Description of Front Detection Radar .....	214
Speed Sign Recognition .....	216
Speed Limit Assistance System.....	218
Lane Assist System .....	223
Traffic Jam Assist System.....	226
Front Collision Assist.....	229
<b>Parking Aid System .....</b>	<b>232</b>
Ultrasonic Sensor Parking Aid.....	232
Parking Camera* .....	233
360 Around View System* .....	233
<b>Rear Driving Assistance System* .....</b>	<b>235</b>
System Overview.....	235
Switching the System Functions On/Off.....	235
Blind Zone Safety Assist.....	236

Rear Cross Traffic Assist.....	238
Rear Collision Warning.....	240
Door Opening Warning.....	241
<b>Tyre Pressure Monitoring System (TPMS).....</b>	<b>243</b>
<b>Load Carrying.....</b>	<b>244</b>
Loadspace Loading.....	244
Internal Loading.....	245
General Towing Safety.....	245
<b>6 Emergency Information.....</b>	<b>249</b>
<b>Hazard Warning Devices.....</b>	<b>250</b>
Warning Triangle.....	250
<b>Vehicle Recovery.....</b>	<b>251</b>
Towing for Recovery.....	251
Transporter or Trailer.....	254
<b>Emergency Starting.....</b>	<b>255</b>
<b>Tyre Repair.....</b>	<b>257</b>
Tool Identification (including tyre repair tool).....	257
Tyre Repair.....	258

# CONTENTS

---

<b>Fuse Replacement .....</b>	<b>261</b>
Fuse .....	261
Passenger Compartment Fuse Box .....	262
Front Compartment Fuse Box .....	264
<b>Bulb Replacement .....</b>	<b>268</b>
Bulb Specification .....	268
Bulb Replacement .....	268
<b>7 Service and Maintenance .....</b>	<b>275</b>
<b>Maintenance .....</b>	<b>276</b>
Routine Servicing .....	276
<b>Bonnet .....</b>	<b>279</b>
Opening the Bonnet .....	279
Closing the Bonnet .....	279
Bonnet Open Alarm .....	279
<b>Front Compartment .....</b>	<b>280</b>
<b>Battery .....</b>	<b>281</b>
Battery Maintenance .....	281
Battery Replacement .....	282

<b>Cooling System</b> .....	<b>283</b>
Coolant Check and Top Up .....	283
Coolant Specification .....	283
<b>High-voltage Battery Pack</b> .....	<b>285</b>
Precautions and restricted conditions for use of battery .....	285
<b>Washer</b> .....	<b>287</b>
Washer Fluid Check and Top Up.....	287
Washer Nozzles.....	288
<b>Wipers</b> .....	<b>289</b>
Wiper Blades .....	289
Replacing Windscreen Wiper Blades.....	290
Replacing Rear windscreen Wiper Blades .....	291
<b>Brake</b> .....	<b>292</b>
Brake Fluid Check and Top Up.....	292
Brake Fluid Specification .....	293
<b>Tyre</b> .....	<b>294</b>
Overview .....	294
Caring for Your Tyres .....	296
Tyre Wear Indicators .....	297

# CONTENTS

---

Tyre Rotation .....	298
Tyre/Snow Chains .....	298
<b>Cleaning and Vehicle Care.....</b>	<b>300</b>
Exterior .....	300
Cleaning the Interior.....	303
<b>8 Technical Data .....</b>	<b>305</b>
<b>Technical Data Dimensions .....</b>	<b>306</b>
<b>Weights.....</b>	<b>308</b>
Towing Weights .....	309
<b>Parameters of Traction Motor .....</b>	<b>310</b>
<b>Recommended Fluids and Capacities .....</b>	<b>311</b>
<b>Four-Wheel Alignment Parameter Table (Unladen).....</b>	<b>312</b>
<b>Wheels and Tyres .....</b>	<b>313</b>
<b>Tyre Pressure (Cold) .....</b>	<b>314</b>

## **Foreword**

---

- 16 Introduction*
- 18 Vehicle Identification Information*
- 21 Instructions for Use of Electric Vehicle*

# FOREWORD

---

## Introduction

### The Owner's Handbook

This handbook describes the standard features and functions of the vehicle series in detail. Some information may not be applicable to your individual models.

If you have any questions about the operation and parameters of the vehicle, please contact MG Authorised Repairer which will provide you with the best service.

The illustrations in the Owner's Handbook are for reference only.

The information contained in this handbook may vary slightly depending on the vehicle configuration, software version and sales regions.

### Announcement

The strategy of our company is to make continuous improvements to the products, therefore, we reserves the right to make changes in the product without further notice after the handbook is printed.

This handbook includes up-to-date information as of printing. Except for personal injury caused by negligence

of the manufacturer or MG Authorised Repairer, the manufacturer or MG Authorised Repairer shall not be liable for any error and its consequences, including property damage or personal injury.

## Symbols Used

### Warning



*This warning symbol identifies procedures that must be followed precisely, or information that must be considered with great care, in order to reduce the risk of personal injury or serious damage to the car.*

### Important

IMPORTANT

The statements stated here must be followed strictly, otherwise your car could be damaged.

### Note

**Note:** *This describes helpful information.*



This symbol indicates parts described must be disposed of by authorised persons or bodies to protect the environment.

### Asterisk

An asterisk (\*) appearing within the text, identifies features or items of equipment that are either optional, or are only fitted to some vehicles in the model range.

### Illustration Information



Identifies components being explained.




Identifies movement of components being explained.

# FOREWORD

---

## Vehicle Identification Information

### Vehicle Identification Markings



- 1 Vehicle Identification Number (VIN)
- 2 Drive Motor Number-Front drive\*
- 3 Electric Drive Transmission Number-Front drive\*
- 4 Drive Motor Number-Rear drive

- 5 Electric Drive Transmission Number-Rear drive

Always quote the Vehicle Identification Number (VIN) when communicating with your MG Authorised Repairer. If the drive motor or electric drive transmission is involved, it may be necessary to provide the identification numbers of these assemblies.

### Vehicle Identification Location

#### VIN Location

- On the floor under the front driver seat;
- Stamped on a plate visible through the bottom left hand corner of the windscreen;
- On the identification plate;
- On the inner side of the tailgate visible by opening the tailgate.

**Note:** *The DLC is located in the driver footwell at the base of the fascia panel on the RH side. The VIN information can be extracted from the vehicle using the approved diagnostic equipment.*

#### Drive Motor Number

Stamped on the lower part of the drive motor housing.

## ***Electric Drive Transmission Number***

Stamped on the upper part of the electric drive transmission housing.

## **Vehicle Identification Label**

The vehicle identification label contains the following information:


- Type Approval Number;
- VIN Number;
- Gross Vehicle Weight;
- Gross Train Weight;
- Max Front Axle Weight;
- Max Rear Axle Weight;
- Electric Machinery Model I;
- Model;
- Electric Machinery Model II ;
- Date of Production;
- Country.

# FOREWORD

---

## Location of Vehicle Identification Label

The identification label is located at the lower side of right pillar B .



## Instructions for Use of Electric Vehicle

### Effects of Ambient Temperature

The working performance of the high voltage battery pack fitted to your vehicle is related to the ambient temperature. This battery powers the vehicle power system and therefore it is recommended that where possible the vehicle should be used within the temperature range of -15°C~45°C. This will ensure that the vehicle is in the optimum working state, and help extend the service life of the high voltage battery pack. Extremely high or low temperatures will affect the performance of the high voltage battery pack and vehicle.

### Instructions for High Voltage Battery Pack Recycling

The high voltage battery pack fitted to your vehicle contains several lithium based battery cells. It is installed centrally to the motor-vehicle chassis. Arbitrary disposal may cause pollution, hazard and damage to the environment. The high voltage battery pack **MUST** be recycled by an MG Authorised Repairer or a professional

approved dismantling agent. Please refer to the following information and requirements.

- **ONLY** qualified personnel should work with the high voltage system - there is danger of **DEATH**.
- **High voltage safety:** the high voltage system fitted to your vehicle features a HV battery containing high voltage components such as lithium battery packs and high voltage wiring harness; **DO NOT** attempt to dismantle any area of this system, suitably trained professional staff must observe insulation safety protection before working on or near the high voltage system.
- **Transportation:** The high voltage battery pack is classed as a Category 9 hazardous material and must be transported by vehicles qualified in transporting Category 9 hazardous materials.
- **Storage:** All HV components (including batteries) should be stored at room temperature and in a dry environment. They must be kept away from dangerous sources, such as flammable objects, heat and water sources.

## FOREWORD

---

- Internal composition: The high voltage battery pack consists of lithium batteries (pack), PCB, HV and normal electric wiring, metal casing and other components.

It is strongly recommended that the used high voltage battery pack generated from vehicle scrappage or any other reasons should be disposed of by an MG Authorised Repairer.

**Note: If you decide not to use the recommended MG Authorised Repairer to dispose of your high voltage battery, the responsibility of the consequences of environmental pollution or accidents must be borne by the owner.**

### Driving Range

The driving range of your vehicle depends on the HV battery condition, quantity of available electricity, vehicle age (current remaining battery life), weather, temperature, road conditions and driving habit etc.

The range can be affected by other electrical loads (such as A/C, lights etc), driving style and general road conditions.

It should be noted that:

- The driving range is related to the rate of discharge. In order to avoid a high rate of discharge from affecting

the performance of the high voltage battery pack, it is recommended that the vehicle is connected to a suitable charger upon illumination of the low battery warning lamp in the instrument pack.

- The actual driving range of the vehicle will reduce with the increase of vehicle age.
- The use of A/C will reduce the driving range.
- The driving range varies at different speeds.
- At low temperatures, the driving range will be reduced due to temperature characteristics of the battery during use.
- In some instances of extreme temperatures and low battery voltage, you may experience insufficient acceleration or power reduction. This is due to battery characteristics.

To help increase the range of the vehicle please observe the following:

- Have the vehicle regularly maintained as per service schedule.
- Always ensure the tyre pressures are correct.
- Try and use the vehicle between the recommended ambient temperatures.

- Do not park or store the vehicle for long periods with a low state of charge, where possible charge the vehicle as soon as possible prior to storage.
- Remove unnecessary articles to reduce the vehicle load.
- Use of high power consuming systems such as A/C and heating will use large amounts of power. This will reduce the driving range.
- At a high speed, where possible, close the windows to reduce wind resistance and power consumption.
- Try to maintain a steady speed at all times, avoid constant acceleration and braking.
- During acceleration, apply the accelerator pedal as gently as possible.
- During deceleration, release the accelerator pedal; under certain conditions when not applying the brake or gently applying the brake, the energy regeneration system (KERS) will assist in charging the HV battery and extend the driving range.

## Equalisation Charging

In order to assist in extending the service life of the high voltage battery pack it is recommended that an equalisation charge is carried out at regular intervals.

Please see "Equalisation Charging" in the "Starting & Driving" section.

## Intelligent Charging

The 12V battery SOC (State Of Charge) is constantly monitored, when the vehicle is power OFF it is possible, under certain conditions, that the HV battery will automatically charge the 12V battery to ensure the vehicle starts. This function will activate and switch off automatically.

**Note: The system will suspend intelligent charging if a fault is present, when starting or the vehicle is being charged by an external device.**

**Note: The driving range will be reduced after intelligent charging.**

**Note: The intelligent charging function is suspended when the high voltage battery is in a low SOC.**

## Crash Outage Control

If a crash or serious impact occurs, a signal from the SDM (Airbag Control Module) will disconnect the relays within the battery management system isolating the high voltage battery from the systems on the vehicle.

# FOREWORD


---

## High Voltage System



- *The high voltage system used on your vehicle features AC and DC voltages. All high voltage components have warning labels attached - please observe these warnings and any requirements when operating within or close to these areas.*
- *ONLY qualified personnel should work on, or with, the high voltage system - there is danger of DEATH.*

The high voltage system component layout is shown below ( 2WD ) :



- 1 Electric Heater
- 2 High Voltage Harness
- 3 High Voltage Battery (ESS)
- 4 Power Distribution Unit (PDU)
- 5 Electric Drive Transmission
- 6 Combined Charging Unit (CCU)
- 7 Charging Port
- 8 HV Battery Heater
- 9 Manual Service Disconnect (MSD)
- 10 Electric A/C Compressor

# FOREWORD

---

The high voltage system component layout is shown below ( 4WD ) :



- 1 Electric A/C Compressor
- 2 Front Electric Drive Transmission
- 3 Electric Heater
- 4 High Voltage Battery (ESS)
- 5 High Voltage Harness
- 6 Power Distribution Unit (PDU)
- 7 Rear Electric Drive Transmission
- 8 Combined Charging Unit (CCU)
- 9 Charging Port
- 10 HV Battery Heater
- 11 Manual Service Disconnect (MSD)

## Precautions in the Event of an Accident



- *Ensure the vehicle is in P, the parking brake is applied and the vehicle power system is OFF.*
  - *If any cables on the vehicle are exposed, in order to prevent electric shock or even death DO NOT make any contact with any cable.*
  - *If the vehicle catches fire, and the fire is small and slow, a carbon dioxide extinguisher can be used to extinguish the fire, and contact the fire services as soon as possible; if the fire is large and spreading quickly, immediately evacuate the vehicle and contact the fire services immediately.*
  - *If the vehicle is involved in a collision and cannot be re-started, the negative cable of 12V battery and Manual Service Disconnect (MSD) MUST be disconnected prior to rescue.*
- *When the vehicle is completely or partially immersed in water, switch off the vehicle power system and evacuate the car immediately. The negative cable of 12V battery and Manual Service Disconnect (MSD) MUST be disconnected prior to rescue or as soon as the vehicle is refloated/removed from the water. Observe the water/vehicle for any abnormal signs such as excessive bubbles or noises, this may indicate battery short circuit issues. If no signs are evident, there should not be a shock risk from the body work and recovery can commence.*
  - *If your car is being recovered by an independent recovery agent, please contact an MG Authorised Repairer for guidance.*
  - *The vehicle is supplied with an emergency response information card.*

## FOREWORD

---

*Please show the card to the rescue  
personnel when they arrive.*

## ***Instruments and Controls***


---

- |    |  |    |                              |
|----|--|----|------------------------------|
| 30 | <i>Instrument Pack</i>                             | 74 | <i>Driver Monitor System</i> |
| 35 | <i>Warning Lights and Indicators</i>               | 76 | <i>Storage Devices</i>       |
| 47 | <i>Lights and Switches</i>                         | 79 | <i>Cup Holder</i>            |
| 55 | <i>Wipers and Washers</i>                          |    |                              |
| 58 | <i>Steering System</i>                             |    |                              |
| 60 | <i>Horn</i>  |    |                              |
| 61 | <i>Power Socket</i>                                |    |                              |
| 63 | <i>Wireless Charging System for Mobile Phones*</i> |    |                              |
| 65 | <i>Rearview Mirrors</i>                            |    |                              |
| 69 | <i>Sunvisor</i>                                    |    |                              |
| 70 | <i>Windows</i>                                     |    |                              |
| 73 | <i>Interior Lighting</i>                           |    |                              |

# INSTRUMENTS AND CONTROLS

---

## Instrument Pack



- 1 Warning Lights and Indicators
- 2 Active Safety
- 3 Time
- 4 Speedometer
- 5 Message Centre
- 6 Energy Regeneration Mode
- 7 Power Meter
- 8 Electricity Meter and Electricity Driving Range
- 9 Driving Mode
- 10 Power System State
- 11 Gear Display

## Instrument Message Display Operation

The functions of message centre can be displayed by selecting the buttons on the right side of the multi-functional steering wheel, as follows:

button or infotainment adjustment button when the infotainment/instrument switching button is pressed.



## 1 Function Adjustment Button ( OK button)

- Push the button up, down, left and right to switch the display items of message centre.
- Push the button up and down to make adjustments.
- Short press the button to confirm, or long press to reset.

## 2 Infotainment/Instrument Switching Button

The function adjustment button ( 1 ) is a multi-use key. It can be shifted to instrument adjustment

# INSTRUMENTS AND CONTROLS

---

## Message Centre

The message centre provides the followings:



- 1 Health Centre
- 2 Trip Computer
- 3 Navigation\*
- 4 Settings
- 5 Multimedia\*

## Health Centre

Displays the failure messages or important notes of the current car.

- Tyre Pressure Monitoring: displays the current tyre pressure status.
- Battery Voltage: displays the 12V battery voltage.

- Warning Message: displays the failure messages or important notes of the current car.

## Trip Computer

The following information will be displayed on the trip computer:

- From Start: Displays the range, duration, average speed and average energy consumption since startup. When the vehicle is powered off for a period of time, these values will be reset. They can also be reset by long pressing the OK button.
- Accumulated Total: Displays the range, duration, average speed and average energy consumption since the last reset. They can be reset by long pressing the OK button.
- From Last Charge: Displays the range, duration, average speed and average energy consumption since the last charge. They can be reset by long pressing the OK button.
- Odometer: displays the total distance the car has travelled.

## **Navigation\***

Displays the navigation message from entertainment mainframe.

## **Settings**

- **Brightness Level:** displays and adjusts backlight brightness.
- **OverSpeed Threshold:** sets the speed limit value for overspeed warning.
- **Next Service:** reminds the driver of the millage until the next maintenance.

## **Multimedia\***

Displays the multimedia message from entertainment mainframe.

## **Warning Message**

The message centre of instrument pack displays the warning messages in pop-up windows. The warning messages are mainly divided into the following:

- Operation Instructions
- System State Reminder
- System Failure Alert

Please follow the text prompts or refer to the sections related to the control system for the failure causes and appropriate solutions.

When the following warning information appears, please stop the vehicle as soon as safety permits, power off the vehicle and contact an MG Authorised Repairer for service immediately

- DANGER! Evacuate Vehicle Safely
- Escape from the vehicle immediately
- Vehicle Control System Fault, Please Stop Safely
- Occupancy Sensor Fault
- EPS Assistance Failure
- Brake Fluid Level Low
- Brake System Fault

When the following warning information appears, please contact an MG Authorised Repairer for service as soon as possible:

- Airbag Fault
- ESCL Fault
- Vehicle Control System Fault, Take Vehicle to MG Dealer

# INSTRUMENTS AND CONTROLS

---

- Vehicle Control System Fault, Please drive carefully!
- Cruise Control System Failure
- Speed Limit Recognition System Failure
- Speed limit system failure
- System Fault , Unable to Restart
- Parking System Fault
- Gearbox Fault
- Motor Fault , Reverse Gear Not Available
- Power Mode Fault
- Passive Entry Fault
- Tyre Pressure System Failed
- Front Left/Front Right/Rear Left/Rear Right Tyre Sensor Battery Low
- 12V Battery Charging System Fault
- EPS Performance Reduced
- Steering Angle Sensor not Calibrated
- Steering Angle Fault
- ABS Fault
- Stability Control Fault
- Traction Control Fault
- Autohold Fault
- Park Brake Force Too Low
- RADAR Calibration Failed
- Front Camera Calibration Failed
- Front Camera System Fault
- Intelligent Driving Assist Sensor Failure
- ACC System Fault
- Lane Departure Warning System Fault
- Lane Keep Assist System Fault
- Forward Collision System Fault
- Auto Emergency Braking System Fault
- Traffic Jam Assist System Fault
- Rear Drive Assist System Fault
- Driver Monitor System Fault
- Driver Drowsiness Detection System Fault

## Warning Lights and Indicators

When the vehicle is starting or traveling, if the warning lights or indicators appear on the instrument, it indicates that the relevant system is in a certain state or is faulty. Some warning lights illuminate or flash with warning tones or prompt message.

Please carefully read the following instructions to understand the meaning of relevant warning lights and indicators. In case of a failure, please take corresponding measures in time and contact a local MG Authorised Repairer for service as soon as possible.

Name	Icon	Description
Low Beam Indicator		Headlamp low beam is on.
High Beam Indicator		Headlamp high beam is on.
Automatic Headlamp Indicator		The auto headlamp function is enabled.
Width Lamp Indicator		Width lamp is on.

## INSTRUMENTS AND CONTROLS

Rear Fog Lamp Indicator		Rear fog lamps are on.
Direction Indicator Lamp		<p>When the left or right turn signal lamp flashes, the direction indicator lamp on the corresponding side also flashes. If the hazard warning lamps are turned on, both direction indicator lamps will flash simultaneously.</p> <p>If either direction indicator lamp in the instrument pack flashes very rapidly, it indicates the turn signal lamp on the corresponding side has failure.</p>
Airbag Warning Light		Airbag system or seat belt has a failure. Stop the car as soon as safety permits and power off the vehicle. Otherwise there may be the risk that SRS system or seat belt cannot work properly when the crash accident occurs.
Untied Seat Belt Warning Lamp		If this lamp illuminates or flashes, it indicates that the seat belt for an occupied front seat remains unfastened.
Antitheft Alarm Indicator		If this light illuminates, it indicates that no valid key is detected. Please use the correct key, or put the smart key in a standby starting position. For details, refer to "Alternative Starting Procedure" in "Starting & Driving" section.

## INSTRUMENTS AND CONTROLS

2

<p>Tyre Pressure Monitoring System ( TPMS ) Warning Lamp</p>		<p>If this lamp illuminates, it indicates that the tyre pressure is low. Please check the tyre pressure.</p> <p>If this lamp flashes first and then becomes always On after a period of time, it indicates the system has a failure.</p>
<p>Electric Power Steering System ( EPS ) Warning Lamp</p>		<p>If this lamp illuminates, it indicates that the electric power steering system has a general failure, and its performance is reduced. Please restart the vehicle, if the lamp still illuminates, the vehicle is supported to travel to a local MG Authorised Repairer.</p>
		<p>If this lamp illuminates, it indicates that the electric power steering system has a general failure relevant to steering angle. Please restart the vehicle, if the lamp still illuminates, the vehicle is supported to travel to a local MG Authorised Repairer.</p> <p>If this lamp flashes, it indicates that the electric power steering system has a serious failure, and is difficult in steering. Stop the car as soon as safety permits and seek an MG Authorised Repairer urgently.</p>

# INSTRUMENTS AND CONTROLS

<p>Dynamic Stability Control/Traction Control System Warning Lamp</p>		<p>If this lamp illuminates, it indicates that the dynamic stability control system/traction control system has failed.</p> <p>If this lamp flashes while driving, it indicates that the system is operating to assist the driver.</p>
<p>Dynamic Stability Control/Traction Control System OFF Warning Lamp</p>		<p>The dynamic stability control/traction control system is vehicle has been shut down.</p>
<p>Auto Hold ( AUTO HOLD ) Status Indicator Lamp</p>		<p>The AUTO HOLD system is operating to assist the driver.</p>
		<p>The AUTO HOLD system has a failure.</p>
		<p>The AUTO HOLD system function is activated in Standby state.</p>
<p>Electronic Parking Brake ( EPB ) System Indicator Lamp</p>		<p>If this lamp illuminates, it indicates that the EPB is enabled.</p> <p>If this lamp flashes, it indicates that the gradient is heavy or the EPB system has a failure, please park the vehicle on a safe road.</p>

## INSTRUMENTS AND CONTROLS

2

Electronic Parking Brake ( EPB ) System Malfunction Indicator Lamp		It indicates that the EPB system has a failure.
Brake System Malfunction Indicator Lamp		The brake system has a failure, please stop the car as soon as safety permits and power off the vehicle.
4WD Status Indicator*		4WD function is faulty.
Trailer Warning Lamp		The trailer lamp has failed.
ABS Malfunction Indicator Lamp		ABS has a failure. If an ABS failure occurs while driving, the ABS function will be disabled while normal braking will still be available.

## INSTRUMENTS AND CONTROLS

<p>Low-voltage Battery Charging System Malfunction Indicator Lamp</p>		<p>If this lamp illuminates after the vehicle is started, it indicates that low-voltage battery charging system has a failure.</p> <p>If this lamp flashes, it indicates that low-voltage battery has low capacity, and prompt message is displayed on the instrument pack. In this case, the system will limit or turn off some electrical devices; please start the vehicle in time to charge the battery.</p>
<p>System Failure Information Indicator</p>		<p>The vehicle has warning information. Please view the failure message or important prompt message in the Message Centre. Refer to "Instrument Pack" of this section.</p>
<p>Adaptive Cruise Control System Indicator</p>		<p>The adaptive cruise control system is activated and not in Standby state.</p>
		<p>The adaptive cruise control system is in Standby state.</p>
		<p>The adaptive cruise control system is activated.</p>

## INSTRUMENTS AND CONTROLS

2

Speed Limit Assistance System Indicator		Manual speed limit assistance system is in Standby state.
		If this lamp illuminates, it indicates that the manual speed limit assistance system is activated.  If this lamp flashes, it indicates that current speed is greater than the speed limit value.
		The intelligent speed limit assistance system is in Standby state.
		The intelligent speed limit assistance system is activated.
Cruise/Speed Limit System Malfunction Indicator Lamp		The constant speed cruise control system, adaptive cruise control system or speed limit assistance system has a failure.
Speed Limit Sign Speed Indicator		“ NNN ” indicates the speed limit sign speed currently identified. When the vehicle speed is greater than the speed limit value, the lamp will flash.

# INSTRUMENTS AND CONTROLS

<p>Speed Limit Sign Ancillary Information Warning Lamp*</p>		<p>The speed limit sign currently identified has ancillary information. Please check.</p>
<p>Traffic Jam Assist System Indicator</p>		<p>Traffic jam assist system is activated and not in Standby state.</p>
		<p>The traffic Jam assist system is in Standby state.</p>
		<p>The traffic Jam assist system is activated.</p>
		<p>The traffic Jam assist system has a failure.</p>

## INSTRUMENTS AND CONTROLS

2

Lane Keeping Assist System Indicator*		The lane keeping function is disabled.
		The lane keeping function is in Standby state.
		The lane keeping function is activated.
		The lane keeping assist system has a failure.
Forward Collision Assist System Indicator		<p>If this lamp illuminates, it indicates any function of the forward collision assist system is disabled.</p> <p>When the functions of the forward collision assist system are fully enabled, if the lamp stays on, it indicates that forward collision assist system cannot work properly.</p>
Rear Driving Assist System Indicator*		The rear driving assist system is disabled, the radar is obscured or the system has a failure, and a corresponding prompt message will be displayed on the instrument pack.

## INSTRUMENTS AND CONTROLS

Power Battery Cut-off Indicator		When the high-voltage battery pack is connected, this lamp will not illuminate. When this lamp illuminates, it indicates that the high-voltage battery pack has been disconnected.
High-voltage Battery Pack Malfunction Indicator Lamp		This lamp will illuminate when the high-voltage battery pack has a failure.
		When the high-voltage battery pack temperature is too high, this lamp will flash. Please stop the vehicle as soon as possible if it is safe to do so, and leave the vehicle.
Power System Malfunction Indicator Lamp		If this lamp illuminates, it indicates that the vehicle has a failure and its performance is restricted.
		If this lamp illuminates, it indicates the vehicle has a serious failure.
Drive Power Restricted Indicator		If this lamp illuminates, it indicates that the power of the power system is restricted.
Charging Connection Indicator Lamp		The charging/discharging gun is connected.

## INSTRUMENTS AND CONTROLS

2

Charging Status Indicator		It indicates charging/discharging failure.
		The vehicle is being charged.
		The vehicle is being discharged.
Motor Malfunction Indicator Lamp		If the lamp illuminates, it indicates that the electric drive unit motors or the PEB has a failure.
		If the lamp illuminates, it indicates that the electric drive unit motors or the PEB has a failure.
High-voltage Battery Pack Low Battery Warning Lamp		The battery is low. Charge the high-voltage battery pack as soon as possible.

## INSTRUMENTS AND CONTROLS

---


READY Indicator	 A black rectangular icon with the word "READY" written in green capital letters.	The vehicle is ready for running.
Driver Status Indicator	 A black rectangular icon with a yellow seatbelt symbol and a yellow crown-like shape above it, representing a driver's head.	The status indicator will be always on in yellow when the driver monitoring system has a failure or is unavailable temporarily. The status indicator will flash in yellow when the driver is monitored to be fatigued or distracted.

# INSTRUMENTS AND CONTROLS

## Lights and Switches

### Master Light Switch



	Auto Lighting
	Side Lamps and Switch Illumination

	Headlamps
	AUTO Lighting OFF

### AUTO Lightings

When the vehicle is powered on, the AUTO lighting system is turned on by default, which will automatically switch the side lamps/switch illumination on and off according to the intensity of current ambient light.

**Note:** This function is realized by a sensor mounted in your vehicle to monitor the exterior light levels in real time. It is installed in the upper part of the dashboard near the windscreen. **DO NOT** mask or cover this area. Failure to adhere to this may result in the headlamps being turned on unnecessarily.

### Side Lamps and Switch Illumination

When the vehicle is powered on, turn the master lighting switch to position 2 to operate the daytime running lamps, rear sidelamps and switch illumination.

# INSTRUMENTS AND CONTROLS

---

When the vehicle is powered off if the lighting switch is in position 2 and the driver's door is opened an audible warning will sound to alert the driver.

## Headlamps

When the vehicle is powered on, move the Headlamp Cycle switch to the position  , to turn on the dipped beams, side lamps/switch illumination.

## Lamps Off

Move the Lamps Off switch to turn off the lamps. Move it again, the lamps level will automatically return to the AUTO position.

## Daytime Running Lamps

The day time running lamps illuminate automatically when the vehicle power on. When the dipped headlamps are switched on, the day time running lamps extinguish automatically.

## Welcome Light

When the car is unlocked, the system will automatically illuminate the dipped beams and side lamps according to the intensity of the current ambient light.

## Follow Me Home

After the vehicle is powered off on the Infotainment display, pull the light lever switch towards the steering wheel. This will enable the Follow Me Home function, and dipped beam headlamps and side lamps will illuminate. Follow Me Home can be set opening and closing in the "Vehicle Settings" interface on the infotainment display.

## Headlamp Leveling Adjustment



The headlamp leveling can be adjusted as per the following table according to the vehicle load.

Location	Load
0	Only driver in the car, or there is a front passenger in addition to the driver in the car.
1	All the seats occupied with no load in the Load space.
2	All the seats occupied plus an evenly distributed load in the Load space.
3	Driver only, plus an evenly distributed load in the Load space.

# INSTRUMENTS AND CONTROLS

---

## Light Lever Switch



*Take care not to dazzle oncoming vehicles when switching between the main and dipped beams.*



## Headlamp Main/Dipped Beams Switching

When the vehicle is powered on and the dipped beams are turned on, push the light lever switch towards the instrument panel to turn on the main beam. At this

time, the main beam indicator in the instrument pack will illuminate. Push or pull the light lever switch once again to switch to the dipped beam.

## Main Beam Flash

To briefly flash the main beam on and off, pull the lever towards the steering wheel and then release.

## Automatic High Beam



*The Automatic High Beam serves only as an auxiliary function. The driver must check the status of the front lamps, and turn on the front lamps when necessary.*



***The Automatic High Beam may not operate normally in the following cases, but not limited to them, so the main and dipped beams should be switched manually:***

- ***The windscreen is dirty, broken or obstructed by other objects blocking the view of the sensor.***
- ***The lamps of other vehicles are missing, damaged, blocked or cannot be detected due to weather and other reasons.***
- ***When pedestrians, non-motor vehicles and other objects with no obvious light or reflected light are encountered.***
- ***When the headlamps and tail lamps of other vehicles cannot be detected due to the sensor view being impaired due to undulating road conditions such as bends, dips or hills.***
- ***When the car is driving on a winding road or mountainous road.***
- ***The wiper switch is in the "Fast" position.***

The automatic high beam system is designed to detect the light intensity information of the vehicle in front using the vehicle forward camera and switch the main beam on or off when certain conditions are met. When the automatic high beam is enabled, the automatic high beam indicator in the instrument pack illuminates. For some models, the automatic high beam function can be switched on/off via the infotainment system. The automatic high beam system can be turned on or off on the large screen.

In the case of automatic control, the system will automatically turn on the main beam when the surrounding environment is dark and there is no light detected from any vehicles ahead, or oncoming vehicles; when the surrounding environment is bright enough or the system detects the headlamps or tail lamps of the vehicle ahead or oncoming vehicles, the system will automatically turn off the main beam.

To enable the automatic high beam system, the following conditions must be met:

- l The light lever switch is in the AUTO position and the dipped beam turns on automatically.

## INSTRUMENTS AND CONTROLS

---

- 2 The vehicle is running and the speed is above 40 km/h.
- 3 Rear fog lamps are not switched on.

If the following conditions are met, the vehicle will automatically exit the automatic high beam system. If the system is disabled, pushing the main beam ON switch twice quickly towards the instrument panel can enable the automatic high beam system again. The function can be disabled for three times only in a starting cycle, otherwise it cannot be enabled again in the current starting cycle:

- When the automatic high beam system is enabled and the dipped beam lights are automatically turned on and the lighting system is manually switched to the main beam lights.
- When the automatic high beam system is enabled and the main beam lights are automatically turned on and the lighting system is manually switched to the dipped beam lights.
- When the automatic high beam system is enabled, the main beams are automatically turned on and the main beam flash switch is operated.

### IMPORTANT

The Automatic High Beam function uses data from the front view camera, always keep the windscreen clean and free from residue in this area to maintain optimum performance of this system. Any damage in this area, such as stone chips must be repaired at the earliest convenience.

## Direction Indicators



Move the light stalk switch down to indicate a LEFT turn . Move the light stalk switch up to indicate a RIGHT turn. The corresponding GREEN direction indicator in the instrument pack will flash when the turn signal lamps are working. Rotating the steering wheel will cancel the indicator operation (small movements of the steering wheel may not initiate the self cancelling). To indicate

a lane change, move the lever briefly and release, the indicators will flash three times and then cancel.

If the light lever switch is gently moved this will activate the "lane change function". The light lever switch will reset immediately and the direction indicators will flash 3 times.

# INSTRUMENTS AND CONTROLS

---

## Rear Fog Lamps



*Fog lights should only be used when visibility is below 100m - other road users could be dazzled in clear conditions.*

When the vehicle is powered on and the dipped beam lights are active, press the rear fog lamp switch which is located at the top left of the Infotainment screen to switch on the rear fog lamps. The indicator will illuminate on the instrument panel when the rear fog lamps are on .

## Hazard Warning Lamps

Press the hazard warning lamps button  , to turn on the hazard warning lamps. At this time, all turn signal lamps and direction indicators will flash together. Press the button again to turn off the hazard warning lamps. All turn signal lamps and direction indicators will stop flashing.

## Wipers and Washers

### Front Windscreen Wiper and Washer Operation

When the vehicle is powered on, operate the lever switch to select different wiping modes.



- HI: Fast Speed Wipe
- LO: Slow Speed Wipe
- INT: Automatic Wipe
- OFF: Wiper Off (Default position)

- Ix: Single Wipe
- ### Automatic Wipe

By pushing the lever switch up to the automatic wipe position ( INT position as shown), the wipers will operate automatically.

Move the automatic wipe speed adjustment switch ( I as shown) to adjust the automatic wipe speed. This speed also changes with the vehicle speed. As the vehicle speed increases, the wipe interval becomes shorter. As the vehicle speed decreases, the wipe interval becomes longer.

### Slow Speed Wipe

By pushing the lever switch up to the slow speed wipe position ( LO position as shown), the wipers will operate at slow speed.

### Fast Speed Wipe

By pushing the lever switch up to the fast speed wipe position ( HI position as shown), the wipers will operate at fast speed.

# INSTRUMENTS AND CONTROLS

---

## Single Wipe

By pressing the lever switch down to the single wipe position ( 1x position as shown) and releasing it, the wipers will perform a single wipe. If the lever switch is held in the single wipe position ( 1x position as shown), the wipers will operate continuously until it is released.

**Note: When the car is stationary, if the bonnet is opened, the front wiper/washer operation will be disabled.**

### IMPORTANT

- Avoid operating the wipers on a dry windscreen.
- In freezing or extremely hot conditions, make sure that the wiper blades are not frozen or adhered to the windscreen.
- In winter, remove snow or ice from around the wiper arms and blades, including the wiped area of the screen.

## Front Windscreen Wash and Wipe

By pulling the lever switch towards the steering wheel, the windscreen washers will operate immediately. After

a short interval, the wipers will commence operating in conjunction with the washers.

**Note: The wipers continue operating for three wipes after the lever switch is released. After several seconds, there will be a further wipe to remove any washer fluid from the windscreen.**

### IMPORTANT

If the washers fail to deliver the screen wash solution (dirt or ice may have blocked the jets), release the lever immediately. This will prevent the wipers from operating, and the consequent risk of visibility being impaired by dirt smearing across the unwashed windscreen.

### **Rear Windscreen Wash and Wipe**

When the vehicle is powered on, the rear wipers and washers can operate.

### **Intermittent Wipe**

Press the intermittent wipe button and release, the wipers will wipe three times at once, then intermittently wipe, and press the intermittent wipe button again to turn off the intermittent wiping. Toggling the automatic wipe speed adjustment switch can adjust the time period between the Intermittent wipes.

### **Wash/Wipe**

By pulling the lever switch towards the instrument, the rear window washers will operate immediately.

The wipers continue operating for a further three wipes after the lever is released. After several seconds, there will be a further wipe to remove any fluid draining down the screen.

**Note:** *When the tail gate is opened, rear wiper operations will be disabled.*

**Note:** *After the windscreen wipers are switched on, if the shift lever is in “R” position, the rear wiper will operate.*

# INSTRUMENTS AND CONTROLS


---

## Steering System

### Steering Wheel Position Adjustment



**DO NOT attempt to adjust the position of the steering wheel while the car is in motion. This is extremely dangerous.**



Adjust the steering wheel position to suit your driving posture:

- 1 Fully release the locking lever (as indicated by the arrow).
- 2 Hold the steering wheel in both hands and tilt it up or down to move the wheel into the most comfortable position.
- 3 Push or pull the steering wheel towards or away from the body.
- 4 Once a comfortable driving position has been selected, pull the locking lever fully to lock the steering wheel into its new position.

### Electric Power Steering



***If the electric power steering fails, the steering may appear very heavy, which will significantly affect driving safety.***

The electric power steering system works only when the vehicle is in READY mode. The system operates via a motor with assistance levels automatically adjusted based on vehicle speed, steering wheel torque and steering wheel angle.

## IMPORTANT

Holding the steering wheel on full lock for long periods will result in a reduction in power assistance causing a heavier feel to the steering for a short period time.

### Steering Mode Switching

The electric power steering system provides 3 different steering modes:

- 1 Normal: provides moderate power assistance.
- 2 Light: provides a high level of assistance, with a light feel.
- 3 Heavy: provides low level power assistance, with a heavier feel.

Please select when stationary via the infotainment system, enter the steering mode screen and select the desired mode.

# INSTRUMENTS AND CONTROLS

---

## Horn



Press the horn button area (as indicated by the arrow) on the steering wheel to operate the horn.

**Note:** *The vehicle horn button areas and the driver's airbag are located in close proximity on the steering wheel. The illustration shows the position of the horn (indicated by arrow). Please ensure that you press in this area to avoid any potential conflict with the operation of the airbag.*

### IMPORTANT


To avoid possible SRS issues, please do not press with excessive force or hit the airbag cover when operating the horn.

## Power Socket



*Use of the front console power socket and the USB port when the vehicle is not started will consume the battery power; extended use will cause premature discharging of the vehicle battery, and the vehicle may thus cannot be started.*

## Front Console Power Socket



The front console power socket is located in the front of the center console, which can provide 12V voltage when serving as a power outlet after the vehicle is powered on.

There are also Type-A port ( 1 as shown) and Type-C port ( 2 as shown) equipped on both sides of the 12V front console power socket, which can either provide 5V voltage when serving as the power outlet, or realize the data transmission function.

## Rear USB Port



## INSTRUMENTS AND CONTROLS

---

There is a USB port at the rear centre console, which can provide a 5V power source as a power outlet after the vehicle is powered on.

***Note: The vehicle's USB ports may not support some fast charging devices.***

### Wireless Charging System for Mobile Phones\*

The wireless charging function can realize the charging of the mobile phone under the condition that the mobile phone does not need a wire connection through electromagnetic induction.

**Note:** *It only works with mobile phones certified to the WPC Qi standard.*

### Wireless Charging of Mobile Phones



The mobile phone wireless charging area is located in front of the shift lever and the charging function can be used when the vehicle is powered on. Place the mobile phone right side up with the back attaching to the charging area for wireless charging.

**Note:** *Only one mobile phone can be charged at a time.*

## INSTRUMENTS AND CONTROLS

---

**Note:** *On bumpy roads, the wireless charging function of the mobile phone may intermittently stop and resume. If the mobile phone deviates from the charging area and stops charging, it will need to be placed back in the rechargeable area.*

**Note:** *The size of each brand of mobile phone is different, and the position of the charging coil on the mobile phone is different. Please adjust the position of the mobile phone accordingly. In addition, the case of some mobile phones may have an impact on wireless charging. It may be necessary to adjust or remove the case to achieve wireless charging.*

If the mobile phone cannot be charged properly, please make sure that there is no foreign matter in the wireless charging area or wait for the wireless charging area to cool down before further attempt. If it still fails, seek an MG Authorised Repairer.

### IMPORTANT

When the wireless charging system of the mobile phone is being used, make sure that the smart key is 20cm or more away from the wireless charging area. Do not place coins, IC cards, metal keys, or other items with a large amount of metal composition in the wireless charging area with your phone. This may result in the failure of wireless charging function and create a safety hazard.

## Rearview Mirrors

The vehicle is fitted with rear view mirrors. These consist of a door mirror fitted to each door and a centrally mounted interior mirror. Rear view mirrors reflect situations directly behind or on both sides of the vehicle thus expanding the driver's field of vision.


The rearview mirrors are safety-critical parts. Proper use and reasonable mirror angle adjustment can improve the driver's driving safety and comfort.

## Exterior Rearview Mirrors

The exterior rearview mirrors feature a manual or electric folding function, this helps avoid damage and allows folding when manoeuvring through narrow passages.

In addition to the manual or electronic folding function, each mirror glass features heating elements and electronic angle adjustment with a memory function.

**Note:** *Objects viewed in door mirrors may appear further away than they actually are.*



## Electric Adjustment of Door Mirror Glass

The exterior rearview mirror glass adjustment switch is located under the instrument panel on the driver's side and the mirror adjustment function will work when the vehicle is powered on.

- Rotate the round knob in the middle to select left ( L ) or right ( R ).

# INSTRUMENTS AND CONTROLS

---

- Move the knob in the desired direction to adjust the angle of the exterior mirror glass.
- Upon completion of the adjustment, rotate the knob back to the central position, this will ensure no accidental adjustment of the mirror.

## Manual Folding of Door Mirror\*

For vehicles not fitted with the electric door mirror fold option, the exterior mirrors can only be folded backwards manually.

## Electric Folding of Door Mirror\*

For vehicles fitted with electric door mirror folding, When the vehicle is powered on, rotate the knob to the middle position ( O ) , and push the knob down.The door mirrors will be folded automatically. Pushing the knob downwards again will return the mirrors to their original position.

**Note:** *While unlocking/locking the vehicle, the exterior rearview mirrors will be deployed/folded automatically.*

**Note:** *For vehicles equipped with electrical folding door mirrors, if the mirrors have been moved from their positions by manual or accidental means, they can be reset by operating the knob to complete fold and deployment one time.*

## Mirror Glass Heating

The door mirrors have integral heating elements which disperse ice or mist from the glass.

The heating elements operate while the Heated Rear Window is switched on, that is, only when the vehicle is powered on, and the heated rear window is turned on,  the heating function of the exterior rearview mirrors will work.

### **Note:**

- ***Door mirror glass adjustments are operated by electrical motors. Operating them directly by hand may damage the internal components.***
- ***Washing or flushing door mirrors with high pressure water jets or car washes may result in electrical motor failure.***

## Interior Rearview Mirror

Adjust the body of the interior rearview mirror to achieve the best possible view. The anti-dazzle function of the interior rearview mirror helps reduce glare from the headlamps of following vehicles at night.

## Automatic Anti-dazzle Interior Rearview Mirror\*



1 Operation Indicator

2 Automatic Anti-dazzle Function Switch

3 Light Sensor

After the car is powered on, the automatic anti-dazzle function is switched on automatically (operation indicator ON). If the system detects a following vehicle where the headlamps may dazzle the driver, the light sensor switches on the anti-dazzle function. Press the automatic anti-dazzle function switch (operation indicator OFF) to switch off the automatic anti-dazzle function, and press it again to re-start this function.

The automatic anti-dazzle function may be impaired or limited in the following situations:

- The lights of the following vehicle are not detected by the light sensor.
- Reserve gear is selected.

**Note:** *Attaching film on the rear window may have influences on the usage of automatic anti-dazzle function.*

## INSTRUMENTS AND CONTROLS

---

### Manual Anti-dazzle Interior Rearview Mirror\*



Move the lever at the base of the interior rearview mirror to change its angle, so as to achieve the anti-dazzle function. Normal visibility is restored by pulling the lever back again.


**Note:** *In some circumstances, the view reflected in a 'dipped' manual mirror can confuse the driver as to the precise location of following vehicles.*

## Sunvisor



*The vanity mirror on the driver side should only be used when the car is stationary.*

*front seat is active, serious injury or even death to the child may be caused.*



Sunvisor ( 1 ) and vanity mirror ( 2 , optional for some models) are arranged on the roof ahead of both the driver and the front passenger.

**A warning label ( 3 ) will be provided on each sunvisor to warn the driver and passengers: NEVER use a rearward-facing child restraint when the SRS in the**

# INSTRUMENTS AND CONTROLS

---

## Windows

5 Rear Window Isolation Switch


### Power Operated Window Switch



- 1 Front Left Window Switch
- 2 Front Right Window Switch
- 3 Rear Left Window Switch
- 4 Rear Right Window Switch

## Window Operation

The electric windows can be operated when the vehicle is powered on (Doors should be closed during operation).



Press the window control switch ( 1 ~ 4 ) down to the "1" position (Position C ) to lower the window, and pull the switch up to the "1" position (Position B ) to raise the window. The window will stop moving as soon as the switch is released.

### "One-Touch" Down

Press the window control switch ( 1 ~ 4 ) down to the "2" position (Position D ) and release, the window automatically descends to fully open. Window movement

can be stopped at desired position at any time by operating the corresponding switch during descent.

### "One-Touch" Up

Depending on vehicle specification, some windows may have the "One-Touch" up function. Lifting the switch to the "2" position (Position A ) and releasing will automatically close the window completely. Window movement can be stopped at a desired position at any time by briefly operating the switch again during ascent.

**Note:** *The front and rear passenger windows can also be operated by individual window switch mounted on each door. If the rear window isolation switch has been activated, the window switches on rear doors will not work.*

### Rear Window Isolation Switch


Press the switch ( 5 ) to isolate the rear window controls (an indicator lamp in the switch illuminates), and press again to restore control.

## **INSTRUMENTS AND CONTROLS**

---

*Note: If there is a power interruption during the raising or lowering of the window, the “One-Touch” Up and “Anti-Trap” features will be lost. To restore this feature, fully close the window and hold the switch for 5 seconds in the closed position, fully open the window and press the switch for another 5 seconds.*

## Interior Lighting



Press one of the switches ( 2 ) to turn the corresponding courtesy light on, press again to turn off.

### Automatic Operation

Press the switch ( 1 ) to turn on automatic operation, press it again to turn off the function.

When the automatic operation is enabled, the courtesy light illumination occurs automatically whenever the followings occur.

- The vehicle is unlocked.
- Any door is opened.
- When the vehicle equipped with a light sensor detects that the ambient light is in dark/or the side lamp illuminates/or the side lamp turns off for 30 s, switch off the power supply.

**Note:** *Under normal circumstances, if a door or the tailgate is left open for longer than 15 minutes, the interior lights will extinguish automatically. In case of low battery, the interior lights will extinguish quicker.*

# INSTRUMENTS AND CONTROLS

---

## Driver Monitor System

### Indirect Driver Fatigue Reminder System



*The driver should always ensure that his/her physical state is suitable for driving even if the vehicle is equipped with an indirect driver fatigue reminder system. NEVER drive the vehicle when fatigued.*



*The indirect driver fatigue reminder system cannot always identify the driver's fatigue level accurately. It calculates the fatigue level through the driver's operation status instead of monitoring the driver's actual physical characteristics such as distraction, and cannot provide emergency reminder to the driver who has just fallen into fatigue.*

The driver attention warning system calculates the driver's fatigue level by comparing information such as vehicle speed and steering wheel angle with basic data obtained based on mass data statistics. The system will constantly compare the calculated fatigue level with the current operation state of the driver. If the system recognizes that

the driver is already in a fatigued state, a warning will be issued.

When the indirect driver fatigue reminder system is turned on, the vehicle speed is over 37 mph / 60 km/h, the driver attention warning system will operate. When the indirect driver fatigue reminder system is off, the vehicle speed is over 43 mph / 70 km/h, the function will automatically start, and the driver attention warning system will operate. When the driver performs the following operations, the system will stop monitoring the driver's fatigue level:

- 1 The driver removes the seat belt and opens the driver door;
- 2 The stop time exceeds 15 minutes;
- 3 The power systems is turned off.

### System Settings

The indirect driver fatigue reminder system can be set on the infotainment display.

**Note:** *The driver attention warning system will not trigger in the following conditions even if it is enabled:*

- *Driving on a continuous curve;*
- *Driving on a poor quality road surface;*
- *Driving on congested roads or roads with lots of traffic lights.*

**Note:** *The time threshold value and vehicle speed provided in the system function description are just for your reference.*

# INSTRUMENTS AND CONTROLS


---

## Storage Devices

### Instructions for Use

- Please close all storage devices when the car is in motion. Leaving these storage devices open may cause personal injury in cases of a sudden start-off, emergency braking and a car accident.
- Do not place flammable materials such as liquid or lighters in any storage devices. The heat in hot conditions may ignite flammable materials and lead to a fire.

### Glove Box




To open the glove box, press the glove box open button (as indicated by the arrow). The glove box light will automatically illuminate.

Push the cover forward to close the glove box. Make sure the glove box is fully closed when the vehicle is being driven.

## INSTRUMENTS AND CONTROLS

### Storage Box

#### Centre Console Front Storage Box



The centre console front storage box is located in front of the centre console armrest box.

#### Centre Console Rear Storage Box



The centre console rear storage box is located at the rear of the centre console.

# INSTRUMENTS AND CONTROLS

---

## Centre Console Armrest Box



Lift the centre console armrest (as indicated by the arrow) to open the centre console armrest box. Put the centre console armrest down gently to close the centre console armrest box.

### Glasses Box



*The glasses box should only be used when the vehicle is stationary.*



The glasses box is located in the proximity of the front interior lamps. Press the panel (as indicated by the arrow), and place the glasses into the glasses box after opening it. Close the glasses box when it is not in use.


***Only glasses with standard frames should be placed in the glasses box.***

## Cup Holder



*DO NOT place hot drinks in the cup holder whilst driving. Spillage may result in personal injury or damage.*

## Centre Console Cup Holder



The centre console cup holder is located in front of the centre console armrest assembly, where a cup or beverage bottle can be placed.



## **Air Conditioning**


---

- 82 *Ventilation*
- 85 *A/C Control Panel*
- 87 *Air Conditioning Control Interface*
- 91 *Infotainment System\**

# AIR CONDITIONING

---

## Ventilation



- 1 Side Vents
- 2 Windscreen/Defrost Vents
- 3 Centre Vents
- 4 Front Footwell Vents
- 5 Front Side Window Vents


The A/C system is used to adjust the temperature, speed, humidity and cleanliness of the air in the vehicle. Fresh air is drawn in through the air intake grille under the windscreen and the A/C filter. Always keep the air intake grille clear of obstructions such as leaves, snow or ice.

### A/C Filter

The A/C filter is used to filter the air. To remain fully effective, the filter should be replaced at the recommended service interval.

### Vents

#### Centre Vents Adjustment



3


Slide the button in the centre of the louvres completely to the left or right to open or close the vent.

Toggle the button at the centre of each vent up and down, left and right to regulate the air direction.

# AIR CONDITIONING

---

## Side Vents Adjustment



Slide the button in the centre of the louvres completely to the left or right to open or close the vent.

Toggle the button at the centre of each vent up and down, left and right to regulate the air direction.

## A/C Control Panel

### Control Panel



- 1 A/C Control Shortcut
- 2 Defrost/Demist Button
- 3 Heated Rear Window Button

### A/C Control Shortcut



Press the A/C Control Shortcut to switch the system on, all functions will revert to the state before shutdown. Press again to switch off.

### Defrost/Demist Button



Press Defrost/Demist Button on the control panel, the indicators on the button and display illuminate,

the A/C cooling and external circulation functions are switched on, and the system enters the defrost/demist function to clear the windshield and side windows.

Press again to switch off. The indicator will go off and the system will return to the previous state.

Whilst the defrost/demist is selected, operate the A/C on/off button to turn the compressor on/off; operate the air recirculation button to switch between internal recirculation and external circulation; operation of either of these functions will not affect the defrost/demist function; operation of any other air distribution modes will quit defrost/demist.

### Heated Rear Window Button



*The heating elements on the inside of the rear window are easily damaged. DO NOT scrape or scratch the inside of the glass. DO NOT stick labels over the heating elements.*



Press the Heated Rear Window Button to switch the function on or off. The button indicator illuminates when the function is on, and is extinguished

## AIR CONDITIONING


---

when the function is off. The heated rear window features a timer function and will automatically switch off after a preset time. To continue to use the heated rear window, operate the button again.

**Note:** *The heated rear window function will only operate when the vehicle is in the READY state.*

## Air Conditioning Control Interface

### Air Conditioning Control Interface - Connected Car \*



- 1 Economy Mode
- 2 Air Recirculation Mode
- 3 Air Distribution Mode
- 4 Cooling On/Off
- 5 System On/Off
- 6 Auto Mode
- 7 Blower Speed Increase
- 8 Temperature Control
- 9 A/C Setting
- 10 Blower Speed Decrease

#### System On/Off

Touch the System On/Off Button on the control interface to switch the system on or off.

#### Cooling On/Off

Touch the A/C On/Off Touch Button to turn the A/C cooling function ON/OFF.

# AIR CONDITIONING

**Note:** After the occupant left the vehicle, the vehicle will activate anti-mould function automatically according to the A/C usage status, therefore to provide clean and fresh air in next drive.

## Auto Mode



Set the target temperature required and then press the AUTO touch button to enable the auto mode function. In auto mode, the air distribution mode, blower speed and so on are automatically adjusted to reach and maintain the required temperature.

Manually adjust the air distribution mode or blower speed to exit auto mode. In this case the AUTO indicator will extinguish.

## Air Distribution Mode

Select the corresponding Air Distribution Mode Touch Button as required to regulate the air distribution mode.

Touch Button	Air Distribution Mode
	Windscreen Mode

	Face Mode
	Feet Mode
	Windscreen and Face Mode
	Windscreen and Feet Mode
	Face and Feet Mode
	Windscreen, Face and Feet Mode

**Note:** The air distribution mode can also be switched by touching the air outlet area of the control interface.

Windscreen Mode: Directs air to the windscreen/defrost and front side window vents.

**Note:** In this mode, a small amount of airflow will be directed to the side vents.

Face Mode: Directs air to the side and centre vents.

Feet Mode: Directs air to the footwell vents.

**Note:** In this mode, a small amount of airflow will be directed to the side, windscreen/defrost and front side window vents.

Windscreen and Face Mode: Directs air to the windscreen/defrost, front side window, side and centre vents.

Windscreen and Feet Mode: Directs air to the windscreen/defrost, front side window and footwell vents.

**Note:** In this mode, a small amount of airflow will be directed to the side vents.

Face and Feet Mode: Directs air to the side, centre and footwell vents.

Windscreen, Face and Feet Mode: Directs airflow to the windscreen/defrost, front side window, side, centre and feet vents.

### Air Recirculation Mode

Touch the air recirculation mode touch button as needed to adjust the air recirculation mode.



During internal recirculation mode, the A/C system circulates the air inside the vehicle to meet the requirements of rapid cooling or heating, and at the same time, it can prevent the outside dirty air from entering the vehicle.



During the external circulation, the A/C system draws air from outside the vehicle to ensure fresh air enters the vehicle.



During the automatic circulation, the A/C system automatically adjusts the internal or external circulation according to the actual situation.

**Note:** Leaving the system in internal recirculation mode can cause the windscreen to mist. If this happens, turn on the defrost/demist mode.

# AIR CONDITIONING

---

## Economy Mode

Touch the ECO touch button, the air conditioning system will enter Economy Mode, and the ECO indicator in the button illuminates. In the Economy Mode, the air conditioning system will run at low energy consumption, so as to prolong the driving range.

**Note:** *Selection of the ECO mode will impact situations that require maximum heating or cooling.*

## Temperature Control

Touch the temperature control touch button to regulate the temperature of the air supplied by the vents.

## Blower Speed Control

Touch the blower speed control touch button to regulate the blower speed.

### Infotainment System\*

#### Important Safety Information

- Do not attempt to fit, repair or modify the infotainment system by yourself, because there are high-voltage components in the device, which may cause electric shock. For internal inspection, adjustment or repair, please consult a local MG Authorised Repairer.
- Do not allow this infotainment system to come into contact with liquids and foreign objects. If any of them enter the system by accident, please park your vehicle at a safe place, immediately switch off the power and contact a local MG Authorised Repairer for service. Do not use the infotainment system in this condition because doing so may result in a fire, electric shock, or other failure.
- If you notice smoke, abnormal noises or odours from the infotainment system, or any other abnormal signs on the screen, switch off the power immediately and contact a local MG Authorised Repairer for service. Using this infotainment system in this condition may result in permanent damage to the system.
- Operation of the infotainment system is prohibited whilst the vehicle is in motion, so as to avoid affecting the driving safety due to distractions. Please park your vehicle at a safe location and apply the parking brake before making the necessary adjustments or watching videos.
- Extremely high or low temperatures will interfere with normal operation of the infotainment system. If your vehicle is parked in direct sunlight or in a cold place for a long time, the system may not work properly. Once the temperature inside the car is back to normal, the system will resume normal function. If it does not resume, please contact a local MG Authorised Repairer for service.
- Excessive use of the entertainment and navigation system without the vehicle being driven or in READY mode can drain the vehicle low voltage battery.
- The navigation function of the infotainment and navigation system is only used to assist you in driving. Routes and navigation information displayed in this infotainment and navigation system are for reference only, so the safe driving rules, actual traffic signals and all current traffic laws must always be followed.

# AIR CONDITIONING

---

- When using a mobile phone, keep the antenna of the mobile phone away from the screen to prevent the disruption of video signal in the form of spots, colored stripes, etc. on the screen.

## Privacy and Data Sharing

When using this infotainment system for the first time, you must read the Privacy Policy carefully and make a choice.

In the settings interface of the infotainment system, you can authorise / disable the data sharing service at any time. Please note that once disabled, the relevant functions will not be available.

**Note: Restoring factory settings or upgrading software may require you to reauthorise data sharing services.**

## Precautions for Screen Usage

- To protect the screen against damage, always touch the screen buttons with your finger (A touch pen may be used for special calibration).
- Please take care to protect the screen against direct sunlight. Extended exposure to direct sunlight will result in screen malfunction due to high temperature.

- When the temperature is beyond the operating temperature range ( -30 °C to +85 °C), please do not use the screen, because the screen may not operate normally and could be damaged.
- Do not use excessive force to drag or press the screen, damage or scratching may occur.
- To remove dust from the screen or clean the screen, please turn the system off first, then wipe with a dry soft cloth. When wiping the screen, take care not to scratch the surface. Do not use irritative or abrasive chemical cleaners.

## Basic Operations

### Control Panel



- 1  (HOME) Button  
Short press to return to the main interface; long press to restart the system.
- 2 Volume Down Button
- 3 Volume Up Button

## Main System Interface

### Page one



- 1 Weather  
Touch to enter the weather interface. Please refer to the Infotainment System Manual for details.
- 2 Energy Management  
Touch to enter the Energy Management interface.
- 3 A/C Display  
Displays the temperature and other information. Pull down to enter the A/C interface.

# AIR CONDITIONING

---

## 4 Radio/Music

Touch to enter the Radio/Music interface.

## 5 Navigation\*

Touch to enter the Navigation interface. Refer to Infotainment System Manual for details.

## 6 Status Bar

Displays the signal strength and other information. Pull down to enter the shortcut control screen to set the screen brightness, car control, etc.

## 7 Shortcut Icons

-  Touch to enter the main system interface.
-  Touch to enter the Navigation interface.
-  Touch to enter the Music interface.
-  Touch to enter the Call interface.
-  Touch to enter the Vehicle Setting interface.


## 8 Android Auto

Touch to enter the Android Auto interface.

## 9 Apple CarPlay

Touch to enter the Apple CarPlay interface.

## Page Two



## 1 A/C

Touch to enter the A/C interface.

## 2 Radio

Touch to enter the Radio interface.

## 3 User

Touch to enter the User interface.

## 4 Phone

Touch to enter the Bluetooth Phone interface.

## 5 Vehicle

- Touch to enter the Vehicle Settings interface.
- 6 Video  
Touch to enter the Video interface.
- 7 360 \*  
Touch to enter the 360 around view system. Refer to the "360 Around View System\*" section in this manual for details.
- 8 Settings  
Touch to enter the Setting interface.
- 9 Rescue Call  
Touch to enter the Rescue Call interface. Please refer to the Infotainment System Manual for details.
- 10 MG Touchpoint  
Touch to enter the MG Touchpoint interface.
- 11 User Manual  
Touch to enter the User Manual interface.
- 12 Track mode \*  
Touch to enter the Track mode interface.

## **Power On/Off**

### **Power On**

When the vehicle is powered on, the system will automatically turn on.

When the system is on, press and hold the power button on the system control panel for about 10 seconds, the system will restart automatically.


### **Power Off**

When the vehicle is locked, the system will automatically power off.

# AIR CONDITIONING

---

## Steering Wheel Control Buttons



- 1 **Speech Recognition Function Button**  
Short press to turn on the speech recognition function; short press again to exit the speech recognition function.
- 2 **Infotainment/Instrument Display Button**  
The function adjustment button is a dual-purpose button, which when pressed will switch control

between the Instrument display and the Infotainment system.

- 3 **Phone Button**  
Short press to answer an incoming call, Long press to end the call.
- 4 **Function Adjustment Button**  
When in the infotainment mode: Push up: Volume up; Push down: Volume down; Push to the left: Previous track; Push to the right: Next track; Short press: Mute or Cancel Mute.  
When in the A/C mode: Push up, Temperature increases; Push down, Temperature decreases; Push to the left, Blower speed decreases; Push to the right, Blower speed increases; Short press: turn on the AUTO mode.
- 5 **Right Shortcut Button**  
The user-defined function of the button can be set to AC, Driving Mode, 360 \* etc. in the vehicle settings.
- 6 **Left Shortcut Button**  
The user-defined function of the button can be set to AC, Driving Mode, 360 \* etc. in the vehicle settings.

## Volume Adjustment

- The audio volume can be adjusted using the control panel , the buttons on the steering wheel and the shortcut control page. During volume adjustment, the system automatically pops up a volume indication window which changes smoothly with the adjustment process.

**Note:** *The playback volume of Bluetooth music can be adjusted by the device itself and the Infotainment player.*

## Bluetooth Phone

### Instructions for Use

- Connection to all mobile phones featuring Bluetooth wireless technology is not guaranteed.
- The mobile phone used must be compatible with the infotainment system so that all functions of the connected Bluetooth device can function correctly.
- When using Bluetooth wireless technology, the infotainment system may not operate all functions on the mobile phone.
- When transmitting voice and data via Bluetooth technology, the straight-line distance between the infotainment system and the mobile phone should not exceed 10 meters. However, the actual transmission distance may be shorter than the estimated distance, depending on the usage environment.
- When the infotainment system is turned off, the Bluetooth connection will be disconnected.
- Due to Bluetooth wireless connection, interruption or error occurring in the process of transmission in some extreme cases, the infotainment system may be unable to be paired and connected with the mobile phone.


# AIR CONDITIONING

---

At this time, it is recommended to clear the paired devices in the device list on the mobile phone and the infotainment system, and conduct pairing again.

Please connect a bluetooth device first before attempting to use any Bluetooth phone functions, Refer to "Bluetooth Pairing and Connection" in "Settings" section for details.

Touch the [Phone] card on the main interface to enter the Bluetooth Phone interface.



## **Making a Call**

Calls can be made using the following methods:

- Call the number in Contacts.
- Call the number in Call History.
- Keypad input.
- Directly on the mobile phone.

## **Ending a call**

Calls can be ended using the following methods:

- Touch  to hang up.
- Long press  button on the steering wheel to hang up.
- Hang up on the mobile phone.

## **Incoming Call**

### ***Answer an Incoming Call***

- Touch  to answer an incoming call.
- Short press  button on the steering wheel to answer an incoming call.
- Answer an incoming call on the mobile phone.

### ***Reject an Incoming Call***

- Touch  to reject an incoming call.
- Long press  button on the steering wheel to reject an incoming call.
- Reject an incoming call on the mobile phone.

## **During a call**

During a call,

- Touch  to enter the Private Mode. Touch  to restore the Speaker Mode.
- Touch  to switch to the Microphone mute or Enable function.
- Touch  to enter the Keypad interface.
- Touch  to add a third-party call and maintain the current call. When there are two calls, short press  button on the steering wheel or touch the corresponding Contacts icon to switch the callers (only available when the mobile phone itself supports the three-way calling function).
- Touch  to see the Contacts.

**Note:** *In the private mode, you may proceed with the call with the mobile phone; the speakers and microphone of the entertainment system will be muted, but Bluetooth is still connected.*

**Note:** *It is illegal to operate a mobile telephone whilst driving. If you wish to make, or take a call using your mobile phone directly, please ensure you pull over in a suitable location and operate the mobile phone where it is safe and legal to do so.*

## Entertainment

### Precautions for Playing from a Storage Medium Mode

- The system supports USB drives and Bluetooth storage media.
- If the USB device media is not in use, DO NOT leave the device connected. This may result in connection deterioration.
- Do not remove USB device whilst media is playing. Failure to follow these instructions could result in corrupted data.
- Keep the USB port dry and free from debris. The port will become unusable if it is blocked.
- Due to differences in the compression ratio and bit rate of the multimedia formats downloaded from the Internet and other factors, the actual situation of the decoding result shall prevail.

# AIR CONDITIONING

---

## Connecting/Disconnecting a USB Storage Device

### Device

#### Inserting a USB Storage Device

Connect a USB device to the USB port for connection.

#### Removing the USB Storage Device

Check and confirm that there is no data being accessed, then pull out the USB storage device.

**Note: If any data loss or breach occurs whilst the USB storage device is inserted or being used, it will generally be unrecoverable. MG Motor accepts no responsibility for any data loss or breach.**

**Note: Some USB storage devices may be unidentifiable.**

**Note: The Infotainment system may not achieve its optimum performance when using some USB storage devices.**

**Note: Using a USB hub or extension cable may result in the USB device not being recognised.**

## Radio

Touch the [Radio] card in the main interface to enter the Radio interface.

Touch [DAB]/[FM] at the top of the screen to enter DAB or FM Radio interface.

## DAB



- 1 Click to empty the favorite.
- 2 Add a Station to /Remove a Station from Favorites.
- 3 Previous Station.
- 4 Pause/play.

- 5 Click to enter the program list.
- 6 Next Station.
- 7 Station list.
- 8 Click to enter the station preferences setting interface.

## FM



- 1 Click to empty the favorite.
- 2 Add a Station to/Remove a Station from Favorites.
- 3 Short press to automatically search for the previous valid station, and long press for quick FM.
- 4 Pause/play.

- 5 Short press to automatically search for the next valid station, and long press for quick FM.
  - 6 Station list.
  - 7 Click to enter the station preferences setting interface.
- Drag  to finely adjust the frequency modulation.

# AIR CONDITIONING

---

## Music

Touch the Radio/Music area in the main interface or  icon to enter the Music interface.

Touch [BT music] / [Online music] / [USB music] on the top of the screen to enter the corresponding music interface. Refer to Infotainment System Manual about the online music for details.

### Bluetooth Music

Before playing Bluetooth music, firstly connect the Bluetooth device. Refer to the "Bluetooth Pairing and Connection" in "Settings" section for details.



1 Track List.

2 Open/Close Play List.

3 Previous Track.

4 Pause/Play.


5 Next Track.

6 Sound Settings.

**Note: Some mobile phones or bluetooth devices may not support synchronized track lists, and the relevant information will not be displayed in the play list bar.**

## USB Music

Insert a USB storage device into the USB port, and the system automatically loads the music from the storage device.



- 1 Track List.
- 2 Single play mode or list play mode.
- 3 Previous Track.
- 4 Play/Pause.
- 5 Drag the progress bar to any playback point.
- 6 Next Track.
- 7 Touch to open the lyrics.
- 8 Random play mode.
- 9 Sound Settings.

# AIR CONDITIONING

---

## Video

Insert the USB storage device to the USB port. Touch [Video] on the main interface to enter Video Playback interface.



## 6 Play List.

- 1 Touch to switch to full screen playback mode.
- 2 Short press to switch to the previous video, and long press to fast rewind.
- 3 Play/Pause.
- 4 Short press to switch to the next video, and long press to fast forward.
- 5 Drag the progress bar to any playback point.

## Vehicle-Mobile Phone Interconnection

**Note:** *Due to the differences of mobile phone models and system versions, some mobile phones may not be able to use the vehicle-mobile phone interconnection function normally.*

### Apple CarPlay

Apple CarPlay enables information interaction between the mobile phone and the on-board infotainment system, including map, music, telephone, voice recognition and so on.

#### Connection Method

- 1 Confirm that your iPhone has the Carplay function and that it is turned on.
- 2 Connect the mobile phone to the infotainment system mainframe using an approved USB cable.
- 3 In the main interface, touch [Apple CarPlay] area to enter the Apple CarPlay interface.
- 4 After the vehicle and mobile phone are successfully connected, you can operate the iPhone using the infotainment system screen.

- 5 Press the HOME button on the control panel to return to the main system interface.

### Android Auto

Android Auto enables information interaction between the android mobile phone and the on-board infotainment system, including map, music, telephone, voice commands and so on.

Ensure the Android Auto software is downloaded to your phone using an APP from your regional APP supplier. Ensure that the function is enabled.

#### Connection Method

- 1 Connect the mobile phone to the infotainment system using an approved USB cable.
- 2 In the main interface, touch the [Android Auto] area to enter the Android Auto interface.
- 3 Operate according to the interface prompts, you can then use the phone functions once the connection is successful.

# AIR CONDITIONING

---

- 4 Press the HOME button on the control panel to return to the main system interface.

## **MG Touchpoint**

Touch [MG Touchpoint] in the main interface to enter the Maintenance interface. You can view the dealer information.

## **Vehicle Settings**

Touch [Vehicle] or  icon on the main interface to enter the Vehicle Setting interface. You can set the MG Pilot, Light, etc.

## **Settings**

Touch [Settings] on the main interface to enter the Settings interface. You can set the general settings, connection methods, traffic management, etc.

## **General**

Touch [General] on the Settings interface to enter the General Settings interface, where you can set the screen brightness, language, and time, etc.

## **Bluetooth Pairing and Connection**

The steps of Bluetooth pairing and connection are as follows:

- Touch [Bluetooth] on the Settings interface to enter the Bluetooth Connection interface, and turn on the Bluetooth switch.
- Vehicle Name: Displays the name of this vehicle. You can customize the name, the name of the vehicle hotspot will be updated synchronously after modification.
- The onboard mainframe will actively search for nearby Bluetooth devices that can be connected and display

them in [Other Devices]. You can also search for this device in your mobile phone for pairing. After pairing, the status bar will display the Bluetooth icon . If the pairing fails, please repeat the above steps.

The devices already paired and connected are displayed in the [Connected Currently] directory, only one Bluetooth device can be connected to this system.

In the Bluetooth Connection interface, you can choose whether or not to synchronize call history and contacts, disconnect the currently connected device, and pair with other devices in [Pairing history] or [Other devices] according to your requirements.

## WiFi Connection

WiFi connection steps are as follows:

- In the settings interface, touch [Wireless network], enter the WIFI connection interface, and turn on the WIFI switch.
- Select the WIFI with which you want to connect in the [Choose the Network] column to connect, or touch [Add network] to connect to a hidden WIFI by entering the WIFI name, security type or password.

**Note:** For your information security, it is recommended to choose a high security wireless network with security of WPA2.

## Hotspot Connection

In the settings interface, touch [Vehicle Hotspot], enter the vehicle hotspot interface, and turn on the Vehicle Hotspot switch.

- Vehicle name: displays the name of this vehicle, you can customize the name, the vehicle name on the vehicle Bluetooth will also be updated synchronously after modification.
- Hotspot Passcode: You can customize the vehicle hotspot password, the length of which must be greater than 8 characters.
- Hotspot network frequency band: 2.4GHz or 5GHz can be selected. 2.4GHz supports more devices connected to the vehicle hotspot, but interference may be easily caused, while 5GHz is the opposite. You can set the network band according to your needs.
- Device Connected: Displays the number of devices connected to the vehicle hotspot and the device information.

# AIR CONDITIONING

---

## Traffic Management

In the settings interface, touch [Data traffic management] to enter the traffic management interface, you can turn the online network switch on or off and view the traffic usage.

## Voice

In the settings interface, touch [Voice] to enter the voice setting interface to set the voice broadcast language, greetings, etc.

## Volume setting

In the settings interface, touch [Volume setting] to enter the volume setting interface to set the system sound, chime, etc.

## System

In the settings interface, touch [System] to enter the system setting interface. You can view the software version or upgrade the application software.

Touch [Upgrade] to enter the Upgrade interface, and select [Detect New Version]. If the system detects a new version,

you can download and install the new software version according to the interface prompt.

**Note: For software version, map and voice upgrade related functions, please contact a local MG Authorised Repairer for more details.**

## Activate

In the settings interface, touch [Activation] to enter the activation interface. If the activation process has not been completed, you can activate it here.

## Privacy Policy

In the settings interface, touch [Privacy policy] to enter the privacy policy interface, where you can view the privacy policy and choose whether to agree with it or not.

## **Seats and Restraints**

---

*110 Seats*

*116 Seat Belts*

*127 Airbag Supplementary Restraint  
System*

*136 Child Restraints*

# SEATS AND RESTRAINTS

---

## Seats

### Seat Positions and Backrest Angle



*To avoid personal injuries due to the loss of vehicle control, DO NOT adjust the seats while the vehicle is in motion.*

An ideal position of the seat should make sure your driving position is comfortable, which allows you to hold the steering wheel with your arms and legs slightly bent and control all the equipment.

Do Not incline the front seat backrest excessively. Optimum benefit is obtained from the seat belt with the backrest angle set to approximately 25 ° from the upright (vertical). To reduce the risk of injury from sitting too close to an inflating airbag, the front seats should be positioned as far rearward as practical. Take care when adjusting the height of front seats - the feet of the rear passenger could become trapped when the seat is lowered.

## Head Restraints



**Adjust the height of the head restraint so that the top of it is in line with the top of the occupant's head. This location may reduce the risk of neck injuries in the event of a collision. DO NOT adjust or remove the head restraints while the car is moving.**



**Do not hang anything on any head restraint or head restraint rod.**

The head restraint is designed to prevent rearward movement of the head in the event of a collision or emergency braking, thereby reducing the risk of head and neck injuries. The height of split type head restraint can be manually adjusted.



When adjusting a head restraint from low to high position, pull the head restraint directly upward, and gently press it downward after it reaches the desired height to make sure that it is locked in position. To remove the head restraint, press and hold the guide sleeve button (as indicated by the arrow) on the left of the head restraint, then pull the head restraint upward to remove it.

When adjusting a head restraint from high to low position, press the guide sleeve button (as indicated by the arrow) on the left of the head restraint, and press the head restraint downward; release the button after it reaches the desired

# SEATS AND RESTRAINTS


---

height, and gently press the head restraint downward to make sure that it is locked in position.

## Front Seats

**Note:** *The front seat functions of the vehicles are not completely the same depending on the model configurations.*

**Manual Adjustment (With the driver side as an example)\***



- Forward/Rearward Adjustment

## SEATS AND RESTRAINTS

Lift the handle 1 to slide the seat into an appropriate position, and release the handle to make sure that the seat is locked in position.


- **Cushion Height Adjustment\***

Lift the handle 2 repeatedly to raise the seat cushion, and press the handle 2 repeatedly downward to lower the seat cushion.

- **Backrest Angle Adjustment**

Lift the handle 3 to adjust the backrest to an appropriate angle, and release the handle to make sure that the backrest is locked in position.

**Electric Adjustment (With the driver side as an example)\***



## SEATS AND RESTRAINTS

---

- **Backrest Angle Adjustment**  
Move the switch 1 forward/backward to adjust the backrest until it reaches the desired angle.
- **Forward/Rearward Adjustment**  
Push the switch 2 along the direction of A to move the seat forward/rearward.
- **Cushion Height Adjustment**  
Pull or push the switch 2 along the direction of B to raise or lower the seat cushion.

### Rear Seats



- **Folding Rear Seats**  
To increase load space, fully lower (or remove) all head restraints of rear seats, pull up the respective control handles and fold the seat backrest forward.

**Note:** *If the rear seat head restraints are not fully lowered or the backrest of the front seat is inclined backward excessively, the folding of the rear seats is very likely to damage the back of the front seat or rear seat head restraints.*

- Unfolding and Locking Rear Seat Backrests

To return the rear seat backrest to an upright position, pull up the backrest control handle to release the lock, raise the rear seat backrest, when the desired upright position is reached, a 'click' will be heard.

**Note:** *When returning the rear seat backrest to the desired position, make sure that the rear seat belts are not trapped.*

### Front Seat Heating Function\*



*If bare skin is in contact with the heated seats for excessive periods of time, it may cause burns.*



The seat heating of this vehicle has three temperature levels, and the seat heating switch is located on the Air Conditioning Control interface of the display. After the vehicle is started, you can enable or disable the seat heating function on the Air Conditioning Control interface of the display, and adjust the heating level. When the cushion temperature reaches approximately 38°C or the backrest temperature reaches approximately 40°C, the heating function will be deactivated automatically.

### IMPORTANT

- DO NOT cover the heated seats with blankets, cushions or other insulation type objects or materials.
- If the seat exceeds a certain temperature and continues getting hotter when using the seat heating function, please turn off the seat heater switch and contact a local MG Authorised Repairer.
- Over use of the driver's heated seat may cause drowsiness and could affect safety.

# SEATS AND RESTRAINTS

---

## Seat Belts



***Incorrectly worn seat belts could cause injury or death in the event of an accident. Seat belts are designed for one person, DO NOT share seat belts.***



***DO NOT wrap a seat belt around when holding a baby or child in your arms. Remove any heavy coats or clothing when wearing a seat belt, failure to do so can affect protection provided by the seat belt.***



***Seat belts should not be wrapped around hard or sharp objects such as pens, spectacles or keys.***



***Seat belts cannot function correctly when the seats are reclined excessively. DO NOT drive when the seats are excessively reclined.***



This vehicle is equipped with seat belt warning lamp to remind you to fasten your seat belt. For details,

refer to "Warning Lamps and Indicators" in "Instruments and Controls" section.

While driving, all occupants must fasten their seat belt. Because:

- You can never predict if you will be involved in a collision accident and how serious it may be.
- The seat belts will automatically lock in the event of a collision or emergency braking. The correctly worn seat belt will make the strongest bone in your body bear the impact force, so that you and your vehicle decelerate together to prevent the out-of-control movement which may cause serious injury to the driver and passengers.
- Even in a minor traffic accident, the forces generated by a low-speed collision cannot be supported by your arms and hands.
- The experience has clearly demonstrated that correct wearing of seat belts is closely related to the effective protection of occupants in most collision accidents!

### Protection Provided by Seat Belts

**Note:** *It is of equal importance for passengers in the rear seats to fasten their seat belts correctly. Otherwise, passengers with seat belts not correctly fastened will be thrown forward in accidents, and will endanger themselves as well as the driver and other passengers. NEVER fasten the driver seat belt or use a buckle replacement when the driver seat is vacant or when exiting the vehicle.*

When the vehicle is in motion, the traveling speed of the occupants is identical to that of the vehicle. In the event of a 'head on collision' or emergency braking, the vehicle may stop, but the occupants will carry on traveling until they come into contact with a stationary object. This object may be the steering wheel, dashboard, windscreen and others. A correctly fastened seat belt will eliminate this risk of injury.

When the seat belt is worn correctly, it will lock automatically in collision accidents or emergency braking to reduce your speed together with the vehicle, so as to prevent the out-of-control movement which may cause serious injury to driver and passengers.



# SEATS AND RESTRAINTS

---

## Wearing Seat Belts



*Incorrectly worn seat belts could cause injury or death in the event of an accident.*



*Seat belts are designed for one person. DO NOT share seat belts.*



*DO NOT wrap a seat belt around when holding a baby or child in your arms.*



*Remove any heavy coats or clothing when wearing a seat belt, failure to do so can affect protection provided by the seat belt.*



*Seat belts should not be wrapped around hard or sharp objects such as pens, spectacles or keys.*



*Seat belts cannot function correctly when the seats are reclined excessively. DO NOT drive when the seats are excessively reclined.*

The seat belts fitted to your vehicle are designed for use by normal sized adults. This part of the literature refers to adult use. For advice on seat belt use with children, please see "Children and Seat Belts".

In order to maintain effective protection, the passengers must sit in the correct orientation, feet placed on the floor in front of them, with an upright body (no excessive recline) and the seat belt correctly fastened.

## Lap and Shoulder Belts

All seat belts are 3-point lap-shoulder belts, which should be used correctly as described below.

- 1 Adjust the seat correctly.
- 2 Hold the metal tab, pull the seat belt out steadily over the shoulder and across your chest. Ensure there is no twist on the belt.

## SEATS AND RESTRAINTS



- 3 Insert the metal tab into the buckle until you hear a 'click', this indicates the seat belt is securely locked.



- 4 Remove any slackness in the belt by pulling up on the diagonal section of the belt.

- 5 To release the seat belt, press the red button on the buckle. The seat belt will retract automatically to its original place.

### Correct Routing of the Seat Belts



**Ensure the seat belt is correctly positioned on the body, NEVER cross the neck or abdomen, NEVER pass the seat belt behind the back or under the arms.**



## SEATS AND RESTRAINTS

---

When wearing seat belts, the lap belt section should be positioned as low as possible across your hips, NEVER across the abdomen. In the event of a collision, the lap belt can apply a force on the hips and reduce the possibility of you slipping under the lap belt. If you slip under the lap belt, the belt will apply force on your abdomen, which may cause serious or fatal injuries. The diagonal section of the belt should cross the middle of the shoulder and the chest. In the event of emergency braking or collision, the diagonal section of the belt will be locked.

To ensure that the seat belts always provide maximum protection, ensure the belt is flat, not loose and contacts the body.

### Seat Belts Use During Pregnancy

Wearing correctly positioned seat belts will provide protection for both mother and unborn child in the event of a collision or emergency braking. The diagonal section of the seat belt should pass across the chest as normal, the lap section of the belt should pass below the belly, low and snug on the hip bones. NEVER position the belt on or

above the belly. Please consult your physician for further details.



Please consult your physician for further details.

### Seat Belts and Disabilities

It is a legal requirement that all occupants wear seat belts, this include people with disabilities.

Depending upon the disability, consult your physician for further details.

## Children and Seat Belts



***Proper protection measures must be taken for children during driving.***

For safety reasons, children must ride in a child restraint fixed to the rear seat.

### Infants



***Only recommended child restraints suitable for the age, height and weight of the child should be used.***



***NEVER carry a child or infant with your arms during driving. When collision accidents occur, the weight of the child will produce so great of a force that you will not be able to hold on to the child. The child will be thrown forward and suffer serious injury or even death.***

The seat belts fitted to your vehicle are designed for adults, they are not suitable for children. In the event of an accident or collision the children are not secure, it could cause death or serious injury.

Infants **MUST** use a suitable child restraint device. Please consult the child seat manufacturer's guidelines when selecting the correct seat. Follow the manufacturer's instructions on installation. Please refer to "Child Restraints" in this chapter for more details.

### Older Children



***NEVER share a seat belt amongst children. In the event of an accident or collision, the children are not secure. It could cause death or serious injury.***



## SEATS AND RESTRAINTS

---

As children grow and become older/larger, it will get to the stage when they no longer require child seat restraints. At this point they will require use of the vehicle standard seatbelt. Please ensure the seat belt is correctly positioned on the body of the child.

When fastening a seat belt for a child, always check it for correct positioning. Adjust the height of seat belt to ensure the shoulder belt is kept away from the child's face and neck. Position the lap belt across the hips as low as possible, and tighten adequately. Correct positioning means that the seat belts can pass the applied force to the strongest part of the child's body in accidents.

If the shoulder belt is too close to the child's face or neck, it may be necessary to use a child booster cushion (always ensure that it meets any relevant laws or standards).

### Seat Belt Pre-tensioners



***The seat belt pre-tensioners will only be activated once and then MUST BE REPLACED. Failure to replace the pre-tensioners will reduce the efficiency of the vehicle's restraint system.***



***If the pre-tensioners have been activated, the seat belts will still function as restraints, and must be worn in the event that the vehicle remains in a drivable condition. The seat belt pre-tensioners should be replaced at the earliest opportunity by an MG Authorised Repairer.***

The vehicle is fitted with seat belt pre-tensioners. These are designed to retract the seat belts and work in conjunction with the airbags in the event of a severe collision. They are designed to retract the seat belt and secure the occupant.

The airbag warning lamp on the instrument pack will alert the driver to any malfunction of the seat belt

pre-tensioners (refer to "Warning Lamps and Indicators" in the "Instruments and Controls" section).

The seat belt pre-tensioners can only be activated once, after activation in a collision they must be replaced. This may also involve replacement of other SRS components. Please refer to "Replacement of SRS Components" in "Airbags" of this chapter.

### IMPORTANT

- The removal or replacement of a pre-tensioner must be carried out by the technicians trained by the manufacturer.
- 10 years from the initial date of registration(or installation date of a replacement seat belt pre-tensioner), some components will need to be replaced by an MG Authorised Repairer.

# SEATS AND RESTRAINTS

---

## Seat Belt Checks, Maintenance and Replacement

### Seat Belt Checks



***Split, worn or frayed seat belts may not function correctly in the event of a collision, if there are any signs of damage, replace the belt immediately.***



***Always ensure the red release button on the seat belt buckle is pointing upwards ensure easy release in the event of an emergency.***

Please follow the instructions below to check the seat belt warning lamp, seat belt, metal tab, buckle, retractor and fixing device regularly:

- Fully extract the seat belt and allow to return slowly to ensure continual and complete smooth operation.
  - Visibly examine the seat belt system for missing or broken components or components that may affect the normal operation.
  - Check if the seat belt warning lamp functions normally. If the seat belt fails any of the above tests or inspections, please contact an MG Authorised Repairer.
- Insert the seat belt metal tab into the corresponding buckle and pull seat belt webbing close to the buckle quickly to check that the belt clasp locks.
  - Hold the metal tab and pull the seat belt forward quickly to check that the seat belt reel locks automatically, preventing the webbing from extending.
  - Fully extract the seat belt and visibly examine for twists, fraying, splits or worn areas.

### Seat Belt Maintenance



***DO NOT attempt to remove, install, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your MG Authorised Repairer. Inappropriate handling may lead to incorrect operation.***



***Ensure no foreign or sharp objects become lodged in the seat belt mechanisms. DO NOT allow liquids to contaminate the seat belt buckle, this could affect the buckle engagement.***

Seat belts should only be cleaned with neutral soap and warm water. DO NOT use any solvent to clean the seat belts. DO NOT attempt to bleach or dye the seat belts, or they may be weakened. After cleaning, wipe with a cloth and allow to dry. DO NOT allow the seat belt to fully retract before it is completely dry. Keep seat belts clean and dry.

If there are contaminants accumulated in the retractor, the retraction of the seat belt will be slow. Please use a clean and dry cloth to remove any contaminants.

# SEATS AND RESTRAINTS

---

## Replacing Seat Belts



*Collision accidents may damage the seat belt system. The seat belt system may not be able to protect users after damage, which may result in serious injury or even death. After an accident, seat belts should be checked and replaced as needed immediately.*

Seat belts should not require change after minor collisions, however, some other parts of the seat belt system may require attention. Please consult an MG Authorised Repairer for advice.

## Airbag Supplementary Restraint System

### Overview



*The airbag SRS provides ADDITIONAL protection in a severe frontal impact only. It does not replace the need, or requirement to wear a seat belt.*




*The airbags together with the seat belts provide optimum protection for adults, but it is not the case for infants. The seat belt and airbag systems in the vehicle are not designed for protecting infants. The protection required by infants should be provided by child restraints.*

In the corresponding position where airbags are fitted, there is a warning sign stating " AIRBAG ". The Airbag Supplementary Restraint System generally consists of:

- Front Airbags (fitted to the centre of the steering wheel and dashboard above the glove compartment)
- Seat Side Airbags (fitted to the outer side of the seat backrest cushion)

- Side Head Impact Protection Airbags (fitted behind the headlining)



### Airbag Warning Lamp



The airbag warning light is located in the instrument pack; if this light illuminates while the car is being driven, it indicates an SRS fault or seat belt pre-tensioner fault has been detected. In this case, please contact an MG Authorised Repairer for service immediately. Otherwise there may be the risk that the SRS

## **SEATS AND RESTRAINTS**

---

or the seat belt pre-tensioner cannot work properly in the event of a collision. The vehicle is equipped with airbag warning lamps to remind you of the status of the vehicle's safety system. For details, refer to "Warning Lamps and Indicators" in "Instruments and Controls" section.

### Airbag Deployment



*Front seat passengers should not place feet, knees or any other part of the body in contact with, or in close proximity to a front airbag.*



*To minimise the risk of accidental injury from inflating airbags, seat belts should be worn correctly at all times. In addition, both driver and front passenger should adjust their seat to provide sufficient distance from the frontal airbags, so as to avoid severe or even fatal injury when the airbag is deployed. If side airbags and side head impact protection airbags are fitted, both driver and front seat passenger should be seated to maintain sufficient distance from the upper part of the body to the sides of the vehicle, this will ensure maximum protection when the side airbags/side head impact protection airbags are deployed.*



*An inflating airbag can cause facial abrasions and other injuries if the occupant is too close to the airbag at the time of its deployment.*



*When airbags are deployed, children without proper protection may suffer from serious injury or even death. DO NOT carry children in the arms or on the knees during traveling. Children should wear seat belts suitable to age. DO NOT lean out of windows.*



*After deployment, the relevant components of the airbags will become very hot, such as the steering wheel, instrument panel and both sides of the roof rails. DO NOT touch airbag related components after airbag deployment, it may cause burns or serious injury.*

## SEATS AND RESTRAINTS

---



***DO NOT knock or strike the position where the related parts of the airbags are located, so as to avoid accidental airbag deployment which may cause serious injury or even death.***



***The inflation passage of the airbag must be free of any obstructions. Do not place any objects between passengers and airbags. It is prohibited to fix or place any objects on the steering wheel cover, or on/near the airbag cover in the front of the instrument panel. DO NOT place any accessories or decorations around the airbags. This may affect the airbag passage or create projectiles that may cause injury or serious harm in the event of airbag deployment.***

In the event of a collision, the airbag control unit monitors the rate of deceleration or acceleration induced by the collision, to determine whether the airbags should be deployed. Airbag deployment is virtually instantaneous and occurs with considerable force, accompanied by a loud noise.

Provided the front seat occupants are correctly seated and with seat belts properly worn, the airbags will provide additional protection to the chest and facial areas in the event of the car receiving a severe frontal impact. Side airbags and side head impact protection airbags are designed to offer additional protection to the side of the body facing the impact, if a severe side collision occurs.

When you sit upright in the seat and against the backrest, seat belts and airbags can provide the most effective protection. When encountering serious collision, airbags will deploy drastically. At this moment, if you or other passengers do not use seat belts properly, and lean forward, recline or sit in other incorrect postures, you or other passengers are likely to suffer from serious injury or fatal injury.

## IMPORTANT

- Airbags cannot protect lower body parts of passengers.
- Airbags are not designed for rear collision, minor frontal collision or vehicle overturn; nor will it operate as a result of heavy braking.
- Deployment and retraction of the airbags take place very quickly and will not protect against the secondary impacts that may occur.
- When an airbag inflates, a fine powder is released. This is not an indication of a malfunction. However, the powder may cause irritation to the skin and should be thoroughly flushed from the eyes and any cuts or abrasions of the skin. If skin, eyes, nose, throat, etc. does not feel good, please go to a doctor immediately.
- After inflation, the airbags deflate immediately. This ensures that the driver's vision is not obscured.

## Frontal Airbags



***NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur. Refer to 'Disabling the Passenger Airbag'.***



***Front seat passengers should not place feet, knees or any other part of the body in contact with, or in close proximity to a front airbag.***



***In extreme cases driving on very uneven surfaces may cause airbag deployment. Please take extra care when driving on uneven roads.***

Airbags are designed to deploy during serious impacts, the following conditions may cause airbag deployment.

- A frontal collision with unmovable or non deformable solid objects at a high speed.
- Conditions that can cause serious chassis damage, such as a collision with kerbstones, road edges, deep ravines or holes.

# SEATS AND RESTRAINTS

---

## Seat Side Airbags and Side Head Impact

### Protection Airbags



*The structure and material of the seat is critical to the correct operation of side airbags. Therefore, please DO NOT fit seat covers which may affect side airbag deployment.*

In the event of a serious side impact, the relevant side airbag will eject from the seat cover and deploy quickly, and the side head impact protection airbag will eject from the roof interior and deploy quickly. The side airbag and side head impact protection airbag at the other side will not deploy. The following or similar conditions may cause the seat side and side head impact protection airbags to deploy.

- One side of the vehicle collides with high-speed ordinary passenger car.

## Conditions in Which Airbags Will Not Deploy

The deployment of airbags does not depend on the vehicle speed, but on the object that the vehicle hits, angle of impact and the rate at which the car changes speed as a result of a collision. When the impact force of collision is absorbed or dispersed to vehicle body, airbags may not deploy; however, airbags may sometimes deploy according to impact condition. Therefore, the deployment of airbags shall not be judged based on the severity of vehicle damage.

## Frontal Airbags

Under certain conditions the front airbags may not be deployed. Some examples are listed below.

- The impact point is not central to the front of the vehicle.
- The impact is with a solid utility pole or traffic sign post.
- The impact area is high (collision with the tail gate of a higher chassis).
- Frontal collision at an angle with guard bars.
- Impacts to the rear or side of the vehicle.
- The vehicle rolling over.

### **Seat Side Airbags and Side Head Impact**

#### **Protection Airbags**

Under conditions described below or similar ones, side airbags and side head impact protection airbags may not be deployed.

- Side impacts at certain angles.
- Light side impacts such as a motorcycle.
- The impact point is far away from the center of the vehicle side, such as impact on the side of the front cabin compartment or loadspace.
- The vehicle rolling over.
- Frontal collision at an angle with guard bars.
- Insufficient side impact force (collision with non-solid objects, such as lamp post or central barrier).
- Insufficient impact force (Collision with parking or moving vehicles).
- The impact is from the rear of the vehicle.

# SEATS AND RESTRAINTS

---

## Service and Replacement of Airbags

### Service of SRS Components



***DO NOT install or modify the airbag. Any changes to the vehicle structure or airbag system wiring harness are strictly prohibited.***



***Changes to vehicle structure is prohibited. This may affect the normal operation of the SRS.***



***DO NOT allow these areas to be flooded with liquid and DO NOT use petrol, detergent, furniture cream or polishes.***



***If water contaminates or enters the SRS, it may cause damage and affect deployment. In this case, even if the collision does not occur, the airbag may deploy accidentally. Please shut down the engine and disconnect the battery cable immediately; do not try to start the vehicle. In this case contact an MG Authorised Repairer immediately.***

If the airbag warning lamp fails to illuminate, stays on, or if there is any damage to the front or side of the vehicle, or the airbag covers show signs of damage, contact an MG Authorised Repairer immediately.

#### IMPORTANT

- The removal or replacement of an airbag module should be carried out by an MG Authorised Repairer.
- After 10 years from the initial date of registration (or installation date of a replacement airbag), some components will need to be replaced by an MG Authorised Repairer.

### Replacement of SRS Components



*Even if the airbag does not deploy, collisions may cause damage to SRS in the vehicle. Airbags may not function properly after damage, and can not protect you and other passengers when a second collision occurs, which may cause serious injury or even death. To ensure that the SRS can function properly after a collision, please go to an MG Authorised Repairer to check airbags and replace them as necessary.*

Airbags are designed for using once only. Once the airbag is deployed, you must replace SRS parts. Please go to an MG Authorised Repairer for replacement.

### **Disposal of Airbags**

When your vehicle is sold, ensure that the new owner knows the vehicle is equipped with airbags, and is aware of the replacement date of SRS. If the vehicle is scrapped, the undeployed airbags may have potential risks, therefore, before the disposal, they must be deployed safely in a certain environment by a professional agency or an MG Authorised Repairer.

# SEATS AND RESTRAINTS

---

## Child Restraints

### Important Safety Instructions about Using Child Restraints

Children under the age of 12 years are recommended to be seated in the rear seats. Compared with adults, children's muscles and bones do not fully develop, so you need to use dedicated child restraints to protect children. Use child restraints in rear seats to protect children based on the child's age, height and weight.

Only child restraints that comply with relevant regulations or standards (such as EU regulations ECE-R44 and ECE-R129 ) are permitted to be used in this vehicle. When choosing a child restraint, check relevant marks or instructions about the weight range applicable for the child restraint and the usage message on it.

It is important to comply with installation instructions supplied by the child restraint manufacturer and that child restraint system is properly secured to the vehicle.

The correct use of child restraints will greatly reduce children's injury risk in accidents or relieve their injury

severity, and please pay attention to the followings when you use child restraints:

- All children must use an appropriate child restraint.
- It is recommended that children shorter than 1.5 metres (or under 12 years of age) should use the appropriate child restraint, and cannot use regular seat belt, otherwise it may cause the abdomen and neck injuries.
- Never let your children ride in unprotected case. Care should not be neglected because of children sitting on the child restraint.
- Only one child may be carried in any one restraint.
- **DO NOT** put the child on the lap or in arms when sitting in any seat.
- Proper child restraint can provide protection for your children.
- The backrest angle of the 2nd row seat is adjustable, so when you install the child restraint onto the second row seat, adjust the backrest angle to the appropriate position and lock it up.

## SEATS AND RESTRAINTS

---

- Relevant front seat may need to be adjusted frontward for installing the rear facing child restraint to the rear seats.
- The height of seat head restraints may also need to be adjusted for installing the forward facing child restraint to the rear seats.
- Never let your child stand or kneel on the seat during driving, otherwise, your child may be tossed and thus lead to injury to their own and other people or even death when an accident occurs.
- If a child's body leans forward or the posture is not correct during driving, then the accident will increase the risk of injury.
- The method of using seat belts have a great influence on the maximum protection offered by the seat belt, you must comply with the child restraint manufacturer's instructions on proper use of seat belts. If seat belts are not properly fastened, even a minor traffic accident may lead to injury.
- Child restraints that are not fitted correctly may move and injure other occupants in the event of an accident or emergency braking. Therefore, even if there is no

infant or child in the child restraint, it should be fitted properly and securely in the vehicle.

## SEATS AND RESTRAINTS

---

### Warnings and Instructions on Use of Child Restraint on Front Passenger Seat



**NEVER use a rearward facing child restraint on the front passenger seat with the front passenger airbag activated, otherwise DEATH or SERIOUS INJURY to the CHILD may occur.**



**Use one child restraint per child.**



**In cases where there is a need to install a rear facing child restraint on the front passenger seat, use the key to deactivate the front passenger airbag function, or severe injury or even death can occur.**



**Once the child restraint is removed from the front passenger seat, use the key to reactivate the front passenger airbag.**



**When installing a child restraint on the front passenger seat, move the front passenger seat as far rearward as possible.**

Please carefully read the safe driving warning label on the sun visor. Always install the child restraint in the rear seat for security reasons. And above warning shall be noted in a special case when the child restraint must be used on front passenger seat.

### Important Instructions on Children's Safety and Side Airbags



*Children should not be allowed in areas where side airbags may be deployed, there is a risk of serious injury.*



*Only recommended child restraints suitable for the age, height and weight of the child should be used and firmly fixed in the vehicle.*



*DO NOT place any items in areas where side airbags may be deployed, there is a risk of serious injury.*

In the event of a side collision, the side airbags can provide better protection for the passenger. However, when the airbag is triggered, a very strong expansion force is generated, if the passenger's seating position is not correct, the airbags or items in the side airbag deployment area may cause injury.

Therefore, the correct child restraint shall be used to secure the child properly in the rear seat and ensure the

child's seating position is correct and there is enough space between the child and the side airbag deployment area for the airbag to deploy without any hindrance in a traffic accident, and thus provide the best protection.

# SEATS AND RESTRAINTS

---

## Fixing Child Restraints

### Secured Using Lap and Shoulder Belts



*Please DO NOT put the rearward facing child restraint on the front passenger seat with the front passenger airbag activated, this may cause serious injury or even death.*



The child restraint can be secured to the rear seat by the lap and shoulder belts.

### Secured with ISOFIX Device



*The ISOFIX anchorages in the rear seat are designed for use with ISOFIX systems only.*



*Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses, or for attaching other items or equipment to the vehicle.*

The 2nd row seats of this vehicle on both sides are provided with ISOFIX interface (as indicated by the arrow in the figure below) connected to the ISOFIX child restraint. When installing and removing any child restraint system, always follow the manufacturer's instructions.

## SEATS AND RESTRAINTS



- Insert the tapered plastic sleeve into ISOFIX anchor between the seat cushion and backrest.
- Push the ISOFIX attachment of the child restraint into the tapered plastic sleeve already fitted, and snag it in the ISOFIX anchor.



- The Top-tether (as arrowed in the figure above) for auxiliary fixation of the child restraint is provided at the back of the rear seat backrest. To fasten the top tether of the child restraint system, route the tether under the rear headrest and attach to the anchorage hook.

## SEATS AND RESTRAINTS

---

**Note:**

***When using seat mounting, universally approved child restraint systems, the top tether must be used.***

***For dual tether child restraint, please route the top tether under both side of the rear seat headrest.***

***When fixing the top tether, be careful not to twist the top tether.***

***If not using ISOFIX lower anchorages, using the seatbelt, complete the installation in line with the child restraint manufactures instructions.***

- After the installation, push or shake the child restraint with moderate force to confirm it is properly secured.

## Child Restraint Groups and Installation Position

Only approved child restraints suitable for children are allowed. Children higher than 1.5 m may directly use the seat belts in the vehicle. Child restraints shall comply with relevant regulations or standards, such as EU regulations ECE-R44 and ECE-R129 .

### Applicability of Different Seating Positions to Child Restraint System

Mass Group	Seating Positions		
	Front Passenger	Second-row Outboard	Second-row Centre
Group 0 (less than 10 kg)	X	U	U
Group 0+ (less than 13 kg)	X	U	U
Group I ( 9 to 18 kg)	X	U <sup>1</sup>	U <sup>1</sup>
Group II ( 15 to 25 kg)	U <sup>1,2</sup>	U <sup>1</sup>	U <sup>1</sup>
Group III ( 22 to 36 kg)	U <sup>1,2</sup>	U <sup>1</sup>	U <sup>1</sup>

Note: Description of letters in the table: U = Suitable for universal child restraint systems approved for this mass group; X = Seat position not suitable for child restraint systems in this mass group.

<sup>1</sup> If the child restraint interferes with the headrest during the installation, please adjust the headrest to the highest position. If the interference persists, please remove and store the headrest properly;

## SEATS AND RESTRAINTS

<sup>2</sup> Adjust the passenger seat to the rearmost position.

### Approved Child Restraint Positions (for ISOFIX Child Restraints)

Seating Position		Mass Group					
		Group 0	Group 0+	Group I <sup>1</sup>		Group II <sup>1</sup>	Group III <sup>1</sup>
		Rear facing		Forward facing	Rear facing	Forward facing	Forward facing
		Up to 13 kg		9~18 kg		15~25 kg	22~36 kg
Front Passenger	Size Class	No ISOFIX Equipped					
	Seat Type						
ISOFIX on both sides of the second row	Size Class	C , D , E <sup>2</sup>	A , B , BI <sup>2</sup>	C , D <sup>2</sup>	-	-	
	Seat Type	IL	IL , IUF	IL	IL	IL	
2nd Row Middle Position	Size Class	No ISOFIX Equipped					
	Seat Type						

Note: IL = suitable for particular ISOFIX child restraints of the semi-universal category. Please refer to the vehicle list recommended by child restraints manufacturer;

## SEATS AND RESTRAINTS

---

IUF = suitable for forward-facing ISOFIX child restraints of universal category approved for use in this mass group and ISOFIX size class;

<sup>1</sup> If the child restraint interferes with the headrest during the installation, please adjust the headrest to the highest position. If the interference persists, please remove and store the headrest properly;

<sup>2</sup> The ISOFIX size class for both universal and semi-universal child restraints is defined by the capital letters A to G . These identification letters are displayed on the ISOFIX child restraints.

## SEATS AND RESTRAINTS

---

### I-Size Child Restraint Table

This table provides recommendations for the installation position of the child restraint and the suitability of the corresponding child's size.

Seat Type	Front Passenger Seat	Rear Outboard	Rear Centre
I-Size Child Restraint	X	I-U	X
Booster Child Restraint	X	I-B	X

Note: I-U means it is suitable for forward-facing I-Size child restraint;

I-B means it is suitable for the following: forward-facing Group II/III ISOFIX Booster child restraint, and forward-facing I-Size child restraint facing the child with height of 100-150 cm (about 39-59 inches);

X means it is not suitable for I-Size child restraint.

**Note:** *It is recommended that children at the age of 18 months should use Britax Safe n Sound Unity child restraint, children at the age of 3 use Britax Safe n Sound Graphene child restraint, and children at the age of 6 use Britax Safe n Sound Hi-Liner SG child restraint. Children at the age of 10 are recommended to use Britax Safe n Sound KidGuard child restraint.*

## SEATS AND RESTRAINTS

### Group 0/0+ Child Restraint



*Never place a rearward facing child restraint on the front passenger seat with the front passenger airbag activated.*



Child restraint that can be adjusted to lying position are the optimum selection for infants with a weight below 10 kg (usually corresponding to the infants younger than 9 months) or the infants with a weight below 13 kg (usually corresponding to the infants younger than 24 months).

### Group I Child Restraint



*Never place a rearward facing child restraint on the front passenger seat with the front passenger airbag activated.*



Rear or forward facing child restraints are most suitable for infants whose weight is 9 ~ 18 kg (normally for those older than 9 months and younger than 4 years old).

# SEATS AND RESTRAINTS

---

## Group II Child Restraint



*The diagonal section of the seat belt should pass across the shoulder and upper body, away from the neck. The lap section of the belt should pass across the hips, away from the abdomen.*



The combination of child restraint and lap and shoulder belt is most suitable for children whose weight is 15 ~ 25 kg (normally for those older than 3 years old and younger than 7 years old).

## Group III Child Restraint



*The diagonal section of the seat belt should pass across the shoulder and upper body, away from the neck. The lap section of the belt should pass across the hips, away from the abdomen.*



The combination of child booster seat and lap and shoulder belt is most suitable for children who are weighing 22 ~ 36 kg, and shorter than 1.5 m (usually corresponding to the children around 7 years or more than 7 years).

## **Starting and Driving**

---

- 150 Keys*
- 154 Child Proof Locks*
- 155 Alarm System*
- 162 Starting and Stopping the Power System*
- 164 Economical and Environmental Driving*
- 167 Charging and Discharging Requirements*
- 186 Pedestrian Alert Control System*
- 187 Electric Drive Transmission*
- 193 One-Pedal Function \**
- 194 Brake System*
- 204 Adaptive Cruise Control System*
- 213 Driving Assist System*
- 232 Parking Aid System*
- 235 Rear Driving Assistance System \**
- 243 Tyre Pressure Monitoring System (TPMS)*
- 244 Load Carrying*

# STARTING AND DRIVING

---

## Keys

### Overview



*Please keep the spare key in a safe place - not in the car!*



*It is recommended that spare keys are not kept on the same key ring, since this may cause interference and prevent correct key recognition and therefore prevent the correct operation of the vehicle power system.*



*The smart key contains delicate circuits and must be protected from impact, high temperature, humidity, direct sunlight and fluid corrosion.*



### WARNING

The keys of vehicle contains coin / button batteries. The battery is **HZARDOUS** and is to be kept away from children (whether the battery is new or used).



### WARNING

A lithium coin / button battery can cause **SEVERE** or **FATAL** injuries within 2 hours or less if it is swallowed or placed inside any part of the body.

### WARNING



**If you think batteries may have been swallowed or placed inside any part of the body, please seek medical rescue immediately.**

We provide two smart keys to you, and each one includes a backup mechanical key. It can be used to mechanically unlock the doors in an emergency, but it cannot be used to start the vehicle.

The smart keys provided to you have been programmed to the security system on your vehicle, any key that is not programmed to the car will not operate the keyless entry function or the vehicle immobiliser.

The smart key only works within a certain range. It's working range is sometimes influenced by the key battery condition, physical and geographical factors. For safety consideration, after you lock your vehicle by the smart key, please recheck if the vehicle is locked..

### Keys



- 1 Lock Button
- 2 Tailgate Button
- 3 Unlock Button
- 4 Smart Key
- 5 Mechanical Key

If your key is lost/stolen or broken, a replacement can be obtained from an MG Authorised Repairer. The lost/stolen key can be deactivated. If the lost key is found, an MG Authorised Repairer can reactivate it.

## STARTING AND DRIVING

**Note:** Any key made privately may not start the vehicle, and may affect the safety of your car. To obtain a suitable key replacement, it is recommended that you can consult an MG Authorised Repairer.

**Note:** The new key cannot be offered to you immediately because it requires programming to the vehicle by the MG Authorised Repairer.

**Note:** If your car is equipped with induction-type wireless charging function, always keep the key more than 20 cm away from the mobile phone which is being charged to prevent the key from the interference of wireless charging device.

**Note:** Avoid operating the smart key close to strong radio interference devices (such as notebook computers and other electronic products), the normal function of the key may be affected.

### Replacing the Smart Key Battery

Please replace the smart key battery if any of the following conditions occur:

- The locking/unlocking function range of the smart key is obviously reduced;
- "Key Battery Low, Please Replace" is shown on the integrated display



- 1 Press the button ( A ) on the smart key to eject the decorative sheet.
- 2 Remove the backup mechanical key ( B ) in the arrowed direction.
- 3 Using a suitable flat bladed tool, insert the tool into the side of the key ( C ), carefully prise off the battery cover and separate the upper and lower casings ( D ).

**Note:** Make sure that the polarity of battery is correct ('+' side facing down).

**Note:** *It is recommended to use a CR2032 battery.*

- 4 Remove the old battery from the slot.
- 5 Put the new battery in the slot, and make sure it is in full contact with the slot.
- 6 Refit the cover and press tightly, ensuring the gap around the cover is even.
- 7 Refit the mechanical key, and close the decorative trim.
- 8 Operate the vehicle power system to resynchronize the key with the vehicle.

### IMPORTANT

- Use of an incorrect or inappropriate battery may damage the smart key. The new replacement's rated voltage, sizes and specifications must be the same as the old one.
- Incorrect fitting of the battery may damage the key.
- Disposal of the used battery must be strictly in accordance with relevant environmental protection acts.

# STARTING AND DRIVING

---

## Child Proof Locks



**NEVER** leave children unsupervised in the car.



- Move the lever to the unlock position in the reverse direction of the arrow to disable the child proof lock. With the child proof lock locked, the rear door on the corresponding side cannot be opened from inside the car, but can be opened from outside the car.

### Steps for enabling or disabling the child proof locks are as follows:

- Open the rear door on the corresponding side, move the child proof lock lever to the lock position in the direction of the arrow to engage the child proof lock;

### Alarm System

Your car is fitted with an electronic anti-theft alarm and power immobilisation system. To ensure maximum safety and operation convenience, we strongly recommend you to carefully read this chapter to fully understand the activation and deactivation of anti-theft systems.

### Power Immobiliser

Power Immobilisation is designed to safeguard the vehicle from theft. The power immobilisation system can only be deactivated to start the car by using the matched key. Once a valid key is detected in the vehicle the immobilisation system will be deactivated automatically.

If the message centre displays "Smart Key Not Detected" or "Put Key Into Back-up Position" or the power immobiliser system warning lamp illuminates, please put the smart key at Alternative Starting position (refer to "Alternative Starting Procedure" in "Starting and Stopping the Power System" section), or try to use the spare key.

If the car can still not be started, please contact MG Authorised Repairer.

# STARTING AND DRIVING

---

## Anti-theft System

### Locking and Unlocking

When the vehicle is locked, the remove indicator lamps flash three times; when it is unlocked, the remove indicator lamps flash once.

### Operation of Door Lock System (Key)

#### Key Locking

- Using the remote key to lock: press the lock button on the remote key to lock the vehicle after closing the doors, bonnet and tailgate.
- Using the mechanical key to lock: partially operate the door release handle, using a suitable flat blade tool, insert the tool into the underside of the trim and carefully remove the door lock trim cover, insert the key into the driver door lock and turn clockwise to lock the car.

#### Key Unlocking

- Using the remote key to unlock: press the unlock button on the key to unlock the car.

- Using the mechanical key to unlock: partially operate the door release handle, using a suitable flat blade tool, insert the tool into the underside of the trim and carefully remove the driver door lock trim cover, insert the key into the driver door lock and turn counter clockwise to unlock the car.


#### Find My Car

After the vehicle has been left in a locked condition for a few minutes pressing the lock button again on the remote key will enable the Find My Car function. This function will identify the car by means of an audible and visual alert. Pressing the Lock button on the handset again will suspend this operation. Pressing the Unlock button will cancel this operation. Find My Car function can be set in the "Vehicle Settings" interface on the Infotainment system display.

**Note: When the complete vehicle is locked, press the UNLOCK button on the remote key\* and perform no other operations for a period of time, the vehicle will automatically lock.**

### Operation of Door Lock System (Keyless)

The keyless entry system can lock and unlock the doors or open the tailgate as long as the smart key is present as you approach the vehicle.



**Note:** Keep the distance between the smart key and the door handle within 1.5 m range in order to lock and unlock the doors in a keyless way.

### Keyless Locking

After the vehicle is stopped, all doors can be locked simply by pressing the button on the front door handle once (no need to press the lock button on the remote key) when closing the doors and leaving the vehicle, and then the vehicle will enter the anti-theft alarm state.

### Keyless Unlocking

Press the button on the front door handle once to unlock the vehicle, then pull the door handle to open the door.

**Note:** When the vehicle is locked, if you are within the smart key range and operate the door handle button, but carry out no further action, after 30 seconds the vehicle will automatically re-lock itself to remain secure.

#### IMPORTANT

After the door is locked by using the key, press the button on the door handle to unlock the vehicle. If the vehicle can not be unlocked or locked normally, please contact a local MG Authorised Repairer.

# STARTING AND DRIVING

---

## Mislock


If the driver's door is not fully closed when the smart key lock button is pressed, the vehicle horn will sound once, indicating a mislock. In this case, none of the doors will lock, the alarm system will not be armed.

If the driver's door is closed, the passenger door, bonnet or tailgate are not fully closed, the horn sounds once to indicate mislock when the car undergoes locking operation. However, the 'partial arming' attributes of the security system will enable as much of the system to be armed as possible (all fully closed doors, bonnet or tailgate apertures will be protected, but an open door will not!). The alarm indicator will flash. As soon as the open aperture is closed, the system will automatically revert to an armed state.

## Anti-theft Alarm Sound

If the anti-theft alarm has been triggered, the vehicle horn will sound continuously. Press the UNLOCK button on the remote key, the anti-theft alarm will be deactivated.

## Interior Lock and Unlock Switch



- 1 Unlock Switch
- 2 Lock Switch

When the body anti-theft system is not set, press the interior lock switch ( 2 as shown) after closing all doors to lock all doors; press the unlock switch ( 1 as shown) to unlock all doors.

**Note:** *If the vehicle anti-theft system is set, pressing the lock/unlock switch of interior locks will not lock/unlock doors but will trigger the alarm system.*

If the doors, bonnet and tailgate are closed, press the interior lock switch, the yellow indicator on the lock switch illuminates.

If any door other than the driver side, bonnet or tailgate is not fully closed, press the interior lock switch, the yellow indicator on the lock switch flashes.

### Interior Door Handles

When the anti-theft alarm system is not in operation, pull the interior door handle to unlock and open the door.

### Speed Lock

All the doors will be locked automatically when the vehicle speed exceeds 15 km/h.


### Manual Tailgate



*If the tailgate can not be closed or the weatherstrip between the body and tailgate is fractured, be sure to close all windows during driving, select the face distribution mode of the air conditioner, and set the blower to maximum speed, so as to decrease exhaust fumes entering the vehicle.*

## STARTING AND DRIVING

---



The manual tailgate can be opened using the following 2 methods:

- 1 When the vehicle is unlocked or the matched key appears within 1 m range around the tailgate, directly press the release switch (Figure A ) on the tailgate to open the tailgate.


- 2 Long press the tailgate open button on the key (Figure B ) for more than 2 seconds to unlock the tailgate. Then the tailgate can be lifted open.

### Emergency Tailgate Opening

Tailgate emergency open switch is located in the inner side of tailgate lock.

Fold down the rear seat to make sure the emergency open keyhole plug on the tailgate trim plate can be touched.

Remove the plug, and rotate the emergency open knob counterclockwise to open the tailgate from inside.



# STARTING AND DRIVING

---

## Starting and Stopping the Power System

### Starting the Power System

#### Starting Procedure

When you open the driver door and sit on the driver seat, the instrument panel and touch screen will be powered on. The door opening and closing status, battery level and other information will be displayed on the instrument panel.


- 1 Depress the brake pedal to enter the READY MODE ;
- 2 Select D gear, or shift into R gear to reverse.

**Note: If the steering wheel cannot be turned after the vehicle has entered "READY MODE", please exit the vehicle ensuring the drivers door is fully closed. Once out of the vehicle, please sit back in the drivers seat and place the vehicle in "READY MODE" as described in the "Starting Procedure Section"**

#### Alternative Starting Procedure

If the vehicle is located in an area where there are strong radio signals causing interference or the smart key battery

condition is low, please use the following steps to attempt to start the car:



- 1 Place the smart key in the position with the buttons facing upward - as shown in the illustration.
- 2 Place the shift lever in P gear, depress the brake pedal and start the power system.

If the vehicle power system cannot be changed after the car has left the area of strong radio interference or had

the smart key battery replaced please consult an MG Authorised Repairer.

### IMPORTANT

- If the vehicle fails to entry "READY MODE" for 3 consecutive times, please contact your MG Authorised Repairer.
- The vehicle is fitted with an anti-theft system. Any independently made key cannot start the vehicle.
- In the environment with a temperature of - 10 °C and below, the time required for starting a power system will increase. It is essential that all unnecessary electrical equipment is switched off.

### Switching the Power System OFF

Setting the power system to OFF:

- 1 After bringing the car to a halt, always maintain brake pedal application.
- 2 Using the electronic shift control knob select P this will automatically apply the parking brake - please check that the parking brake is applied gear;
- 3 After leaving the driver seat with the key, press the lock button on the remote key (Refer to "Keys" in this section) to power off.

**Note:** When you are sitting in the driver's seat, you can still power off the vehicle by clicking the  icon on the large screen and selecting "Safety - Power Off". If you depress the brake pedal, the vehicle will restart.

**Note:** Please observe the park brake warning light and message displayed in the instrument pack message centre confirming that the parking brake is applied before exiting the vehicle.

# STARTING AND DRIVING

---

## Economical and Environmental Driving

### Running-in

The brakes and tyres need time to 'bed-in' and adjust to the demands of everyday motoring. During the first 1500 km, please avoid heavy braking where possible.

### Environment Protection

Your vehicle has been designed with the latest technology in order to minimize the environmental impact of exhaust emissions.

## Economic Driving

The way in which you drive your car has a significant bearing on the life span of the car and battery.

### *Drive Smoothly*

Anticipating obstructions and slowing down well in advance, avoids the need for unnecessary acceleration and harsh braking. A smooth driving style not only improves battery/distance performance, but can reduce the amount of wear on the brakes and tyres.

### *Avoid Driving at Maximum Speed*

Power consumption and noise levels rise significantly at higher speeds.

### *Driving Foreseeingly*

Avoid roads with traffic congestion or traffic jams. Foresee road congestion as early as possible, keep enough distance from the car in front during driving, and slow down in time. Avoid lengthy and heavy brake pedal applications when they are not necessary, these will cause the brakes to overheat and cause premature brake wear.

## ***Use of Electrical Equipment***

Use of electrical equipment will reduce the power available from the battery. Whilst it is essential to maintain a comfortable interior environment, excessive use of system such as A/C will increase power consumption and reduce the vehicle range.

## **Driving in Special Environment**

### ***Driving in Rain or Snow***



***Emergency braking, accelerating and steering on slippery roads will reduce the vehicle's handling performance and grip.***

- When raining the windows may fog, reducing visibility (Use the Air-conditioning demist function).
- Grip will be reduced, so please drive carefully.
- Reduce speed when it rains. Avoid aquaplaning (the effect of a film of water between the tyres and the road) affecting steering and braking performance.

### ***Driving through Water***

Avoid driving through floods after heavy rain, which may lead to serious damage to the vehicle.

# STARTING AND DRIVING

---

## Check and Service

### *Check Tyre Pressures Regularly*

Under-inflated tyres increase the rolling resistance of the car which, in turn, increases power consumption. Over or under-inflated tyres wear out more rapidly and also have a detrimental effect on the car's handling characteristics.

### *Do not Carry Unnecessary Loads*

The additional weight of unnecessary loads wastes power, especially in stop/start conditions where the car is frequently required to set off from stationary.

### *Maintain Correct Four-Wheel Alignment*

Maintain the correct wheel alignment. Avoid collisions with the kerb and reduce speed on uneven road surfaces. Out of specification wheel alignment will not only lead to excessive tyre wear, but also increases the load and power consumption.

### Charging and Discharging Requirements



*Under normal circumstances it is strongly recommended that you use a slow charging method, avoid constant or regular use of rapid chargers.*



*Prior to using any charging equipment please inspect the sockets, plugs and cables for any damage. DO NOT use any equipment that shows signs of misuse or damage.*



*It is recommended that the charging cable be connected to the charging device before connecting to the vehicle and charging commences.*



*DO NOT attempt to switch the vehicle power system to READY during charging.*



*After charging completion, switch off the charger (where necessary), disconnect the cable from the vehicle, fit the waterproof blanking plugs, close the charging point door. If necessary you can then disconnect the cable from the charger (where applicable).*



*Whilst charging the car on rainy days, where possible, please avoid connecting the charger during torrential rain or storms. If excessive water is evident around the charging plugs please use a suitable cloth to dry the area as best possible before removing the waterproof blanking plugs and connecting the charging cables.*



*DO NOT touch the charging connector or charging plug when your hand is wet.*



*DO NOT stand in water or snow when connecting or disconnecting the charging cable.*

## STARTING AND DRIVING

---



**DO NOT** attempt to charge when the charging connector and plug are wet.



Always keep the charging connector and charging plug in clean and in a dry condition. Be sure to keep the charging cable in a condition where there is no water or moisture.



Only use the correct charger for charging the electric vehicle. Using any other charger or connector configuration may cause failure.



Take care not to drop the charging connector. This could result in damage.



**STOP** charging or discharging immediately if you find anything abnormal, such as sparks, burning or smoke.



Always hold the charging connector handle or plug when connecting or removing the charging cable, if you pull the cable itself (without using the handle), the internal wires may disconnect or get damaged. This may lead to electric shock or fire.



High voltage charging or discharging equipment can cause interference with electronic medical devices. When using medical electrical devices such as pacemakers, please consult your doctor about whether charging or discharging your electric vehicle will impact the operation of the device. In some instances, electromagnetic waves that are generated from the charger can seriously impact medical electric device operation.



**NEVER** use a high powered jet wash directly on the charger door or to clean around the charge point.

### Charging Your Vehicle at Home

If you want to use an emergency home charging kit, it is essential that you check with a qualified electrician that the infrastructure of your property will support the charging equipment. Please seek qualified advice that your current electrical supply and circuits will support the requirements of the charging equipment.

#### Installed Charging Points

Various companies will supply and install charging points to your property, MG insist that only qualified reputable suppliers and installers are used - failure to have the correct equipment installed by a qualified professional may result in overloaded circuits and fire.

#### Home Charging Guide

ONLY use certified approved equipment.

ONLY use qualified suppliers and installers.

When the battery is fully charged, disconnect the cable plug from the vehicle socket - if it is necessary to interrupt the charging of the vehicle, isolate the power supply first, then disconnect the vehicle plug.

NEVER allow water or fluids to enter or contaminate your charger or vehicle charging sockets.

NEVER use damaged charging points, equipment or sockets.

STOP charging immediately if you see anything unusual, smell something burning or see sparks.

ALWAYS follow the operating instructions supplied with your charging equipment.

**Note:** *The charging point and power supply infrastructure must be installed and serviced by suitable qualified personnel from an approved installation company using only the materials recommended by them.*

# STARTING AND DRIVING

---

## Charging and Medical Condition Awareness



***High voltage charging equipment can create areas of strong electromagnetic interference, this may cause operational issues with electronic medical devices.***

When using medical electrical devices such as pacemakers or cardioverter defibrillators (ICD's), please consult your doctor about whether charging or discharging your electric vehicle will have an impact on the operation of the device. In some instances, electromagnetic waves that are generated from the charger can seriously impact medical electric device operation.

***Note: There are no cautions issued about medical devices when the car is not charging or discharging. It is perfectly safe for individuals fitted with pacemakers or cardioverter defibrillators to drive or ride in the vehicle.***

## Charging Port

The charging port is located behind the charging port door located rear left of the vehicle. It is incorporated into the master locking system.

To open the door, ensure the vehicle is unlocked, press the charging port door and release - the door will open to reveal the waterproof plug cover.

Remove the plug cover to reveal the combined charging port.



- 1 Slow and Fast Charge Port - 7 Pin - Type 2 Plug
- 2 Rapid Charge Port - 7 Pin and 2 Pin - CCS Type Plug

**Note:** *In order to use the rapid charger socket, the lower waterproof plug cover will require removal.*

After charging, refit the waterproof plug cover (where necessary), close the charging port door, push the door fully home until the latch locates.

ALWAYS ensure that any excess water is removed from the port area before connecting any charging device.

### Charging Port Electronic Lock

In order to prevent the charging connector and cable being disconnected inadvertently during charging, the charging socket features an electronic locking mechanism.

The electronic lock is activated as soon as the vehicle begins charging, and remains in a locked state until the charging is finished or interrupted.

Whilst the charging cable is connected DO NOT attempt to remove the plug.


### Manually Releasing the Charging Port Lock in Emergency Situations

The vehicle features an emergency release device for the charging port lock.

To access the manual release, remove the trim plate covering the service access hole on left side of boot -see picture.


## STARTING AND DRIVING

---



Pull the release cable handle, remove the connector plug whilst maintaining tension on the cable this will release the locking device.


### Electric Charging Identifier Label Identifier Label on Slow Charging Kit



1 AC charging identifier label

**Note:** Users can purchase a slow charging kit from an MG Authorised Repairer.

### Identifier Labels on Charging Port



- 1 AC charging identifier label
- 2 DC charging identifier label

### Precautions for AC or DC charging

After opening the charging port door, check the charging identifier symbol on the plug cover. Check the charging connector identifier symbol on the AC or DC charger cable. After checking that the alphabetic characters of the charging identifier symbols match, proceed the next charging step.

**Note:** *Risk of failure, fire or injury etc. when using a charging connector with unmatched identifier symbols.*

# STARTING AND DRIVING

---

Electric charging identifier label symbol table

Supply Type	Configuration	Type of Accessory	Voltage range	Identifier
AC	7P	Vehicle connector and vehicle inlet	$\leq 480V$	
DC	7P+2P	Vehicle connector and vehicle inlet	50V–500V	

### Rapid Charging

**Note:** Please read any equipment operating instructions carefully prior to using the rapid charging station. Each type of charger may use different instructions.

**Note:** The cable of the charging plug should be shorter than 30 m.

If you have any doubts, please seek professional assistance.

### Rapid Charging Safety Precautions

Before connecting the rapid charger, switch the vehicle power system OFF and wait 10 seconds.

**Note:** If at any time during the charging process you should want to check the state of charge, please power on the vehicle. The high voltage battery state of charge will be displayed in the message centre in the instrument pack.

**Note:** Considering the safety and service life of the high voltage battery, when using a rapid charging station to charge the vehicle the battery will not become fully charged, and therefore the instrument pack may display less than 100% power. If you have a long journey planned, it is recommended that you use a slow charging point to charge the vehicle so as not to affect your journey.

### Slow Charging

**Note:** Carrying out a full slow charge is the only way for the high voltage battery to reach the optimal equilibrium state (equalisation charge).

High voltage battery chargers are available with various power outputs. Chargers with outputs of up to 11kW are generally considered as slow chargers, larger than 11kW are considered as fast chargers and rapid chargers are available in AC or DC outputs. Generally the AC chargers are rated at 43kW and the DC chargers at 50kW plus.

Charging times are dependent on charger output.

To carry out an equalisation slow charge, it is recommended that the charger output does not exceed 11kW.

**Note:** Chargers of up to 7kW power output are supplied via standard household single phase power. Any chargers that are rated above this, 11kW for example, will require a 3 phase power supply.

# STARTING AND DRIVING

---

## AC Charging Points

### IMPORTANT

Please ensure that only charge points that meet IEC 61851 and IEC 62196 are used to connect to your vehicle.

Using an AC charging device:

- 1 Ensure the vehicle is power OFF and all doors are closed.
- 2 Open the charging port door.
- 3 Plug the cable from the charger point into the vehicle. Lock the vehicle.
- 4 On completion of the charge, shut off the power, unlock the vehicle and disconnect the plug from the vehicle.
- 5 Ensure the charge socket is free from debris. Close the charging point door.

**Note:** *If at any time during the charging process you want to check the state of charge, please turn on the instrument pack.*

## Residential Charging

During the charging operation the vehicle power system must be OFF. Carry out the following procedure to charge the vehicle:

- 1 Ensure the vehicle is power OFF and all doors are closed.
- 2 Open the charging port door.
- 3 Connect the 7 pin charging plug to the socket on the vehicle.
- 4 Connect the charging device plug to the domestic electricity supply. Lock the vehicle.
- 5 On completion of the charge, shut off the power, unlock the vehicle, disconnect the plug from the vehicle, and then the domestic plug.
- 6 Ensure the charge socket is free from debris. Close the charging point door.

**Note:** *RCD Type B or RCD Type A (DC 6mA) may be used. The RCD MUST conform to IEC 62955 and be from an established manufacturer.*

*Note: If at any time during the charging process you should want to check the state of charge, please power off the vehicle. The high voltage battery state of charge will be displayed in the message centre in the instrument pack.*

# STARTING AND DRIVING

---

## Charging Information

At the beginning of the charging process, the following information will be displayed within the instrument pack message centre.



- 1 Battery pack status
- 2 Current time
- 3 Driving range
- 4 Remaining charging time
- 5 Charging status

**Note:** The information displayed on the instrument pack may be different based on vehicle configuration.

### Equalisation Charging

Equalisation charging means that after a normal charging process the battery management system will enter a mode where it will attempt to equalise the charge of every battery cell.

If an equalisation charge has not been carried out for sometime, the message centre in the instrument pack will display 'Please Slow-charge the Vehicle'. Please refer to 'Slow Charging' in the 'Starting and Driving' section.

On average it takes at least 12 hours (single phase power) or 9 hours (three phase power) to complete a charge that includes the equalisation charge for battery pack type 1.

On average it takes at least 10 hours (single phase power) to complete a charge that includes the equalisation charge for battery pack type 2.

On average it takes at least 14 hours (single phase power) or 10.5 hours (three phase power) to complete a charge that includes the equalisation charge for battery pack type 3.

**Note:** Ambient temperatures have an effect on charging times. It may take longer to complete a charge when the ambient temperatures are low.

# STARTING AND DRIVING

---

## Charging Times

Charging times of the high voltage battery can vary depending upon numerous factors, these include: current capacity, charging mode, ambient temperature and device type/power.

### Rapid Charging Time

Rapid chargers will vary in power output, on average it will take approximately 40 - 60 minutes to charge the high voltage battery up to 80% (80% displayed in IPK) using an average rapid charger.

**Note:** *Ambient temperatures have an effect on charging times. It may take longer to complete a charge when the ambient temperatures are low or high.*

### Slow Charging Time

On average it takes approximately 10.5 hours (single phase power) or 7.5 hours (three phase power) to charge the high voltage battery from low battery warning to 100% for battery pack type 1 (charge quantity can be checked using the instrument pack).

On average it takes approximately 8.5 hours (single phase power) to charge the high voltage battery from low battery warning to 100% for battery pack type 2 (charge quantity can be checked using the instrument pack).

On average it takes approximately 12.5 hours (single phase power) or 9 hours (three phase power) to charge the high voltage battery from low battery warning to 100% for battery pack type 3 (charge quantity can be checked using the instrument pack).

- At low temperatures the charging time will be extended.
- If an equalisation charge has not been conducted for along time the required charge time will be extended.
- An equalisation charge must be carried out prior to using the car after a long period of storage or non use. In these cases the charging time will be extended.

**Note:** *The slow charging notes above relate to using an AC charging device. Use of the slow charging device using a domestic power supply can increase the charging times by up to 3 times.*

## Indicative Charging Times for Battery Pack Type I

Rapid charging		From alarm status to 80%, it takes almost 45 minutes.		
Slow charging	Residential electricity	From alarm status to 100%, it takes almost 24.5 hours.	From alarm status to 100% and equalisation, it takes almost 26.5 hours.	For first use after parked or stored status to 100% and equalisation, it takes approximately 27.5 hours.
	AC charging station (single phase power, approx 7kW)	From alarm status to 100%, it takes almost 10.5 hours.	From alarm status to 100% and equalisation, it takes almost 12 hours.	For first use after parked or stored status to 100% and equalisation, it takes approximately 13.5 hours.
	AC charging station (three phase power, approx 11kW)	From alarm status to 100%, it takes almost 7.5 hours.	From alarm status to 100% and equalisation, it takes almost 9 hours.	For first use after parked or stored status to 100% and equalisation, it takes approximately 10.5 hours.

**Note:** *These times are only a guide.*

## STARTING AND DRIVING

---

### Indicative Charging Times for Battery Pack Type 2

Rapid charging		From alarm status to 80%, it takes almost 43 minutes.		
Slow charging	Residential electricity	From alarm status to 100%, it takes almost 19.5 hours.	From alarm status to 100% and equalisation, it takes almost 21.5 hours.	For first use after parked or stored status to 100% and equalisation, it takes approximately 22.5 hours.
	AC charging station (single phase power, approx 7kW)	From alarm status to 100%, it takes almost 8.5 hours.	From alarm status to 100% and equalisation, it takes almost 10 hours.	For first use after parked or stored status to 100% and equalisation, it takes approximately 11.5 hours.

**Note:** *These times are only a guide.*

## Indicative Charging Times for Battery Pack Type 3

Rapid charging		From alarm status to 80%, it takes almost 45 minutes.		
Slow charging	Residential electricity	From alarm status to 100%, it takes almost 29.5 hours.	From alarm status to 100% and equalisation, it takes almost 31.5 hours.	For first use after parked or stored status to 100% and equalisation, it takes approximately 32.5 hours.
	AC charging station (single phase power, approx 7kW)	From alarm status to 100%, it takes almost 12.5 hours.	From alarm status to 100% and equalisation, it takes almost 14 hours.	For first use after parked or stored status to 100% and equalisation, it takes approximately 15.5 hours.
	AC charging station (three phase power, approx 11kW)	From alarm status to 100%, it takes almost 9 hours.	From alarm status to 100% and equalisation, it takes almost 10.5 hours.	For first use after parked or stored status to 100% and equalisation, it takes approximately 12 hours.

**Note:** These times are only a guide.

**Note:** Alarm status refers to the high voltage battery low warning displayed in the instrument pack message centre. 100% refers to fully charged that the high voltage battery state of charge displayed in the instrument pack message centre.

# STARTING AND DRIVING

---

## Discharging

The vehicle is equipped with a discharge function, this can convert the high voltage DC power in the high-voltage battery pack into domestic AC power.

This discharge function can be realized by using a discharge kit.

**Note: Users have the opportunity to purchase the discharge kit from an MG Authorised Repairer.**

To use the discharge function, follow the instructions below:

- 1 Unlock the vehicle and access the AC charging port (the charging port is also the discharging port).
- 2 Insert the discharge gun connector into the discharge port socket. When fully connected the discharge port indicator will illuminate blue.
- 3 Access the energy management interface in the infotainment display screen, ensure the cut-off power of discharge is set. After setting, click the start discharging button, the electronic lock will lock the discharge gun in place and the vehicle will enter the discharge state. At this time, do not attempt to

remove the discharge gun using force, this will damage the locking mechanism.

- 4 The user is able to click the stop discharging button in the infotainment display screen to stop the discharge, or stop the discharge after the power is discharged to the set cut-off value. At this time the electronic lock will automatically be released and the discharge gun can be removed.
- 5 Make sure there is no debris or foreign matter in the charging port, fit the charging port cover and close the charging point door.

**Note: After the vehicle starts discharging, if the infotainment display goes off, the vehicle will still maintain the discharging condition.**

**Note: The current power status and available driving range can be displayed on the instrument cluster.**

**Note: During the discharge process, the user can still set the discharge power cut-off point.**

**Note: During discharge, the vehicle cannot be placed in "READY" mode.**

**Note: Using the discharge function will reduce the driving range of the vehicle.**

### IMPORTANT

- Before beginning the discharge operation, check the condition of the discharge connector and gun.
- If it is necessary to use the discharge function on wet days, please pay particular attention in protecting the discharge port area and discharge gun from water, rain or snow.
- In cases of abnormal phenomena such as peculiar smells, smoke emission or overheating etc during the discharge process, the electrical circuit **MUST** be disconnected immediately and the discharge operation stopped.

# STARTING AND DRIVING

---

## Pedestrian Alert Control System

In order to improve the safety, your car is fitted with a Pedestrian Alert System. When the vehicle is travelling at a low speed, the system controls a speaker that sounds to remind pedestrians in the vicinity of your presence.

### Strategies of sounding warnings

The speaker sounds when all of the following conditions are met:

- 1 The vehicle is READY;
- 2 The pedestrian alert system is fault free;
- 3 During acceleration, the vehicle speed is less than 30 km/h; during deceleration, the vehicle speed is less than or equal to 25 km/h.

## Electric Drive Transmission

### Instructions

The following information is very important; please read carefully before use:

- The electric drive transmission system is a high voltage unit; DO NOT touch it without authorisation.
- Depress the brake pedal, and when the vehicle power system is ready, turn the shift knob to the required position.
- Keep the brake pedal depressed until you are ready to manoeuvre the vehicle. On a flat road, once the brake pedal is released, the vehicle will automatically travel at a slow speed with the accelerator pedal not depressed.

## Gear Shift Control



The shift knob is in the middle steady-state position and has two non-steady state positions respectively if turned anti-clockwise or clockwise, that is, the shift knob will return to the middle steady-state position as soon as it is released.

**Note:** When shifting out of the P/N gear or into the R gear , it needs to depress the brake pedal.

## STARTING AND DRIVING

---

- P Park

In this position, the vehicle is locked, and the EPB is applied. Use this gear when the vehicle is stationary.

Press the P button, and the vehicle will shift into Park gear.

**Note: With the brake pedal released, the driver seat belt unfastened and the driver door open, the vehicle engages P gear automatically.**

**Note: If it is not in P gear, when the charging plug is inserted, it will be switched to P gear automatically.**

- R Reverse

Select this gear only when the vehicle is stationary and the driver has the intention to drive backwards.

Depress the brake pedal, turn the knob to the end anti-clockwise, and the vehicle will shift into Reverse gear.

- N Neutral

Select this gear when the vehicle is stationary when (for example, waiting for traffic lights).

With the vehicle in P gear, depress the brake pedal, turn the knob to the first non-steady state position

anti-clockwise or clockwise, and the vehicle will shift into Neutral gear.

With the vehicle in R gear, turn the knob to the first non-steady state position clockwise, and the vehicle will shift into Neutral gear.

With the vehicle in D gear, turn the knob to the first non-steady state position anti-clockwise, and the vehicle will shift into Neutral gear.

- D Drive

The Drive gear is used for normal driving.

With the vehicle in P/R/N gear, depress the brake pedal, turn the knob to the end clockwise, and the vehicle will shift into Drive gear.

## Driving Mode ( Mode )

The driver can select 5 driving modes through the Infotainment display: Snow Mode ( SNOW ), Economy Mode ( ECO ), Normal Mode ( NORMAL ), Sport Mode ( SPORT ), and Custom Mode ( CUSTOM ).

In different driving modes, the tuning of the power, steering, pedal force, air conditioning system and coasting energy regeneration varies.

### Snow Mode

In Snow Mode, initiate Level I coasting energy regeneration, which is suitable for driving on wet and slippery roads.

### Eco Mode

In Eco Mode, the vehicle is in low energy consumption state, which is used for energy saving driving.

### Normal Mode

In Normal Mode, the vehicle performance is balanced, which is used for daily driving.

## Sport Mode

In Sport mode, the control system allows the vehicle to provide more power to improve the driveability.

Keeping the vehicle in Sport Mode will increase energy consumption.

**Note: It is recommended to choose Sport Mode when driving on special road conditions such as mountain roads.**

## Custom Mode

In Custom Mode, the power, steering and pedal force modes can be matched freely.

# STARTING AND DRIVING

---

## Energy Regeneration



*Deceleration caused by energy regeneration is NOT a substitute for braking safely. The driver must ALWAYS be prepared to make braking manoeuvres to maintain safe driving.*

When the vehicle is in braking or coasting state, the energy regeneration function will be activated, and the motor will convert part of the kinetic energy of the vehicle into electric energy, which is then stored in the high voltage battery.

Energy cannot be regenerated in the following conditions:

- The vehicle is in N/R gear (Do not coasting in N gear while driving);
- During torque intervention (gear shifting, tyre skidding, etc.);
- High voltage battery is fully charged;
- High voltage battery temperature is too high or too low.

The driver can select 4 energy regeneration modes through the Infotainment display.

## Low mode ( Low )

In Low mode: less energy regenerated, longer coasting distance and no significant vehicle drag feel. Instrument Display ① .

## Medium mode ( Medium )

In Medium mode: moderate energy regenerated. Instrument Display ② .

## High mode ( High )

In High mode: more energy regenerated, shorter coasting distance and strong vehicle drag feel. Instrument Display ③ .

## Adaptive mode ( Adaptive )

In Adaptive mode: automatic adjustment of regeneration strength by the vehicle based on road conditions and distance from the vehicle ahead. Instrument Display ④ .

## Energy Saving Mode

When the high voltage battery is low on power, a message will appear on the infotainment display, prompting the driver to enable the energy saving mode. When the

energy saving mode is enabled, the vehicle will operate on the minimal energy consumption. The power of the air conditioner is limited. The energy regeneration level is automatically adjusted and fixed to "strong". When the energy saving mode is turned off, the energy regeneration returns to the former-selected level. The energy saving mode can be turned on and off on the infotainment display.

Energy saving mode cannot be enabled when the vehicle is in Snow Mode.

### Protection Mode



*When parking the vehicle, please ensure the vehicle is parked safely and that all traffic by-laws are observed.*

### Motor Overheating Protection of the Electric Drive Transmission System

The electric drive transmission may become very hot in a high-temperature environment with frequent starting, frequent rapid acceleration and deceleration, long-term continuous steep climbing, and overload of the electric drive transmission. In order to prevent damage to the motor, the system will perform an overheating protection function, the instrument interface prompts that the coolant of the electric drive transmission system is overheated. In this case, park your vehicle safely or, while keeping a lowload, continue to drive your vehicle at a constant speed to cool the motor. Only when the motor temperature has decreased, and the warning message disappears, can the vehicle be driven normally.

If the electric drive transmission has cooled down for a long time (about 20 minutes) and the warning message has

# STARTING AND DRIVING

---

not disappeared, please park the vehicle safely and seek an MG Authorised Repairer immediately. Otherwise it may seriously damage the electric drive transmission.

## IMPORTANT

When the motor of the electric drive transmission is under overheating protection, in order to avoid damage to the motor, the power of the vehicle will be limited (the message centre will display “Power Limited, Limiting Speed”, and warning indicator  will illuminate). After decelerating, the warnings will disappear when the motor temperature returns to normal.

## Electric Drive Transmission Failure

If a general failure is detected in the electric drive transmission system, the warning indicator  on the instrument interface will illuminate in yellow, please drive with caution. For severe functional malfunction, the warning indicator  will illuminate in red. Please park the vehicle safely and contact an MG Authorised Repairer for service as soon as possible.

## Gear Shift System Failure

In some cases, when a fault or severe failure is detected in the gear shift system, the message centre will display “EP”. For safety reasons, if the vehicle speed is below a preset speed, the power system will isolate the power transmission, and the vehicle will not be able to be driven, please seek an MG Authorised Repairer immediately.

### One-Pedal Function \*



***Do not use the One-Pedal function when the vehicle tends to slip.***



***Do not reduce the prediction of road conditions due to the convenient operation of the One-Pedal function. In an emergency, you still need to brake the brake pedal. Please always be prepared for braking to ensure driving safety.***

When the One-Pedal function is enabled, the driver can control the vehicle speed through the accelerator pedal; depress the accelerator pedal to accelerate; release the accelerator pedal to decelerate, then the vehicle can slow down until it stops.

***Note: Even if the One-Pedal function can achieve the parking effect, there will still be the risk of sliding in the case of large slope. Don't risk driving with the convenience of the One-Pedal function. Please always ensure effective parking.***

The driver can set the ON/OFF of the One-Pedal function through the entertainment display.

In some cases, the One-Pedal function will be limited or exit, such as:

- Seat belt unfastened or door ajar;
- Brake system failure;
- Power system failure;
- Snow mode ON;
- When the intelligent driving function is activated, the One-Pedal function is limited;

# STARTING AND DRIVING

---

## Brake System

### Overview

This series of models is equipped with an Integrated Braking System ( IBS ), which brakes the vehicle through dual circuits. Pay attention to the followings during use of the IBS :

- The IBS only functions with the power system in READY mode. NEVER allow the vehicle to freewheel with the power system turned off.
- If the power system is turned off while driving, you should firmly press the brake pedal, and stop the vehicle as quickly as traffic safely permits.
- If the IBS performance degrades due to a low battery or other reasons, you need to apply more force than usual to the brake pedal to brake effectively.
- If the braking efficiency decreases due to vehicle failure, please contact an MG Authorised Repairer for service as soon as possible.

IBS can provide 3 different braking response modes for the vehicle:

- Comfort: The braking response is slow and the pedal feel is soft.
- Normal: The braking response is moderate and the pedal feel is moderate.
- Sport: The braking response is quick and the pedal feel is sensitive.

You can switch the braking response mode by adjusting the driving mode of the vehicle, or customize the settings on the Infotainment display. If the brake pedal is pressed or the Stability Control System ( SCS ), Traction Control System ( TCS ) or Anti-lock Brake System ( ABS ) is triggered, the switching of braking response modes cannot be completed immediately.

IBS supports brake energy regeneration. When the brake pedal is pressed for braking, the IBS will determine the driver's demand for braking force. The drive motor will convert the vehicle's kinetic energy into electrical energy, which is stored in the high voltage battery when the vehicle is decelerating. This process can improve the range of the vehicle.

The brake system can be divided into service brake system and parking brake system. The service brake system

## STARTING AND DRIVING

consists of Electronic Brake Force Distribution System ( EBD ) and Electronic Brake Assistance System ( EBA ). EBD system can automatically distribute the braking force between the front and rear wheels, so that the vehicle can have good braking performance under different load conditions. The EBA system can increase the braking force applied on each wheel during emergency braking to assist the driver in quickly triggering ABS , thereby shortening the braking distance.

Driving through water or heavy rain may adversely affect braking efficiency. In this case, keep a safe distance from other vehicles and intermittently apply the brake pedal to keep the brake disc surface dry.

### Parking Brake System - Electronic Parking Brake ( EPB )



*When the EPB system cannot be turned off due to malfunction, do not move the vehicle with the rear wheels on the ground, otherwise damages may be caused.*



The EPB system can be turned on and off through the following 2 ways:

## STARTING AND DRIVING

- Manual operation: Pull up the EPB switch to turn on the EPB system after the vehicle is parked safely. When the vehicle is powered on, press the brake pedal and press the EPB switch to turn off the EPB system.
- Automatic operation: Shift into P gear to turn on the EPB system after the vehicle is parked safely. Park the vehicle safely on a flat road or a road with a small slope, start the power system, press the brake pedal, and shift into N, D or R gear from P gear to turn off the EPB system.

If the indicator in the EPB switch and the indicator in the instrument pack  illuminate, it indicates that the EPB system has been turned on. If the indicator in the EPB switch and the indicator in the instrument pack  goes off, it indicates that the EPB system has been turned off.

**Note:** Always turn on the EPB system every time you leave the vehicle.

**Note:** An audible motor noise may be heard when turning on or off the EPB system.

**Note:** On a steep slope, shifting from P gear to other gears will not turn off the EPB system. In this case, please turn off the EPB system manually, or use the Start Assist function of EPB .

### IMPORTANT

- DO NOT leave the vehicle before the indicator lamp in the EPB switch illuminates and the gear indicator displays P , the vehicle may not be safely parked due to EPB failure and slip.
- In the event of a flat battery or power failure, it is not possible to apply or release the EPB. In such a case, 'booster cables' shall be used for emergency vehicle start. Please refer to 'Emergency Starting' in 'Emergency Information' chapter.

## Start Assist

If the driver's seat belt is fastened, and the accelerator pedal is pressed for start off, the EPB system will be automatically turned off.

## Emergency Braking Function



*Inappropriate use of EPB can lead to accidents and injuries. DO NOT apply the EPB for vehicle braking during vehicle running, unless in an emergency.*



*During emergency braking using the EPB, DO NOT switch off the power system, this could result in serious injury.*

In the event of normal brake failure during driving, emergency braking using the EPB can be initiated by pulling and holding the EPB switch upward. An audible warning will sound during emergency braking. The braking process will be canceled by releasing the EPB switch.

## Service Brake System

### Anti-lock Brake System ( ABS )



*The effect of ABS to accelerate the vehicle stop may be limited when driving at high speed or on slippery roads (such as roads with a layer of water that prevents effective contact between the tyres and the road surface). In all cases, it remains the driver's responsibility to maintain safe distance with other vehicles.*



*DO NOT depress the brake pedal repeatedly at any time; this will interrupt the operation of ABS and may increase the braking distance.*

The ABS is mainly used to automatically adjust the braking force of each brake when braking to prevent the wheels from being locked, thus avoiding dangerous situations such as loss of direction or side slip during emergency braking.

This system enables the driver to maintain control over the steering in case of emergency braking, keeps the vehicle stable, and improves the safety factor.

## STARTING AND DRIVING

---

Under normal braking conditions, ABS will not be activated. However, if the braking force exceeds the adhesion between the tyres and the road surface, causing the wheels to lock, the ABS will automatically come into operation.

If emergency braking is required, the driver should apply full braking effort to trigger the ABS even when the road surface is slippery.

**Note:** *On loose gravel, loose soil or snowy roads, the braking distance of vehicles equipped with ABS system may be greater, even improved steering would be experienced.*

### IMPORTANT

Although ABS can greatly improve the driving safety, the true safety still depends on the standard driving behavior of the driver.

### Stability Control System ( SCS ) and Traction Control System ( TCS )

SCS is designed to assist the driver in control of driving direction. When SCS detects that the vehicle is not moving in the intended direction, it will intervene by applying brake force to selected wheels or through the power system management system to prevent sliding and assist in bringing the vehicle back to the right direction.

TCS contributes to maintain the control to the vehicle by improving the vehicle's traction trafficability and driving stability. TCS monitors the driving speed of each wheel individually. If spin is detected on one wheel, the system automatically brakes that wheel, transferring torque to the opposite, non-spinning wheel. If both wheels are spinning, the power system output torque will be reduced until traction is regained.

SCS and TCS are automatically switched on when the vehicle is powered on. And they can be switched off by using the switch located on the Infotainment display.

**Note:** *Disabling SCS and TCS will not affect the operation of ABS . Always disable SCS and TCS when driving with snow chains fitted.*

### Auto Hold



*The auto hold function cannot guarantee the stability of the vehicle when starting off or braking on hills especially on slippery or icy surfaces.*



*When auto hold stops the vehicle for reasons such as power system shutdown, releasing the seat belt or pressing the auto hold switch, the electronic parking brake is applied. It cannot be guaranteed that the vehicle will be stabilised in all cases. For example, the rear wheels are on a snowy or slippery road surface, or the vehicle incline is too great. Please make sure that the vehicle is safely stabilised prior to exiting.*



*The driver should pay full attention and observe the surroundings even if the vehicle is equipped with auto hold system.*



*Auto hold cannot guarantee the electronic parking brake operation in all cases where the power system is turned off. Please ensure the electronic parking brake is applied and the vehicle is stabilised prior to exiting the vehicle.*



*The auto hold function should be switched off during the use of a car washer for automatic car washing, otherwise the electronic parking brake may suddenly apply and cause vehicle damage.*

If the vehicle is required to stop frequently for long periods while driving (such as wait at the traffic lights, stop on a slope or stop and go with traffic), the Auto Hold function can assist you in stabilising the vehicle, enabling you to remove your foot from the brake pedal when the vehicle is stationary and the Auto Hold active.

Auto Hold has 3 states as follows:

I Standby:

With the driver's seat belt fastened, the driver's door closed and the power system in READY mode, touch

## STARTING AND DRIVING

---

the Auto Hold switch on the Infotainment display to switch the Auto Hold function from Off to Standby state.

### 2 Parking:

When the vehicle is moving forward, press the brake pedal to stop the vehicle, then firmly press the brake pedal to switch the Auto Hold function from Standby to Parking state.

**Note: If the vehicle is stopped by firmly pressing the brake pedal, the Auto Hold function will directly enter the parking state.**

The Auto Hold will exit the parking state if the brake pedal is firmly pressed again.

The Auto Hold will exit the parking state if gear D is selected and the accelerator pedal is pressed.

The Auto Hold will exit the parking state if gear R is selected.

### 3 OFF:

Touch the Auto Hold switch located on the Infotainment display to turn off the function.

The Auto Hold will exit the parking state under some circumstances such as releasing the seat belt, turning off the power system, remaining static for a length of time or operating the Auto Hold switch. At this time, the EPB will be applied.

**Note: The EPB will NOT be applied when operating the switch to turn the Auto Hold off with the brake pedal pressed.**

**Note: When the vehicle is in R gear, the Auto Hold function will not be triggered.**

### Hill Hold Control ( HHC )



*HHC has limitations when subject to adverse conditions such as wet or icy surfaces, and the driver must always pay attention to the vehicle conditions.*



*DO NOT exit the vehicle with only HHC applied, it may lead to a serious accident when HHC releases.*



*During hill start under a stop-and-go road condition, please step on the brake pedal deeply for several seconds before each start.*

HHC assists the driver by 'holding' the vehicle during hill starts. If the driver releases the brake pedal, the HHC will hold the vehicle stationary for a short time.

The following conditions must be fulfilled to activate HHC:

- The driver's door is closed and the driver seat belt is fastened.
- The vehicle is stopped steadily on a slope.
- SCS is fault free.

- EPB is fault free and released.
- Power system is in READY mode.
- D or R gear is selected.
- Sufficient brake pedal application force has been applied before start.

**Note:** *The HHC can also work when the vehicle is reversing uphill.*

# STARTING AND DRIVING

---

## Active Rollover Protection ( ARP )

The ARP system is a driver aid to assist the stability of the vehicle under extreme conditions. It is not a guarantee that the vehicle will not roll over.

When the vehicle is at risk of rollover during dynamic driving (such as lane change) or steady driving (such as loop driving), the ARP will automatically brake the outside wheels to cause the vehicle to understeer and prevent rollover.

**Note: With ARP in use, the vehicle under-steers and it is normal if it fails to steer fully according to the intent of the driver.**

## Emergency Braking Hazard Warning Lights Control System ( HAZ )

If the driver makes an emergency braking manoeuvre and certain conditions are met while driving, the brake lamp will automatically flash to alert the drivers behind.

**Note: With the hazard warning lamp turned on, the emergency brake strobe function will not operate.**

When the emergency braking manoeuvre is exited, the HAZ function will be switched off after a few seconds.

**Note: As the vehicle speed drops to below 10 km/h and the brake lamps no longer flash, the hazard warning lamps will illuminate automatically. Short press the hazard warning lamp button or increase your speed to above 20 km/h for more than 5 seconds to switch off the hazard warning lamps.**

## Multi-Collision Brake System ( MCB )

The MCB function will automatically apply the brake to reduce the vehicle speed and improve the vehicle stability after a collision. It is designed to reduce the risk of a secondary collision caused by the uncontrolled movement of the vehicle after a collision.

The MCB will be activated when the following conditions are all met at the same time:

- A vehicle collision where seat belts or airbags are deployed;
- The vehicle speed is less than 60 km/h;
- The steering wheel has not been turned in excess of 180 °;
- SCS is fault free.

If the driver firmly presses the accelerator pedal after a collision, the system will not be triggered.

If the driver firmly presses the accelerator pedal after the MCB function is triggered, the system will exit the braking state.

**Note:** *The MCB function cannot guarantee that the vehicle will slow down in all collision situations, as the collision may cause some parts to malfunction or fail, affecting the normal operation of the function.*

### **Electronic Differential System ( XDS ) \***

Your car is provided with electronic differential system ( XDS ). In case the understeering occurs when making a turn at high speed, the system will apply the brake to the wheels at inner side to improve the accuracy of steering.

# STARTING AND DRIVING

---

## Adaptive Cruise Control System



*The adaptive cruise control system is designed as a comfort system. It provides assistance to the driver, but DOES NOT replace any of the driver's responsibilities. When using the adaptive cruise control system, it is important that the driver maintains concentration at ALL times and is prepared to take action. Otherwise, accidents or personal injuries may occur.*

The adaptive cruise control system can automatically switch between constant speed cruise and car following cruise depending on whether it can detect a vehicle directly ahead. Constant speed cruise controls the vehicle within a certain speed range. Car following cruise operates by setting the distance between the vehicle and the vehicles directly ahead.

When activated if the adaptive cruise control system detects a vehicle in the same lane directly ahead it may

accelerate or gently apply the brakes of the car to maintain the set following distance.

**Note:** *The adaptive cruise control system is designed for highways and roads in good condition. It is recommended not to be used on urban roads and mountain roads.*

### Activation of Adaptive Cruise Control



*After following the vehicle ahead to a stop, the driver must ensure that there are no obstacles or other traffic participants, such as pedestrians, directly in front of the vehicle before starting off to follow the vehicle ahead again.*



*Whilst using the car following cruise function, it is strongly recommended that the driver does not touch the accelerator pedal. Any activation of the accelerator will not allow the adaptive cruise control system to automatically apply the brakes, and the vehicle is only controlled by the driver's manipulation of the accelerator pedal.*



**DO NOT** exit the vehicle when the adaptive cruise control system keeps the car stationary. Before exiting the car, the shift control knob should be in the P position or turn off the power system.



If the adaptive cruise control system keeps the car stationary, the driver still needs to pay full attention and be ready to apply the brakes manually. Note that if the system is disabled, turned off or cancelled, the vehicle will no longer stay still, it may move forward or slip backward.



When driving on a bend, the adaptive cruise control may actively reduce the vehicle speed to maintain vehicle stability and safety.



- 1 Adjustment Switch
- 2 Pilot Switch

The adaptive cruise control system can be set with the switch on the infotainment display and the switch on the left of the steering wheel.

- 1 If the switch on the infotainment display is OFF, the adaptive cruise control system is OFF.

## STARTING AND DRIVING

---

- When the switch on the infotainment display is ON, and the pilot switch ( 2 ) is pressed briefly, the adaptive cruise control system indicator on the instrument will turn green, and the adaptive cruise control system will be activated (the vehicle speed should be greater than 3 mph / 5 km/h for the first activation). Its target speed is the actual speed at activation (if the vehicle speed is below 20 mph / 30 km/h, the target speed of the system is set at 20 mph / 30 km/h). If the speed of the vehicle ahead is greater than the cruise target speed of your vehicle, your vehicle will maintain the target speed to conduct constant speed cruise. If the speed of the vehicle ahead is lower than the cruise target speed of your vehicle, it will enter the car-following cruise. An image of your car and the car ahead is displayed in the instrument pack message centre. In this mode the actual speed may be less than the set target speed. Whilst in the car following cruise mode, you can follow the vehicle ahead to a stop. If the parking time is less than a preset time period, your vehicle may automatically pull away to follow the vehicle ahead, or you need re-activate the adaptive cruise control system using the method displayed.

**Note:** *Manual deactivation of either the Stability Control System ( SCS ) or Traction Control System ( TCS ) will inhibit the operation of the adaptive cruise control system.*

### **Adaptive Cruise Target Following Distance Adjustment**

When the adaptive cruise control system is activated, press the adjustment switch to the right (increase spacing) or to the left (decrease spacing) to adjust the following distance, which is switched between 3 distance settings and displayed on the instrument.

Select the corresponding following distance according to the relative speed to the preceding vehicle, the higher the relative vehicle speed, the longer the distance is. Considering the traffic and weather conditions, the range of optional following distance may not be suitable for all drivers and driving conditions.

### **Adaptive Cruise Target Speed Adjustment**

When the adaptive cruise control system is activated:

- Use the accelerator pedal to reach the desired speed, press the adjustment switch ( 1 ), and then release the

adjustment switch and accelerator pedal, so that the vehicle will cruise at the desired speed.

- When the adjustment switch is moved upward and held, the target speed will increase until the required set speed appears on the instrument, and then release the switch. When it is determined that there is no vehicle ahead or the vehicle ahead exceeds the preselected following distance, the vehicle speed will increase to the set speed.
- When the adjustment switch is moved downward and held, the target speed will decrease until the required set speed appears on the instrument, and then release the switch, the vehicle speed will decrease to the set speed.
- When the target speed is adjusted by using the adjustment switch, it will change by 3 mph / 5 km/h each time the switch is moved briefly; When the switch is moved and held, the target speed will continue to rise or fall at 1 mph / 1 km/h until the switch is released.

**Note:** *If the vehicle ahead continuously makes hard acceleration or deceleration, the ACC system may not be able to keep the following distance accurately, the driver must pay attention and perform the operations such as braking or lane change in time according to the surrounding environment.*

### **Adaptive Cruise Pause/Standby**

When the adaptive cruise control system is active, short press the pilot switch to cancel the function, and the adaptive cruise control system will exit to the Standby state.

### **Automatic Deactivation of Adaptive Cruise**

In the following situations, the adaptive cruise control system may be automatically deactivated, this transfers full control of the vehicle to the driver.

- Turn off the adaptive cruise control system switch on the infotainment display.
- Press the brake pedal whilst the vehicle is in motion.
- Move the rotary gear knob to either R or N position.
- The driver unfastens his/her seat belt.
- Press and hold the accelerator pedal beyond a preset time period.

# STARTING AND DRIVING

---

- Open any door, bonnet or tailgate.
- Pull the EPB switch up to apply the parking brake.
- Follow the vehicle ahead to a stop and the stop time exceeds a certain period of time.
- The camera or radar view is blocked, the surrounding environment triggers the preset safe exit mechanism of the sensors, or the system fails.

**Note:** *If following the vehicle ahead to a stop with the adaptive cruise control system enabled, if any of the following conditions occur whilst the vehicle is in a stopped state, the EPB will automatically be applied:*

- *The driver unfastens the seat belt;*
- *The driver door is opened;*
- *The stationary time exceeds the preset time period.*

## **Adaptive Cruise Override**

If the driver has cause to use the accelerator pedal when the adaptive cruise control system is activated, the vehicle will remain in Cruise mode while the vehicle speed increases. When the accelerator pedal is released, the adaptive cruise control system will resume to operate at previously set cruise speed.

## **Adaptive Cruise Resume**

After the adaptive cruise control system is paused and not turned off, it can be reactivated by moving the switch upward. The target cruise speed will automatically be set to the target speed before exiting the adaptive cruise control system.

## **Clearing Target Speed Memory**

The adaptive cruise control system can be turned off by turning off the adaptive cruise control system switch on the infotainment display, and the speed set by the adaptive cruise control system in the memory will be cleared synchronously. The stored set speed will also be cleared by turning off the power system.

## **Adaptive Cruise Control System Impairment and Ineffectiveness**

- Encounters a vehicle or object which is stationary or traversing the lanes.
- Approaching the vehicle ahead too fast, and the system cannot apply sufficient braking force.
- The vehicle ahead is an oncoming vehicle, or makes an emergency braking manoeuvre.

- Vehicle ahead is reversing.
- A vehicle suddenly cuts into the lane in front.
- Encounters a vehicle driving at a low speed.
- Encounters a vehicle with loaded items protruding from the body profile of the vehicle.
- Encounters a vehicle with a higher chassis (e.g. a truck).
- Encounters pedestrians, non-motor vehicles or animals.
- The vehicle is driving on an uneven road or a complex traffic road section.
- The vehicle makes a sharp turn.
- Enters and leaves a tunnel or drives in the tunnel.
- Drives in the shade of mottled trees.
- Excessive weight being carried in the load space or cargo area causing the front of the car to point upwards.


### Special Driving Environments

The adaptive cruise control system has its limitations. Listed below are some conditions that may be beyond the safe operating limits. The driver should maintain control of the vehicle and must remain alert at all times. They should pay special attention to the traffic conditions and

surroundings, select the appropriate speed and be ready to take any required actions.


- 1 When turning at an intersection or following a vehicle into, or out of a curve, the adaptive cruise control system may be unable to detect the vehicle ahead, even if it is in the same lane, it is possible the system may detect a vehicle in another lane.

**Note:** *Do not use the adaptive cruise control system on entrance/exit ramps or sharp bends.*




## STARTING AND DRIVING


---




- 2 If the vehicle ahead changes lanes, but does not drive into the lane completely, the adaptive cruise control system may be unable to detect the vehicle. If the vehicle ahead changes lanes, but does not exit the lane completely, the adaptive cruise control system may determine that the vehicle ahead has exited the lane and accelerate to any preset speed.



- 3 When driving on uneven roads that may include steep climbs or dips please **DO NOT** use the adaptive cruise control system.



- 4 When driving behind a vehicle that is only partially overlapping your vehicle, 'A' in the graphic, the adaptive cruise control system may be unable to detect anything.



## STARTING AND DRIVING

---

**Note:** Please **DO NOT** use the adaptive cruise control system in the following situations:

- *Driving in bad weather conditions;*
- *When the ambient light is insufficient, the light is too bright, or the forward lighting of the vehicle is poor;*
- *Driving on rough or poor road surfaces;*
- *Driving through roadworks or construction sites;*
- *Driving on low friction roads (the rapid change of the tyre traction may result in the excessive wheel slip).*

**Note:** *The time threshold value and vehicle speed provided in the system function description are just for your reference.*

**Note:** *Some models are equipped with towing mode. When towing mode is active, the relevant driving assistance functions will be disabled (such as ACC, TJA, etc.), subject to the actual vehicle.*

## Driving Assist System

The driving assist system can detect the road and environmental information ahead of the vehicle by utilising a front view camera and a front detection radar under certain conditions. This information is used to relay warning messages or provide assistance to help the driver control the vehicle more safely and reliably. The front view camera is located in the interior rearview mirror base cover, the front detection radar is located at the lower middle of the front bumper.

**Note:** *DO NOT operate any infotainment switches whilst driving. If you wish to make any settings changes, please pull over when it is safe and legal to do so.*

**Note:** *The time threshold value and vehicle speed provided in the system function description are just for your reference.*

**Note:** *Some models are equipped with towing mode. When towing mode is active, the relevant driving assistance functions will be disabled (such as ACC, TJA, etc.), subject to the actual vehicle.*

## Description of Front View Camera

### Calibration of Front View Camera

The front view camera re-calibration is required after any of the following:

- Removal and refitting of the front view camera.
- Replacement of the windscreen.

**Note:** *The calibration of front view camera requires professional knowledge and tools. If calibration is required, please seek an MG Authorised Repairer.*

### Obstruction of the front view camera

On occasion the front view camera view may become obstructed by foreign objects or stains on the glass. In these cases a prompt message will appear in the information centre. Please wipe or clean immediately.

**In the following situations, the detection performance of front view camera will be affected:**

- Driving in poor weather conditions where visibility is reduced due to thick fog, heavy rain, snow, dust or sand storm etc.

## STARTING AND DRIVING

---

- Affected by light, for example low light levels at night, poor auxiliary lighting, excessive backlighting in the view, light from oncoming vehicles, abrupt change of brightness with a quick bright/dark jump (tunnel entrance/exit), driving on surfaces with strong reflective properties (road surface covered with water or snow), tunnels, inside a building etc.
- The front view camera is partially or fully blocked by obstacles, e.g. dust, foreign objects, oil pollution, mud, snow, excessive water (rain), frost or water spray from the road on the windscreen.
- The windscreen in view is damaged.
- Not calibrated after removing/refitting the front view camera or the windscreen.
- The front view camera is not secured in place.

### Description of Front Detection Radar

#### Calibration of Front Detection Radar

The front detection radar re-calibration is required after any of the following:

- The front detection radar mis-alignment failure, for example the position of the front detection radar has changed.
- Remove/refit the front detection radar or radar bracket.
- Remove/refit the front anti-collision beam.
- The four-wheel alignment parameters have changed.

**Note:** *If the front detection radar is subject to strong vibration or slight impact, the mounting position of the front detection radar needs to be checked and re-calibrated as necessary.*

**Note:** *The calibration of front detection radar requires professional knowledge and tools. If calibration is required, please seek an MG Authorised Repairer.*

**Front radar performance will be effected in the following situations:**

- When the front detection radar is covered by mud, snow, excessive water (rain) or water spray from the road.
- When the radar or surrounding areas are covered by objects such as labels or auxiliary lighting installation.
- When the front detection radar is subject to strong vibration or slight impact.
- Some targets may affect and weaken the detection capability of the front detection radar, such as road barriers, fences and tunnel entrances.
- When the front detection radar is affected by the environment, such as strong electromagnetic field interference or due to the target itself.
- Strong reflected radar signals (such as: in multi-storey car parks, tunnels, sprinkler spray systems or water jets etc). Experiencing any of these could cause the function of the front detection radar to be effected.

***Note: Any snow that gathers on the front radar may be removed using a soft brush, and any ice should be removed using a propriety deicing spray.***

***Note: Avoid any collision or contact with the front radar module, this may cause misalignment.***

# STARTING AND DRIVING

---

## Speed Sign Recognition



*The intelligent speed assist system is an auxiliary function. It may display an incorrect speed limit value or no speed limit value in the instrument pack due to various factors. As a result, the vehicle speed is not restricted within the correct range. The driver still needs to observe the speed limit of the road traffic, and speeding is strictly prohibited.*



*The front view camera cannot recognise speed limit signs painted on the road surface. The driver **MUST** observe these speed limits and adjust their speed accordingly.*

The setting interface of the speed sign recognition is located on the infotainment display, and the driver can choose to turn on or off the speed sign recognition system through the soft switch on the infotainment display. The vehicle detects the speed limit sign (such as ) at the roadside with the front view camera. When the vehicle speed exceeds the speed in the speed limit sign speed

indicator, the speed limit sign speed indicator will flash, and the driver is reminded to reduce the vehicle speed through the audible alarm and prompt message on the instrument pack.

When the speed sign recognition is enabled, the speed limit sign speed indicator will illuminate. When the vehicle passes the first identified speed limit sign, the speed limit sign speed indicator will display the real-time speed limit value. When encountering a speed limit sign with the same speed limit value, the speed limit value in the speed limit sign speed indicator will not be updated.

**Note:** *After the car identifies a speed limit sign, if no new signs (same or different) are identified beyond a certain mileage, the original speed limit value on the instrument pack will be reset and displayed as "--" . The driver **MUST** observe these speed limits and adjust their speed accordingly.*

**Note:** *When the vehicle needs to change lane, make a turn or turn around at an intersection and the driver uses an indicator in advance and slows down, the original speed limit value on the instrument pack will be reset until a new speed limit sign is detected. If the conditions are not met, the original speed limit value will be maintained and not be reset. The driver MUST observe the speed limits and adjust their speed accordingly.*

### **Speed sign recognition may not work properly in the following situations:**

- 1 The detection performance of the front view camera is affected.
- 2 The vehicle is being driven at high speed.
- 3 The speed limit signs are obscured along the road, for example: by trees, ice/frost, snow, dust, etc.
- 4 The speed limit signs are incorrectly placed or damaged.
- 5 There are multiple speed limit signs above the lane or on the sides of the road. Currently, the front view

camera can only recognise the speed limit signs for the lane in which the vehicle is being driven.

- 6 Non standard speed limit signs or signs that contain additional information.
- 7 The speed limit signs set up at a fork in the road, on a bend or on-ramp/off-ramp.
- 8 During manoeuvres such as lane-changing.
- 9 The vehicle is driven in non-sales area or the units selected on the infotainment display does not match with the current country.

## STARTING AND DRIVING

### IMPORTANT

- In poor lighting conditions or poor weather, or in case the speed limit signs are irregular or being sheltered, the camera may not identify all speed limit signs or make error identification (e.g. identify the weight limit sign as a speed limit sign, identify the minimum speed sign as the maximum speed sign etc.)
- The camera cannot recognize the text messages provided below the speed limit sign, such as Auxiliary Lane, 100 m Ahead, School Section, 7:00-10:00 . The camera will recognize the speed limit sign with text messages as a normal speed limit sign.
- Some drastic and rapid steering operations of the driver may be judged as changing lane or turning around in the intersection by the system, resulting in the identified speed limit signs being cleared.

### Speed Limit Assistance System



***Speed limit assistance system is only an auxiliary function. Due to that the speed limit sign is not standardized or the front view camera is blocked, the wrong speed limit value or no speed limit value may be displayed on the instrument pack, and the vehicle is not restricted in the correct speed range, so the driver still needs to be responsible for real-time evaluation of the speed limit on the road.***



***The front view camera cannot recognise speed limit signs painted on the road surface. The driver MUST observe these speed limits and adjust their speed accordingly.***

The setting interface of the speed limit assistance system is located on the infotainment display. Enter the vehicle setting interface and find the setting interface of the speed limit assistance system to select the mode: Intelligent, Manual or OFF.

- 1 Intelligent: Intelligent speed limit. The vehicle detects the speed limit sign (such as ) at the roadside with the front view camera, and intervenes the speed control to keep the vehicle speed in the permitted maximum speed limit.
- 2 Manual: Manual speed limit. The driver sets the maximum speed via the buttons on the left of the steering wheel, actively intervenes in the speed control, and keeps the speed within the allowable maximum speed limit, as described in the section "Manual Speed Limit Settings".
- 3 OFF: Turn off the speed limit assistance system.

**Note:** *If mode selection is disabled, please confirm that the intelligent driving is turned off on the infotainment display and try again.*

### Manual Speed Limit Settings

After switching to the manual speed limit, you can set the target speed limit via the buttons on the left of the steering wheel as follows:



- 1 When the manual speed limit is enabled, it enters the standby state, and the speed limit assistance system indicator on the instrument pack illuminates in white. The manual speed limit function can be activated by pressing the Pilot switch ( 2 as shown below), and the speed limit assistance system indicator illuminates in green. When the Pilot switch is pressed for the first time, if the actual vehicle speed is lower than 20 mph / 30 km/h, the target speed limit value displayed on the speed limit assistance system indicator will be 20 mph / 30 km/h; If the actual vehicle speed is higher than 20 mph / 30 km/h, the target speed limit value will be displayed as the multiple of 5 by rounding up the current vehicle speed to the nearest integer. After that, press the vehicle speed adjustment button ( 1 as shown below) up and down to adjust the target speed limit value of the manual speed limit. The target speed limit will increase or decrease by 5 mph for each press of the button. Hold the up or down button, and the target speed limit value changes continuously in units of 5 mph.

## STARTING AND DRIVING

---

- 2 After the manual speed limit is activated, the system will actively limit the vehicle to not exceed the target speed limit; when the actual vehicle speed exceeds the target speed limit set by the driver, the system will gradually reduce the vehicle speed below the target speed limit.
- 3 After the manual speed limit is activated, the driver can press the Pilot switch ( 2 as shown below) to allow the system to return to the Standby state. Press the Pilot switch ( 2 as shown below) again to resume the manual speed limit.



### National Speed Limit Sign Indicator\*



When the national speed limit sign is identified and the speed limit information function or intelligent speed assist function is enabled, the national speed limit indication illuminates. These two functions will work using 60mph as the national speed limit.

### Intelligent Speed Limit Settings



When the intelligent speed limit is enabled, the status indicator of the speed limit assistance system will illuminate in green. When the vehicle passes the first identified speed limit sign, the speed limit sign speed indicator will display the real-time speed limit value. When encountering a speed limit sign with the same speed limit value, the speed limit value in the speed limit sign speed indicator will not be updated.

**Note:** *After the car identifies a speed limit sign, if no new signs (same or different) are identified beyond a certain mileage, the original speed limit value on the instrument pack will be reset and displayed as "--". The driver MUST observe these speed limits and adjust the their speed accordingly.*

**Note:** *When the vehicle needs to change lane, make a turn or turn around at an intersection and the driver uses an indicator in advance and slows down, the original speed limit value on the instrument pack will be reset until a new speed limit sign is detected. If the conditions are not met, the original speed limit value will be maintained and not be reset. The driver MUST observe the speed limits and adjust their speed accordingly.*

The driver can temporarily exit the speed limit assistance system via the following operations:

- 1 Depress the accelerator pedal hard to exceed the speed limit temporarily; at this time the speed limit assistance system indicator on the instrument pack illuminates in green and flashes (at manual speed limit mode) or the speed limit sign on the instrument pack flashes (at intelligent speed limit mode);
- 2 Briefly pressing the Pilot switch ( 2 as shown above) can temporarily exit the speed limit assistance system function. In this case, the speed limit assistance system indicator in the instrument pack will change into white. Short press the Pilot switch again to resume the speed limit assistance system function.

# STARTING AND DRIVING

---

## Intelligent speed limit may not work properly in the following situations:

- 1 The detection performance of the front view camera is affected.
- 2 The vehicle is being driven at high speed.
- 3 The speed limit sign is blocked by trees, frost, snow, dust, etc.
- 4 The speed limit signs are incorrectly placed or damaged.
- 5 There are multiple speed limit signs above or on the side of the road. Currently, the front view camera can only recognize the speed limit sign of the current lane.
- 6 Non standard speed limit signs or signs that contain additional information.
- 7 The speed limit signs set up at a fork in the road, on a bend or on-ramp/off-ramp.
- 8 During manoeuvres such as lane-changing.
- 9 The vehicle is driven in non-sales area or the units selected on the infotainment display does not match with the current country.

### IMPORTANT

- In poor lighting conditions or poor weather, or in case the speed limit signs are irregular or being sheltered, the camera may not identify all speed limit signs or make error identification (e.g, identify the weight limit sign as a speed limit sign, identify the minimum speed sign as the maximum speed sign etc.)
- The camera cannot recognize the text messages provided below the speed limit sign, such as Auxiliary Lane, 100 m Ahead, School Section, 7:00-10:00 . The camera will recognize the speed limit sign with text messages as a normal speed limit sign.
- Some drastic and rapid steering operations of the driver may be judged as changing lane or turning around in the intersection by the system, resulting in the identified speed limit signs being cleared.

## Lane Assist System



*The lane assist system is an auxiliary system that provides assistance to the driver. It does NOT remove the responsibility of safe driving from the driver. When choosing to use the lane assist system, the driver MUST always pay attention to the surroundings, hold the steering wheel and be prepared to correct or take over the steering wheel control. Failure to maintain overall control of the vehicle may result in an accident or personal injury.*



*The lane assist system does not always recognise the lane lines or curbs. Sometimes poor road surfaces, certain road structures or objects may be mistaken for lane lines or curbs. When such situations occur, the lane assist system must be immediately turned off.*

The lane assist system switch is located in the infotainment display. Enter the corresponding interface for driving

assistance to turn the system ON/OFF, and make mode selection.

### Alert

The system uses the front view camera to detect the lane lines ahead of the vehicle. The system will be activated when the following detection conditions are met:

- The function is switched ON.
- Vehicle speed is above 37 mph / 60 km/h.
- Lane line markings are clear and the system recognises at least one lane line.

When a wheel is about to cross the lane line, or has already crossed the line, the system will provide warnings to prompt the driver to take action and maintain the vehicle position between the lane lines. The function will automatically exit when the vehicle speed drops below 34 mph / 55 km/h.

### Lane Departure Assist

The system uses the front view camera to detect the lane lines ahead of the vehicle. The system will be activated when the following detection conditions are met:

## STARTING AND DRIVING

---

- The function is switched ON.
- Vehicle speed is above 37 mph / 60 km/h.
- Lane line markings are clear and the system recognises at least one lane line.

When a wheel is about to cross the lane line, or has already crossed the line, the system will provide assistance to the driver by keeping the vehicle in between the lane lines by applying corrective steering intervention and simultaneously displaying a prompt. The function will automatically exit when the vehicle speed drops below 34 mph / 55 km/h.

### Emergency Lane Keeping\*

The system uses the front view camera to detect lane lines, kerb and adjacent lanes of oncoming traffic ahead. The system will be activated when the following detection conditions are met:

- The function is switched ON.
- Vehicle speed is above 37 mph / 60 km/h.
- Lane line markings are clear and the system recognises at least one lane line.

When a wheel is about to cross the lane line or kerb, or the vehicle is approaching oncoming traffic in the adjacent lane, and there is a collision trend, the system will provide assistance to the driver by keeping the vehicle in between the lane lines or kerbs, or avoiding sharply by applying corrective steering intervention and simultaneously displaying a prompt. The function will automatically exit when the vehicle speed drops below 34 mph / 55 km/h.

In cases of several interventions within a certain period of time and in the absence of detecting any steering input by the driver during the interventions, the system will provide warnings.

IMPORTANT
<ul style="list-style-type: none"><li>• In cases where the number of lanes increase or lanes merge, the driver <b>MUST</b> take full control of the vehicle.</li><li>• In areas where there are complex traffic conditions such as intersections or road junctions with congestion, the driver <b>MUST</b> take full control of the vehicle.</li></ul>

**The lane assist system will be impaired or ineffective in the following conditions:**

- The driver indicates in the direction of the lane line about to be crossed.
- The hazard lamps are activated.
- The driver applies the accelerator rapidly, carries out an emergency manoeuvre or makes a hard brake pedal application.
- The system detects that the driver has not moved the steering wheel for a preset time period (in the mode of lane departure assist and emergency lane keeping).
- During system intervention the steering wheel is operated (in the mode of lane departure assist and emergency lane keeping).
- The lane line is too thin, damaged, or fuzzy.
- Irregular or damaged kerbs.
- The vehicle is driven on the bend with a small curvature radius, the road is too narrow or too wide.
- The vehicle has just entered a road section with lane lines or is driven on a road section without lane lines.
- The vehicle changes lanes or sways laterally too fast.

- The vehicle is not in D.
- The vehicle speed is below 34 mph / 55 km/h, or too high.
- The anti-lock brake system (ABS) and the dynamic stability control system (SCS) are activated.
- Faults exist in the anti-lock brake system (ABS), dynamic stability control system (SCS), electric power steering system (EPS), etc.

It is recommended to turn off the lane assist system in the following situations:

- Driving in a sports style or manner.
- Driving in bad weather conditions.
- Driving on rough or poor road surfaces.
- Driving through roadworks or construction sites.

# STARTING AND DRIVING

---

## Traffic Jam Assist System



*The traffic jam assist system is an auxiliary system that provides assistance to the driver. It does NOT remove the responsibility of safe driving from the driver. When choosing to use the traffic jam assist system, due to the limitations of system detection and control, the driver must always be careful and hold the steering wheel at all times. The driver needs to correct or take over the steering wheel control if necessary. Failure to maintain overall control of the vehicle may result in an accident or personal injury.*



- Adjustment Switch ( 1 )
- Pilot Switch ( 2 )

The system switch is located on the infotainment display, and it can be turned on/off by entering the corresponding interface of driving assistance.

When the following conditions are met:

- The traffic jam assist system switch on the infotainment display is on.

- The system detects lane lines on both sides of the vehicle.
- The vehicle is in Drive gear.

Short press the pilot switch to activate the traffic jam assist system. The traffic jam assist system works on the basis of the adaptive cruise control system. If the lane lines ahead on both sides are clear, the system will assist the vehicle in driving within the lane lines. When driving at a low speed, if there is a vehicle ahead and the lane lines are not clear, the system can assist the vehicle in following the track of the vehicle ahead.

**Note:** *With the ACC system activated, the traffic jam assist system can be activated without pressing the Pilot switch when the above conditions are met.*

In the absence of a steering input from the driver for a certain period of time, the system will provide warnings.

**Note:** *The driver should adjust the vehicle speed and the following distance according to the road visibility, weather and road conditions. The traffic jam assist (TJA) system does not respond to pedestrians, animals, stationary vehicles and vehicles that drive across the lane or oncoming vehicles in the same lane. If the traffic jam assist system cannot reduce the vehicle speed timely and effectively, the driver MUST apply the brakes. In congested conditions, should another vehicle cuts into the lane being used by the vehicle under traffic jam assist system control, the system may not detect the vehicle in adequate time to make a braking manoeuvre. In this case the brakes should be applied by the driver.*

The traffic jam assist system will be impaired or ineffective in the following conditions:

- The hazard lamps are activated.
- The driver indicates in the direction of the lane line about to be crossed.
- The driver applies the accelerator rapidly, carries out an emergency manoeuvre or makes a hard brake pedal application.

## STARTING AND DRIVING

---

- The system detects that the driver has not moved the steering wheel for a preset time period.
- During system intervention, the steering wheel is being manipulated by the driver.
- The lane line is too thin, damaged, or fuzzy.
- The vehicle is being driven on a bend with a small curvature radius, the road is too narrow or too wide.
- The vehicle has just entered a road section with lane lines or is being driven on a road section without lane lines.
- The vehicle is not in D.
- The vehicle changes lanes or sways laterally too fast.
- The turning radius of the car using the traffic jam assist system to track in front is too small.
- The anti-lock brake system (ABS) and the dynamic stability control system (SCS) are activated.
- Faults exist in the anti-lock brake system (ABS), dynamic stability control system (SCS), electric power steering system (EPS), etc.

It is recommended to turn off the traffic jam assist system in the following situations:

- Driving in a sports style or manner.

- Driving in bad weather conditions.
- Driving on rough or poor road surfaces.
- Driving through roadworks or construction sites.
- Driving on steep, winding or slippery roads (such as snow covered and icy roads, wet roads and roads covered with water).
- Driving on grass tracks or unpaved roads.

### IMPORTANT

- In cases where the number of lanes increase or lanes merge the driver **MUST** take full control of the vehicle.
- In areas where there are complex traffic conditions such as intersections or road junctions with congestion, the driver **MUST** take full control.
- The driver **MUST** be aware of the surroundings and be able to assume full control of the vehicle when using the traffic jam assist system to track the car in front should the need arise.

### Front Collision Assist



*The driver remains responsible for the safety of the entire driving process, even if the vehicle is equipped with a front collision assist. The driver **MUST** pay full attention and drive carefully. As with all the driver assist systems, the front collision assist cannot prevent accidents or avoid collisions in all situations. The driver **MUST** always remain in control to avoid accidents or emergency situations.*



*Emergency braking whilst under the control of the front collision assist may cause injuries to the passengers. Therefore, drive carefully and all passengers **MUST** wear seat belts at all times.*



*Ensure the front collision assist or vehicle power system is switched off when being towed. If the front collision assist is enabled when the vehicle is being towed, adverse effects may affect the safety of your vehicle, the towing vehicle and the people around.*



*To avoid the occurrence of accidents, never specially test the functions of the front collision assist.*

The front collision assist switch is located in the infotainment display. Enter the corresponding interface for driving assistance to turn the system ON/OFF, and make mode selection.

### Alert

When the system detects that there is a risk of collision between the vehicle and the vehicle in front in the same lane, warnings will be provided to prompt the driver to slow down in time and keep a relatively safe distance from the vehicle ahead.

# STARTING AND DRIVING

---

## Emergency braking

When the system detects that there is a risk of collision between the vehicle and the vehicle directly in front of the vehicle, the brake system will automatically intervene to decelerate the vehicle, so as to avoid collision accidents or mitigate damage from collision accidents. If the vehicle is braked and stopped under the system control, it will remain stationary for a short time. Full control of the vehicle will then be returned to the driver.

## The system will only slow down the vehicle automatically if the following conditions are met:

- The dynamic stability control system (SCS) and traction control system (TCS) are fault-free and ON.
- The vehicle is in D or N.
- The airbags are not deployed.

**Note:** *In some cases, the driver may not have anticipated any braking intervention and does not want to apply the brakes whilst the front collision assist is braking heavily, the driver can temporarily cancel this operation by heavily pressing the accelerator pedal after ensuring that it is safe to do so.*

## The operation of the front collision assist may be impaired or ineffective in the following situations:

- The vehicle ahead approaches head-on, crosses the intersection or jumps the queue rapidly in a short distance.
- The vehicle ahead does not follow the rules of driving and parking (such as drives on the lane lines).
- The vehicle ahead is not in the same lane as your vehicle or the vehicle ahead is partially obscured.
- The vehicle ahead is an abnormal vehicle (modified or abnormal shape).
- The vehicle ahead is a vehicle with higher chassis.
- The vehicle ahead is a large vehicle at close range (such as tractor, trailer, towing vehicle, mud truck, sanitation truck, sprinkler truck etc.).
- The vehicle ahead is unusual transportation (such as a horse, cart, carriages etc.).
- The system detects the side of a vehicle.

- The contour of the vehicle ahead is unclear (such as water being sprayed by the wheels of the front and surrounding vehicles).
- The vehicle ahead does not have or has obscured tail lamps when driving at night or in a tunnel.
- The tail lamps of the vehicle ahead are all LED strip lights or other homemade coloured lamps.
- The street lights are inconsistent or flickering when driving at night.
- The pedestrian is not directly in front of the vehicle, or the pedestrian is not fully visible.
- The pedestrian is not standing upright, or it is a child under a certain height.
- There is a group of pedestrians in front of the vehicle that is over-shadowed or in the dark.
- There are animals in front of the vehicle.
- Objects such as special-shaped ground obstacles (e.g. roadblocks, isolation piles, isolation strips, large stones, other scattered objects etc.) are detected in front of the vehicle.
- Objects such as signs, guardrails, bridges, buildings or other are detected in front of the vehicle.
- The vehicle is being driven on a hillside road, upper and lower bridge section or tight bend.
- The vehicle is in R.
- The vehicle is in a state of braking or rapid acceleration.

# STARTING AND DRIVING

---

## Parking Aid System

### Ultrasonic Sensor Parking Aid



*The purpose of the parking aid is only to assist the driver in parking! The ultrasonic sensors may not be able to detect certain types of obstructions, e.g. narrow posts or small objects no more than a few inches wide, small objects close to the ground, objects above the tailgate and some objects with non-reflective surfaces.*



*Keep the ultrasonic sensors free of dirt, ice and snow. If deposits build up on the surface of an ultrasonic sensor, its performance may be impaired. When washing the car, avoid aiming high pressure water jets directly at the ultrasonic sensors from close range.*

### Rear Parking Aid

The ultrasonic sensors on the rear bumper monitor the area behind the vehicle to search for obstacles. If an

obstruction is detected, the system calculates its distance from the rear of the car and communicates this information to the driver by an alarm sound.

### Open Parking Aid

The parking aid is enabled automatically when the R gear is selected.

A short beep is given by the parking aid after selecting R gear to indicate that the system is operating normally. If an obstacle is detected, the audible sounds in different frequencies are transmitted (there might be blind zones). The closer the vehicle is to the obstacle, the faster the frequency of the alarm sound.

**Note:** *If a longer, higher pitched sound is emitted for 3 seconds when the R gear is selected, this indicates a fault in the system. In this case seek assistance from your MG Authorised Repairer.*

### Close Parking Aid

When shifting to P gear or the vehicle speed exceeds a certain value, the vehicle will automatically turn off the parking aid system.

### Parking Camera\*



*The purpose of the parking camera system is to assist the driver during reversing! The camera has limited field of view and cannot detect obstructions outside the field of view.*

Some models have a rear parking camera fitted between the rear license plate lamps. When reverse gear is selected, the camera will display an image of what is immediately behind the car. This image will be shown on the infotainment system display.

### 360 Around View System\*



*The purpose of the 360 around view system is to assist the driver during parking! The cameras have a limited field of view and cannot detect obstructions outside the field of view.*



*Although the infotainment display can provide images around the vehicle, please still pay attention to the current actual road conditions for your driving safety.*



*Please ensure that the exterior rearview mirrors are unfolded when using the 360 around view syste.*

With the 360 around view system activated, the infotainment display will display the 360 degree panoramic image of the vehicle to facilitate the observation of the surrounding environment in order to assist with safer driving. Buttons on the infotainment display can be touched to view the images from different angles around the vehicle.

The 360 around view system can be enabled using the following methods:

- Selecting Reverse gear.
- Operating the 360 button.
- Using the 'Setting' interface to select low speed switching of corner lights/indicators, this will automatically open the 360 around view system when the indicators are used at low speeds and exit when the indicators are cancelled.

In the 360 around view system display interface, select the settings icon to enable personal settings for system functions.

## STARTING AND DRIVING

---

*Note: When the shift lever is placed in a forward gear position, the 360 around view systems is inhibited at speeds above or equal to 10 mph(15 km/h)*

*Note: The time threshold value and vehicle speed provided in the system function description are just for your reference.*

*Note: Some models are equipped with towing mode. When towing mode is active, the parking aid system and rear driving assistance system will be disabled, subject to the actual vehicle.*

### Rear Driving Assistance System \*

#### System Overview



*The rear driving assistance function is only an aid, it is NOT a substitute for the attention of the driver. The driver must always remain in control, observe the surroundings and drive safely.*



*The effective recognition capabilities of the rear sensors can be limited by objects such as roadside buildings, guardrails, changes in pitch angle of the car due to heavy loading, road conditions such as bends or bumps or weather conditions such as snow and ice etc. Any of the above may trigger a false alarm.*



*The rear driving assistance system may not provide adequate warning of very fast approaching vehicles or operate correctly on tight curves of radius.*



*The rear driving assistance system will not operate correctly whilst towing a trailer or caravan.*



*The correct operation of the radar sensors will be compromised if they are misaligned due to accident damage. This may cause the system to automatically shutdown.*



*To ensure that the radar sensors work correctly, the rear bumper should be kept free of snow and ice and must not be covered.*



*Use of non recommended materials or paint on rear bumper repairs may have a detrimental effect on the operation of the rear sensors. Please only use recommended materials.*

#### Switching the System Functions On/Off

The rear driver assist system function and sub system switches can be accessed via the infotainment screen. Select ON/OFF to activate/deactivate the system.

## STARTING AND DRIVING

---

**Note:** *The vehicle speed provided in the system function description is just for your reference.*


**Note:** *Some models are equipped with towing mode. When towing mode is active, the parking aid system and rear driving assistance system will be disabled, subject to the actual vehicle.*

### **Blind Zone Safety Assist**


#### **Blind Spot Detection**

Blind Zone Safety Assist consists of two active safety assist functions: Blind Spot Detection ( BSD ) and Lane Change Assist ( LCA ), which are designed to alert the driver to vehicles that may be hidden or obscured from their sight when carrying out an maneuver.

Blind Spot Detection ( BSD ) alerts the vehicles in the vehicle's blind spot ( 1 as shown), Lane Change Assist ( LCA ) alerts the rapidly approaching vehicles on the adjacent left or right lane ( 2 as shown).



### Alarm Mode



When the system detects that there is a vehicle in the blind zone of the exterior rearview mirror or a vehicle approaching behind in the adjacent lane while the vehicle speed exceeds 10 mph / 15 km/h, the warning lamp on the corresponding side will illuminate. If the indicator lamp on the same side is turned on at this time, the warning

## STARTING AND DRIVING

---

lamp will flash to remind the driver that it is dangerous to continue changing lanes.


**Note:** *The warning lamps will not be illuminated when the vehicle speed is significantly faster than the overtaking of the motor vehicle in the blind zone.*

### Rear Cross Traffic Assist


#### Rear Cross Traffic Functions

Rear Traffic Assist includes the Rear Cross Traffic Alert ( RCTA ) and Rear Cross Traffic Braking ( RCTB ).

When reversing, the Rear Cross Traffic Alert ( RCTA ) monitors the approaching vehicles at the left/right rear by using sensors and issues an alarm when the vehicle is at risk. The Rear Cross Traffic Braking ( RCTB ) is an extension of the Rear Cross Traffic Alert ( RCTA ), which will perform emergency braking to avoid collision if the driver does not take safety measures based on the alarm.



### Alarm Mode



If there is a risk while reversing, the warning lamp on the corresponding side will illuminate, and a warning triangle is displayed on the infotainment display. If the driver does not take safety measures, the system will perform emergency braking.


# STARTING AND DRIVING

---

## Rear Collision Warning

### Rear Collision Warning Functions

When there is another vehicle or object in the same lane, which may result in a Rear Collision Warning (RCW) will activate. The RCW system will sound an alarm and activate the brake lights to warn vehicles behind.




## Alarm Mode

When there is a risk of collision, the instrument pack interface will give a prompt warning message along with an alarm sound. The rear direction indicator lamps of the vehicle flash to warn the vehicles behind.

### Door Opening Warning

#### Door Opening Warning Functions

Whilst the vehicle is stationary, the door opening warning system monitors the surrounding area for approaching vehicles, motorcycles and bicycles. If the approaching object meets the conditions programmed into the system the corresponding warning lamps will illuminate, subsequently, if the door is opened, the corresponding warning lamps will flash accompanied with an alarm sound to warn the occupant of the approaching object and assist in avoiding any collisions .



# STARTING AND DRIVING

---

## Alarm Mode



When there is a risk of collision, the warning lamp on the corresponding side will illuminate. If the door continues to be opened at this time, the warning lamp will flash with an alarm sound.

## Tyre Pressure Monitoring System (TPMS)



*TPMS can not replace routine maintenance and checks of the tyre condition and pressure.*



*Using equipment that transmits on frequencies similar to that of the TPMS may interfere with the operation of the Tyre Pressure Monitoring System, this may illuminate a warning or register a temporary fault.*

TPMS uses pressure sensors built into tyre valves to continuously monitor pressure and transmit data to the ECU inside the vehicle using RF signals. If it deduces that the pressure of that tyre has fallen below the predefined limit of the system, the warning light in the instrument pack will illuminate (always yellow). For more information, please refer to 'Instrument Pack' in 'Instruments and Controls' section. TPMS can remind you of low tyre pressure, but it can not replace normal tyre maintenance. For tyre maintenance, please refer to 'Tyres' in 'Maintenance' chapter.

*Note: TPMS only warns of low tyre pressures, it does not re-inflate the tyre.*



If the TPMS malfunction indicator lamp illuminates, and the warning message "XX Tyre Pressure Low" is displayed, it is advised that you please stop the car as soon as possible, check the tyre pressure when they are cold and inflate the tyre to the standard pressure value. The tyre pressure label attached to the B pillar indicates the standard pressure value required by your vehicle tyres when they are cold.

Driving with under-inflated tyres may overheat and cause tyre fault. Over or under-inflated tyres wear out more rapidly and also have a detrimental effect on the car's handling characteristics. Under-inflated tyres increase the rolling resistance of the car which, in turn, increases power consumption.

### TPMS Self-learning

When replacing a TPMS sensor and receiver, or performing tyre rotation, the TPMS self-learning is required, please consult a local MG Authorised Repairer for details.

# STARTING AND DRIVING

---

## Load Carrying



***DO NOT exceed the gross vehicle weight or the permitted front and rear axle loads. Failure may result in vehicle damage or serious injury.***

## Loadspace Loading



***Ensure that the rear seat backrests are securely latched in the upright position when loads are carried in the load space behind the seats.***

When luggage is carried in the load space, always ensure heavy items are placed as low and as far forward as possible, so as to avoid cargo shift in the event of an accident or sudden stop.

Drive carefully and avoid emergency braking or hard acceleration when loaded with large or heavy articles.

### IMPORTANT

Traffic regulations must be observed when loading cargo, if the cargo extrudes the loadspace appropriate warning measures must be taken to warn other road users.

## Internal Loading



**DO NOT carry unsecured equipment, tools or luggage that could move, causing personal injury in the event of an accident, or emergency braking or hard acceleration.**



**DO NOT obstruct the driver's or passenger's vision with loads.**

Folding the rear seats can increase luggage space, refer to “Rear Seats” described in the “Seats and Restraints” section.

When cargo is loaded in the vehicle, place it at a position as low as possible and ensure that it is tightly secured, so as to avoid personal injury caused by cargo movement when traffic accidents or emergency braking occurs. If the cargo has to be placed on a seat, then the seat must not be used by an occupant during that time.

## General Towing Safety

Your vehicle can tow a trailer if you carefully observe load limits, use approved equipment, and follow the towing guidelines. Always check load limits before towing.

Towing loads in excess of the maximum towing weight can seriously affect vehicle handling and performance, this could damage your vehicle and drive-train.

**Note: Exceeding any load limits advised by MG Motor is dangerous. Consult the recommended load limits and loading prior to any journey.**

Check the loading of your vehicle and trailer carefully before starting to drive.

Trailer hitch load should never exceed the limit advised by MG Motor.

**Note: Excessive towing loads reduce front tyre traction and steering control, too little trailer nose load can make the trailer unstable and cause it to sway.**

**When adding a coupling / towing device to the vehicle:**

**When towing:** All rear vehicle lights shall remain visible to road users behind the vehicle and shall not be

## STARTING AND DRIVING

---

obscured/partially obscured.If when towing light sources are obscured a secondary lighting source shall be used such as a lighting board.

**When not towing:** The fitted towing device shall not obscure any lighting source.If the towing device obscures or partially obscures a lighting source such as the fog lamp it must be removed or retracted when not towing.

**Tow bars:** Only genuine MG approved tow bars should be fitted to your vehicle. Only use the attachment method specified by the vehicle manufacturer for securing the towing hitch. Contact your authorised MG dealer for more information.

**Safety chains:** Safety chains must be used as a precautionary measure should the trailer become unintentionally unhitched. Make sure the safety chain is securely attached to both the trailer and the vehicle prior to departure.

**Altitude:** If you tow a trailer in a mountainous area you should reduce the combined vehicle and trailer weight by 10 % for every 1000 m of elevation.

**Gradients:** Where possible, when towing, you should plan your journey to avoid steep gradients. The advised brake towing mass stated assumes a maximum gradient capability of 12 %. Where possible it is recommended you drive on gradients less than 12 %. Follow the trailer associations recommendations for suitable roads.

**Running in period:** Avoid towing a trailer during your vehicles first 1000 km.

### Towing Mode

Your vehicle provides towing mode, the function will be engaged or disengaged via:

- 1 Automatically: Connect or disconnect the electrical connection with the trailer and the vehicle.
- 2 Manually: Enter the entertainment display to turn on or turn off the function.

**Note:** *When towing mode is engaged automatically, manual adjustment via the entertainment display is not possible.*

**Note:** When towing mode is activated, some functions of the vehicle will be limited or turned off, such as:

- Auto emergency brake;
- Adaptive cruise control system;
- Traffic jam assist system;
- Lane departure assist system;
- Rear driving assistance system;
- Rear parking aid system;
- ...

**Note:** If the trailer is equipped with tail light clusters, the vehicle also controls the trailer's lights after connect the electrical connection.

**Note:** When switch on the rear fog lamps, the trailer's rear fog lamps turn on while the vehicle's rear fog lamps turn off.



## **Emergency Information**

---

*250 Hazard Warning Devices*

*251 Vehicle Recovery*

*255 Emergency Starting*

*257 Tyre Repair*

*261 Fuse Replacement*

*268 Bulb Replacement*

# EMERGENCY INFORMATION

---

## Hazard Warning Devices

### Warning Triangle



The warning triangle supplied with your vehicle is stowed in the loadspace.

If you have to stop your vehicle on the road in an emergency, you must place a warning triangle approximately 50 ~ 150 metres directly behind the vehicle

if possible, and press the hazard warning switch to warn other road users of your position.

## Vehicle Recovery

### Towing for Recovery



***DO NOT tow the vehicle with any of the driving wheels in contact with the road surface, this will avoid electric drive transmission damage. When it is necessary to temporarily push or tow the vehicle from a dangerous situation or onto the transporter, the speed must remain below 3 mph and be completed within 3 minutes.***



***When pushing or towing the vehicle for temporary situation, the driver's side seat belt should be inserted into the lock and maintained in the inserted state, and then place the electric drive transmission in Neutral in order to release the EPB, otherwise the vehicle may be damaged.***

### Towing Hook



***DO NOT use a tow rope that is twisted - or the towing hook may be unscrewed.***

## EMERGENCY INFORMATION

---



Your vehicle is equipped with 2 towing eyes (located at the front and the rear of the vehicle), which are used for fitting the towing hook in the tool kit. The tool kit is placed beneath the loadspace floor. To fit the towing hook, remove the small cover set into the bumper, first press one end of the small cover plate, then open the small cover plate after the other end is lifted, then screw in the towing hook via the small hole into the threaded hole in the bumper beam (see illustration). Ensure the towing hook is fully tightened!

**Note: The towing eye cover may be secured to the bumper by a plastic cord.**

Both towing points are intended for use by qualified recovery specialists to assist in the recovery of your vehicle when a breakdown or accident occurs. They are not designed for towing other vehicles, and must NEVER be used to tow a trailer or caravan. The vehicle can be towed using a tow rope but a towing bar is recommended.

# EMERGENCY INFORMATION

## Towing for Recovery



*When towing, DO NOT accelerate or brake suddenly, this can cause accidents.*




*DO NOT tow the vehicle with all 4 wheels in contact with the road, this will cause damage to the drive motor.*

## Suspended Towing



*When using suspended towing, be careful not to let the high voltage battery pack touch the ground.*



Suspended towing is the best method for recovering a vehicle that needs to be towed. The drive wheels **MUST** be suspended above the ground (some vehicles are driven with rear wheels, some vehicles are driven with four wheels ). Switch the hazard warning lamps **ON**, and ensure no


## EMERGENCY INFORMATION

---

passengers are in the vehicle, otherwise vehicle damage or personal injury may be caused.

### Transporter or Trailer

If your vehicle needs to be transported on the back of a trailer or a transporter, it must be secured as illustrated:



1 Apply the parking brake and place the electric drive transmission in park.

- 2 Fit wheel chocks ( 1 ) as shown, then position the anti slip rubber blocks ( 2 ) around the circumference of the tyre.
- 3 Fit the lashing straps ( 3 ) around the wheels and secure them to the transporter or trailer. Tighten the straps until the vehicle is securely held.

### Emergency Starting



**NEVER attempt to power the vehicle by pushing or towing.**



**Make sure that both batteries are of the same rated voltage (12 volts), and that the booster cables are approved for use with 12 volt car batteries.**



**Ensure sparks and open flames are kept well away from the front compartment.**




**Ensure that booster cables are firmly connected and do not touch each other or other moving parts, otherwise, sparks may be caused, resulting in fire or explosion.**


In case of low battery, the vehicle can be started by using a booster cable to connect the battery of another vehicle or connecting the battery externally.

Ensure that the vehicle is powered off, and all electrical appliances of the vehicle has been turned off, then follow the instructions below:

- 1 Connect a RED booster cable between the positive ( + ) terminals of both batteries. Connect the BLACK booster cable from the negative ( - ) terminal of the donor battery ( A ) to a good earth point (an steering gear assembly housing or other unpainted surface, for example) of the disabled vehicle ( B ), as far away from the battery as possible and bypassing the brake line.



## EMERGENCY INFORMATION



- 2 Start the donor vehicle and allow it to idle for a few minutes.
- 3 Start the disabled vehicle. If the disabled vehicle will not start after several attempts, it may need to be repaired. Please contact the SAIC New Energy Vehicles Authorised Repairer for an overhaul.
- 4 After both vehicles are started normally, turn off the Start switch of the donor vehicle.

- 5 Disconnecting the booster cables. Disconnecting the booster cables must be an exact reversal of the procedure used to connect them, i.e. disconnect the BLACK negative cable from the earth point on the disabled vehicle FIRST.

### IMPORTANT

DO NOT switch on any electrical appliance in the disabled vehicle until the booster cables have been disconnected.

**Note:** *It is recommended to turn off lighting, air conditioning and other comfort appliances, and ensure that the disabled vehicle remains powered or runs for more than 1~2 hours after it is started, in order to recover the battery power. If the vehicle still fails to start/power normally after full charging, please contact an MG Authorised Repairer.*

### Tyre Repair


Some vehicles are equipped with low wind resistance wheel trim covers, which are fixed by snaps. If you need to remove or install the wheel trim cover, please pay attention to the following precautions:

- 1 When removing the trim cover, it's better to pull the trim cover apart at several positions near the hollow. Please **DO NOT** pull the trim cover at other positions to avoid damaging it;
- 2 When removing the trim cover, pull the five best pulling points one by one, and remove the wheel trim cover as a whole after all of them are pulled apart;
- 3 When installing the trim cover, make sure the valve can be exposed from the hollow. And then clamp the trim cover inplace.

**Note:** *When the new vehicle leaves the factory, the dust cap of the valve may be a little tight. It is recommended that you remove the wheel trim cover first during the first inflation operation, and then screw off the dust cap when there is enough space.*

**Note:** *If the pulling force required to remove the wheel trim cover is large, use a suitable tool to pull it out, avoiding scratching the trim cover.*

**Tool Identification (including tyre repair tool)**




- 1 Electric Air Pump
- 2 Wheel Bolt Cap Removal Tool
- 3 Repair Fluid
- 4 Towing Hook
- 5 Warning Triangle

# EMERGENCY INFORMATION

## Tyre Repair

- 1 Remove the label at the bottom of the repair fluid reservoir and attach it to the steering wheel to remind the driver not to exceed 80 km/h.



- 2 Connect the air hose of the electric air pump to the repair fluid reservoir, fit the repair fluid reservoir bottle (upright) into the slot on the compressor. Remove the valve dust cap of the flat tyre, and connect the filler hose from the repair fluid reservoir bottle to the tyre valve. Ensure that the power switch of the

electric air pump is in switched off (i.e., press "O"), then insert the plug from the electric air pump into the centre console power socket, and turn the vehicle power system on.



**Note:** To avoid battery discharge, it is recommended to keep the vehicle in P and READY mode.

- 3 Switch on the power switch of the electric air pump (i.e., press "-"), to start pumping sealant into the tyre. The repair fluid reservoir bottle will become empty

after approximately 30 seconds. The tyre should reach the specified pressure within 5 or 10 minutes.

**Note:** *The pressure gauge may briefly reach 600 kPa (i.e. 6 bar), then the pressure begins to drop to normal.*

- 4 When the required pressure is reached, switch off the electric air pump (i.e., press "o").

**Note:** *If the required pressure cannot be reached within 10 minutes, please disconnect the compressor, drive the vehicle 10 metres approx forward or backward to allow the sealant to spread within the tyre. If the required pressure can still not be reached, the tyre is severely damaged and you should seek assistance from the Roadside Assistance company or an MG Authorised Repairer.*

**Note:** *Continual operation of electric air pump for more than 10 minutes may result in damage to the compressor.*

- 5 Remove the tyre sealant bottle from the slot, and disconnect the hose of the tyre sealant bottle from the tyre valve. Then remove the plug of the electric air

pump from the centre console power socket, return the tyre repair kit to its stowage tray.

- 6 After successfully adding sealant to the tyre, drive immediately for a short time (around one minute). This will allow the sealant to distribute evenly inside the tyre. Continue driving and do not exceed 80 km/h. After a further 5 km, find a safe place to stop and recheck the tyre pressure.

Please follow different guidelines based on the tyre pressure measured:

If the tyre pressure has dropped to less than 80 kPa ( 0.8 bar), do not continue driving, seek assistance instead.


If the tyre pressure is between 80 kPa ( 0.8 bar) and the specified pressure, connect the hose of the electric air pump to the tyre valve, and inflate the tyre until it reaches the specified pressure. Repeat Step 6 .

If the tyre pressure has not dropped, you may continue driving, but the vehicle speed must not exceed 80 km/h, and the driving mileage must not exceed 200 km.

## EMERGENCY INFORMATION

---

**Note:** *DO NOT* remove foreign objects (eg. screws, nails) from the tyre. The tyre repair system must only be used when the foreign object is in the tread pattern ( A ), *DO NOT* attempt a repair when the damage is in the sidewall of the tyre ( B ).



## Fuse Replacement

### Fuse

Fuses are simple circuit breakers that protect the car's electrical equipment by preventing the electrical circuits from being overloaded. A blown fuse indicates that the circuit under its protection fails and stops working.

If you suspect a fuse is faulty, you can take it out of the fuse box and inspect it to see if the wire in the fuse is blown.


#### IMPORTANT

- NEVER attempt to repair a blown fuse. ALWAYS replace a fuse with one of the same rating, otherwise the fire may be caused due to electrical system damage or circuit overload.
- If a replaced fuse fails immediately, please contact a local MG Authorised Repairer for service as soon as possible.

It is recommended to have spare fuses in the vehicle, which can be obtained from a local MG Authorised Repairer.

### Fuse Box


The vehicle is equipped with 2 fuse boxes:



- 1 Passenger compartment fuse box (behind the driver side knee trim panel)
- 2 Front compartment fuse box (left of the engine compartment)

# EMERGENCY INFORMATION

## Passenger Compartment Fuse Box



### Check or Replace a Fuse

- 1 Power off the vehicle and turn off all electrical appliances, and disconnect the negative battery cable.
- 2 Remove the driver side knee trim panel to access the fuse box.

- 3 Clamp the fuse head with a fuse extraction tool in the fuse box cover of the front compartment, pull and remove the fuse, and check whether the fuse is blown.
- 4 If a fuse is blown, replace it with another fuse of the same type and same ampere value.

### Fuse Specification

Code	Specs	Function
F1	-	-
F2	5A	High Voltage Electric Heater
F3	7.5A	Gateway
F4	15A	Heated Steering Wheel
F5	5A	Driver door combination switch, exterior rearview mirrors and headlamp leveling switch, EPB switch, infotainment control panel, clock spring

## EMERGENCY INFORMATION

Code	Specs	Function
F6	5A	Pedestrian alert module, communication module
F7	5A	Gear shift control unit, instrument pack
F8	7.5A	Digital radio, central display, front view camera module
F9	5A	Charging Port
F10	-	-
F11	30A	Driver seat control module, driver seat adjustment switch
F12	-	-
F13	5A	Fatigue Monitoring Module
F14	10A	Airbag Control Module
F15	15A	Super Lock
F16-F17	-	-


Code	Specs	Function
F18	10A	Electronic Steering Column Lock
F19	-	-
F20	10A	DLC
F21	-	-
F22	10A	Automatic Temperature Control
F23	-	-
F24	20A	Infortainment Mainframe
F25	5A	Rear Driving Assistance Radar
F26-F43	-	-
F44	15A	Front Console Power Socket

## EMERGENCY INFORMATION

---

Code	Specs	Function
F45	5A	Rear USB port, wireless charging module of mobile phone
F46	-	-

### Front Compartment Fuse Box



### Check or Replace a Fuse

- 1 Power off the vehicle and turn off all electrical appliances, and disconnect the negative battery cable.
- 2 Press the lock catch to open the upper cover of the front compartment fuse box.

## EMERGENCY INFORMATION

- 3 Clamp the fuse head with a fuse extraction tool in the upper cover, pull and remove the fuse, and check whether the fuse is blown.
- 4 If a fuse is blown, replace it with another fuse of the same type and same ampere value.

### Fuse Specification

Code	Specs	Function
F1	20A	Reserved Trailer Module
F2	-	-
F3	15A	Reserved Trailer Module
F4-F50	-	-
F51	15A	Horn Relay
F52	5A	Electric vehicle communication controller, active intake grille
F53	20A	Left Headlamp
F54	30A	Body Control Module

Code	Specs	Function
F55	30A	Body Control Module
F56	5A	Forward Detection Radar
F57	5A	Electric Parking Motor Control Unit
F58	30A	Body Control Module
F59	-	-
F60	30A	Heated Rear Window
F61	40A	Integrated Braking System
F62	30A	Power Window Regulator Motor
F63	5A	Airbag control module, collision power module, instrument pack, gateway, parking assist sensor, body control module
F64	30A	Collision Power Module

## EMERGENCY INFORMATION

Code	Specs	Function
F65	-	-
F66	10A	Electric Exterior Rearview Mirror
F67	-	-
F68	20A	Electric Parking Motor Control Unit
F69	30A	Collision Power Module
F70	5A	Integrated braking system, electric power steering, second axis motor controller, intelligent electronic control unit
F71	-	-
F72	20A	Right Headlamp
F73	5A	Battery sensor, brake pedal switch

Code	Specs	Function
F74-F76	-	-
F77	15A	PEB Cooling Water Pump
F78	20A	High Voltage Battery Pack System
F79	50A	Air Conditioning Inlet Box
F80	10A	Second axis motor control unit, intelligent electronic control unit
F81	15A	PEB Cooling Water Pump
F82	-	-
F83	15A	Battery Pack Coolant Pump
F84	-	-
F85	15A	Front Wiper Motor
F86	15A	Heat Pump Controller
F87	5A	Combined Charging Unit

## EMERGENCY INFORMATION

Code	Specs	Function
F88	5A	Electric air conditioning compressor, battery pack heater
F89	5A	Interior rearview mirror, exterior rearview mirrors and headlamp leveling switch, left headlamp, right headlamp
F90	-	-
F91	30A	Body Control Module
F92	25A	Wiper Relay
F93	30A	Automatic Window Regulator Motor
A	-	-
B	-	-
C	80A	Electric Power Steering
D	-	-

Code	Specs	Function
E	100A	Passenger compartment fuse box
F	-	-
G	60A	Cooling Fan Power Supply
H	60A	Integrated Braking System

## EMERGENCY INFORMATION

---

### Bulb Replacement

#### Bulb Specification

Lamp	Specification
Front Reading Lamp	W5W 5W
Rear Turn Signal Lamps	WY21W 21W
Reverse Lamps	W21W 21W
Rear Fog Lamps	W21W 21W

**Note:** Other light sources not included in the list are LED , which cannot be replaced individually.

### Bulb Replacement


Before replacing any bulb, turn off the vehicle power to avoid any possibility of a short circuit. When replacing the bulb, actions shall be gentle so as not to damage the lamp.

If the bulb glass is scratched or contaminated, it may cause the bulb in use cannot concentrate the light. To replace the bulb, wear gloves or wrap the bulb with soft cloth. Do not touch the bulb glass with hands. If necessary, wipe off the stains on the bulb with alcohol.

For other bulbs not listed and to be replaced, please contact an MG Authorised Repairer.

**Note:** When replacing the bulb, be sure to use the same type and specification of light source.

### Front Reading Lamp Bulb



- 1 Disconnect the negative battery cable.
- 2 Use a small flat-bladed screwdriver to gently prise the lens from the light unit.
- 3 Pull the bulb from its mounting to remove.
- 4 Refit a new bulb in the holder.
- 5 When fitting the lens, locate the two prongs at the front of the lens and then carefully flex the lens to locate the two prongs at the rear of the lens into the

light unit. Push the lens upwards until it 'clicks' into position.


- 6 Connect the negative battery cable.
- 7 Check if the front reading lamp operates normally.

# EMERGENCY INFORMATION


---

## Rear Turn Signal Lamp Bulb & Reverse Lamp Bulb

- 1 Open the tailgate.
- 2 Disconnect the negative battery cable.
- 3 Remove 2 plugs of bodyside side tail lamp trim panel.




- 4 Remove the bolts fixing the bodyside side tail lamp to the body.



- 5 Disconnect the harness connector and remove the bodyside side tail lamp.
- 6 Rotate the rear turn signal lamp holder counterclockwise 1 or reverse lamp holder 2 , take out the holder, and remove the rear turn signal lamp bulb or reverse lamp bulb.

## EMERGENCY INFORMATION



- 7 Refit a new rear turn signal lamp bulb or reverse lamp bulb in the holder.
- 8 Rotate the rear turn signal lamp holder or reverse lamp holder clockwise to install on the bodyside side tail lamp.
- 9 Ensure the tail lamp seal gasket is in position.

- 10 Connect the harness connector, and fix the bodyside side tail lamp to the body, install 2 bolts and tighten them to 3 - 5 Nm.
- 11 Refit 2 plugs of tail lamp trim panel.
- 12 Connect the negative battery cable.
- 13 Check if the rear turn signal lamp or reverse lamp operates normally.
- 14 Close the tailgate.

# EMERGENCY INFORMATION

---

## Rear Fog Lamp Bulb




**Do not replace rear fog lamp bulb while the vehicle is charging.**

- 1 Open the tailgate.
- 2 Disconnect the negative battery cable, and keep the vehicle stationary for at least 1 minute.

**Note: Ensure the rest time when the vehicle discharges the current from the high voltage components to avoid the risk of electric shock.**

- 3 Use a suitable support device to safely lift and support the front of the vehicle. Do not work under a vehicle supported only by shear jack or wheelbarrow horizontal jack.
- 4 Remove the rear bottom deflector using an appropriate wrench or socket wrench.




- 5 Rotate the lamp holder counterclockwise (as shown in the figure), and remove the bulb.

**Note: Do not touch the high voltage component (2) when replacing the rear fog lamp bulb.**

**Note: If the high voltage component (2) shows any signs of damage, please contact a local MG Authorised Repairer for bulb replacement. Never replace the bulb without permission.**

## EMERGENCY INFORMATION



1. High-voltage components

2. Rear fog lamp

- 6 Refit the new bulb to the holder.
- 7 Refit the lamp holder to the rear fog lamp assembly, rotate it clockwise until it is fully secured.
- 8 Refit the rear bottom deflector.

- 9 Connect the negative battery cable.
- 10 Check if the rear fog lamp operates normally.



## ***Service and Maintenance***

---

*276 Maintenance*

*279 Bonnet*

*280 Front Compartment*

*281 Battery*

*283 Cooling System*

*285 High-voltage Battery Pack*

*287 Washer*

*289 Wipers*

*292 Brake*

*294 Tyre*

*300 Cleaning and Vehicle Care*

# SERVICE AND MAINTENANCE

---

## Maintenance

### Routine Servicing

The safety, reliability and performance of your car will depend partly on how well it is maintained. You must ensure that maintenance is carried out when required and according to the information contained in the "Service Schedule" owners section.

### Servicing

After the completion of each service, the next service display will be reset by your MG Authorised Repairer.

**Note: If the maintenance is not carried out (or the display is not reset by an MG Authorised Repairer after maintenance), the maintenance display will not be able to provide correct information.**

### Service History

Ensure MG Authorised Repairer registers the Service History after each service.

### Brake Fluid Replacement

Replace the brake fluid according to the information contained in the "Service Schedule" owners section.

**Note: Brake fluid replacement will be an additional cost.**

### Coolant Replacement

The coolant (anti-freeze and water solution) needs to be replaced according to the information contained in the "Service Schedule" owners section.

**Note: Coolant replacement will be an additional cost.**

### Owner Maintenance



**Any significant or sudden drop in fluid levels, or uneven tyre wear, should be reported without delay to MG Authorised Repairer.**

In addition to the routine services referred to previously, a number of simple checks must be carried out more frequently. Advice is given on the pages that follow.◦

Daily Check

- Operation of lights, horn, wipers, washers and warning lamps.
- Operation of seat belts and brakes.
- Look for fluid deposits underneath the car that might indicate a leak.
- Check tyre appearance.

### Weekly Check

- Coolant levels.
- Brake fluid level.
- Windscreen washer fluid level.
- Operate air conditioning.

### Special Operating Conditions

If your car is frequently used in dusty conditions, or operated in extreme climates where sub-zero or very high ambient temperatures are normal, more frequent attention may need to be paid to servicing requirements. You need to carry out special maintenance operations (refer to Service Schedule) or contact an MG Authorised Repairer.

### Safety in the Garage

**Note: Cooling fans may commence operating after the vehicle is switched off, and continue operating for a number of minutes. Keep clear of all fans while working in the front motor compartment**

If you need to carry out maintenance, observe the following safety precautions at all times:

- If the car has been driven recently, DO NOT TOUCH cooling system components until the drive motor has been fully cooled down.
- DO NOT TOUCH electrical leads or components when the power is on.
- DO NOT work underneath the car with a wheel changing jack as the only means of support.

## SERVICE AND MAINTENANCE

---

- Wear protective clothing and work gloves.
- Remove watches and jewellery before working in the front compartment.
- DO NOT allow tools or metal parts of the car to make contact with the battery leads or terminals.

### **Toxic Liquid**

Fluids used in motor vehicles are poisonous and should not be consumed or brought into contact with open wounds. These include: battery acid, coolant, brake fluid and windscreen washer fluid.


For your own safety, Always read and obey all instructions printed on labels and containers.

### Bonnet

#### Opening the Bonnet



**DO NOT drive when the bonnet is not closed or retained only by the safety catch.**



- 1 From the inside of the vehicle, pull the bonnet release handle ( A ).

- 2 Move the safety catch release handle on the bonnet lock assembly in the direction of the arrow ( B ) to release the bonnet safety catch.

- 3 Raise the bonnet and hold it up with the support rod firmly.

#### Closing the Bonnet

Hold the bonnet using both hands and lower it, allowing it to drop for the last 20 ~ 30 cm to fully close the bonnet.

By attempting to lift the front edge of the bonnet, check if the bonnet is fully locked after closing the bonnet. If the bonnet is not fully locked, you must repeat the closing operation.

#### Bonnet Open Alarm

If the bonnet is not fully locked, the corresponding alarm icon (refer to "Message Centre" in "Instruments and Controls" chapter) will be shown on the message centre display. If it is found that the bonnet is not fully locked while driving, an audible warning will sound.


# SERVICE AND MAINTENANCE

---

## Front Compartment



*When operating the components in the front compartment, the safety precautions listed in "Safety in Garage" should be observed, and please refer to "Maintenance" in this section.*



- 1 High Voltage Battery Pack Coolant Expansion Tank (Black Cap)
- 2 Electric Drive Transmission Coolant Expansion Tank (Black Cap)
- 3 Brake Fluid Reservoir (Black Cap)
- 4 Washer Fluid Reservoir (Blue Cap)

## Battery

### Battery Maintenance



**DO NOT** use on-board electrical appliances for an extended period of time when the vehicle is not started, otherwise the battery may become flat, resulting in the failure to start the vehicle or the reduction of battery life.



Always store batteries upright, and never attempt to dismantle a battery.

The battery, located in the front compartment, is maintenance-free, therefore there is no need to refill fluid.

According to current load conditions and battery status, the system may limit the power of some electrical appliances. Please ensure the vehicle is placed in READY mode as soon as possible to charge the battery.



**Note:** It is recommended to set the power mode to **READY** for more than half an hour every week to help extend the service life of the battery. When the vehicle will not be used for an extended period (more than 1 month), it is recommended to disconnect the battery negative terminal clamping pile head. Make sure that the vehicle power system has been turned off before connecting or disconnecting the negative battery cable.

# SERVICE AND MAINTENANCE

---

## Battery Replacement



*The battery contains sulphuric acid, which is corrosive.*

Please contact an MG Authorised Repairer to remove and refit the battery. In order to maintain the correct vehicle functionality, it is recommended to fit a replacement battery of the same type and specification as the original.



The battery must be disposed of using an approved method, used batteries can be harmful to the environment. It should be recycled by a professional company. Please consult an MG Authorised Repairer for more details.

## Cooling System

### Coolant Check and Top Up



**DO NOT remove the coolant pressure cap when the cooling system is hot - escaping steam or hot coolant could cause serious injury.**



- 1 High-voltage battery pack coolant expansion tank
- 2 Electric drive transmission coolant expansion tank

The cooling system should be checked weekly when the cooling system is cold and with the car resting on level ground. If the coolant level is below the MIN " mark, open the coolant expansion tank cap and top up coolant. The coolant level should not be higher than the " MAX " mark.

**Note: Prevent coolant from coming into contact with the vehicle body when topping up. Coolant will damage the paint.**

If the coolant level falls appreciably during a short period, and you suspect that there may be a leak, please seek an Authorised Repairer for service.

### Coolant Specification



**Coolant is poisonous and can be fatal if swallowed - keep coolant containers sealed and out of the reach of children. If accidental contact of coolant by children is suspected, seek medical assistance immediately.**

## SERVICE AND MAINTENANCE

---



*Prevent the coolant from coming into contact with the skin or eyes. If this occurs, rinse immediately with plenty of water. If eyes are still red, painful or uncomfortable, seek medical attention immediately.*

Please use the coolant which is recommended and certified. Please refer to 'Recommended Fluids and Capacities' in the "Technical Data" section.

***Note: The addition of corrosion inhibitors or other additives to the cooling system of this car may severely disrupt the efficiency of the system and cause parts damage. For cooling system issues please consult an Authorised Repairer.***

### High-voltage Battery Pack

#### Precautions and restricted conditions for use of battery



*When using the vehicle on a daily basis, it is recommended to fully charge it at least once a week, which is conducive to the health maintenance of the high-voltage battery pack; every 3 months to half a year, a low-power (less than 10% or 1 grid) full charged is performed.*



*If the vehicle is not going to be used, parked, or stored for a long time it is necessary to charge the vehicle at least once every 3 months. During this time, the High Voltage battery state of charge should not be allowed to drop below 50%.*



*If the battery is in a low state of charge and the instrument pack displays no valid driving range, the vehicle **MUST NOT** be left in a stored state for more than 7 days without being charged to above 50%.*



*Failure to follow these guidelines will result in HV battery damage and invalidate the warranty.*



***DO NOT** attempt to dismantle the battery pack or any High Voltage components - **THESE ARE DANGEROUS**. Any signs of dismantling or damage caused by attempts to dismantle will invalidate the warranty.*



*When using a paint curing oven please observe the following: Before and after any paint baking process, the vehicle should be parked at room temperature ( $20 \pm 2$  °C) for 24 hours. The vehicle can be used normally after being parked for 24 hours. The baking oven temperature should not exceed 80 °C and the baking time should not be longer than 30 minutes.*

- DO NOT park the vehicle in conditions where the ambient temperature exceeds 45°C for more than 15 days. This will effect the performance and service life of the high voltage battery.*

## SERVICE AND MAINTENANCE

---

2 To maintain or improve the service life of the high voltage battery, it is recommended that you use a slow charging method wherever possible, rapid charging should only be used for long distance journeys or emergencies.

3 It is recommended using the vehicle at least once a month.

Where possible it is recommended that you carry out a slow charging (equalisation charging) every month to extend the service life of high-voltage battery pack. The battery management system will monitor the status of the high voltage battery pack. After monitoring for a period of time, if an equalisation charge has not been carried out for some time the message centre in the instrument pack will display 'Please Slow-charge the Vehicle'. At this time you must carry out an equalisation charge. For operation mode, please refer to 'Equalisation Charging' in 'Starting & Driving' section.

4 When the vehicle is used for the first time or after a long period of storage, the SOC displayed on the

instrument may have deviation. A fully charge is recommended before use. (Battery pack type 2)

5 In the event of an accident, damage to the high voltage battery or any of its related components, or any repairs made to the high voltage system the car must be inspected by qualified personel at an MG Authorised Repairer.

6 In the event of any accident or body repairs being required please consult the qualified personnel at an MG Authorised Repairer. The repair may require high voltage battery isolation or specialist HV component removal.

### IMPORTANT

Only fully trained and qualified personel are allowed to work on the high voltage systems and components of this vehicle. Any disassembly of such systems or components is strictly prohibited.

### Washer

#### Washer Fluid Check and Top Up



*Windscreen washer fluid is flammable. DO NOT allow windscreen washer fluid to come into contact with naked flames or sources of ignition.*



*When filling the washer fluid, DO NOT let the washer fluid spill on parts around the power train or on the paint surface of the vehicle body. In case the washer fluid is spilled on hands or other parts of the body, please immediately wash with clean water.*

Check the washer fluid level regularly. When the level of washer fluid is low, please top up the washer fluid as instructed. Use the washer fluid recommended and certified by the manufacturer. Refer to "Recommended Fluids and Capacities" in the "Technical Data" chapter.



**Note:** *DO NOT use an anti-freeze or vinegar/water solution in the washer reservoir-anti-freeze will damage paintwork while vinegar will damage the washer pump.*


## SERVICE AND MAINTENANCE

### IMPORTANT

- Use the washer fluid recommended and certified by the manufacturer. Misuse of washer fluid in winter may cause damage to the washer motor due to freezing.
- Turning on the washer switch when there is no washer fluid may cause damage to the washer motor.
- Operating the wipers when the windscreen is dry and there is no washer fluid may cause damage to the windscreen and wiper blades. Please spray the washer fluid and start the wipers when there is adequate washer fluid.

### Washer Nozzles

The windscreen washer nozzle is located on the A/C air intake grille panel in the front compartment, and is configured during the factory settings, so generally there is no need for adjustments. To adjust the washer nozzle, you can insert a small flat-bladed screwdriver in the gap (the black area indicated by the arrow) between the housing ( 1 ) and the nozzle ( 2 ) and turn the nozzle downward or upward slightly to obtain an appropriate injection angle.



Operate the washer to spray water periodically to check if the washer nozzles are clean and in the correct direction. If the nozzle is obstructed, insert a needle or thin metal wire into the hole to remove the obstruction.

## Wipers

### Wiper Blades

#### IMPORTANT

- Grease, silicon and petroleum products impair the blade's wiping capability. Clean the wiper blades in warm soap water, and check their status periodically.
- Clean the windscreen frequently. DO NOT use wiper blades to remove stubborn or ingrained dirt, it will reduce their effect and their life span.
- If signs of hardness or cracking in the rubber are found, or if the wipers leave streaks or unwiped areas on the windscreen, then the wiper blades should be replaced.
- Clean the windscreen regularly with an approved glass cleaner and ensure the windscreen is thoroughly cleaned before the replacement of wiper blades.
- Only fit the wiper blades that are identical to the original specification.
- Clean ice and snow from the wipers and ensure they are not frozen or otherwise, sticking to the windscreen before attempting to operate them.

## SERVICE AND MAINTENANCE

---


### Replacing Windscreen Wiper Blades



- 1 With the engine hood closed,  press down the wiper stalk switch to Single Wipe position (see 'Wipers and Washers' in 'Instruments and Controls' section) and release within 20 seconds after clicking the symbol on the screen, and select "Safe - Power OFF" in sequence, then the wiper will automatically move to service position, and stop on the windscreen.
- 2 Lift the wiper arm away from the windscreen.
- 3 Press the button on the wiper arm (as illustrated), and pull the upper end of the wiper blade outward to disengage from the wiper arm.
- 4 Unhook the blade from the wiper arm and discard.
- 5 Locate the new wiper into the slot of the wiper arm.
- 6 Push the wiper blade towards the wiper arm until the wiper blade is fully embedded.
- 7 Check whether the wiper blade is fitted correctly to the arm before positioning on the windscreen.
- 8 Press down the wiper stalk switch again to Single Wipe position and release, or power on the system, the wiper will exit the service mode and automatically return to its original position.

### Replacing Rear windscreen Wiper Blades

4 Place the wiper assembly back on the rear window.



- 1 Lift the wiper arm away from the rear window.
- 2 Pull the wiper blade connector outward with moderate force to separate it from the wiper arm and discard the wiper blade.
- 3 Put the fitting of the new wiper blade into the slot of the wiper arm. Ensure the wiper blade is properly secured on the wiper arm.

# SERVICE AND MAINTENANCE

---

## Brake



**DO NOT rest your foot on the brake pedal while driving; this may overheat the brakes, reduce their efficiency and cause excessive wear to the brake components.**

The free travel of the brake pedal is 0~30 mm.

Reasonable usage scope of brake friction pair: not less than 2 mm for thickness of brake pads, 23~25 mm ( 2WD-51kWh&64kWh )、 28~30 mm ( 4WD-64kWh&2WD-77kWh ) for front brake disc, and 10~12 mm ( 2WD-51kWh&64kWh )、 20~22 mm ( 4WD-64kWh&2WD-77kWh ) for rear brake disc.

For the first 1500 km, you should avoid situations where heavy braking is required.

Please check all the brake system components periodically for wear at the time interval specified in the Service Portfolio, and replace them when necessary to ensure long term safety of the brake system.

The vehicle needs to run in for 800 km after brake pad or disc replacement.

### Brake Fluid Check and Top Up



**Brake fluid is highly toxic, keep the brake fluid sealed and stored out of reach of children. If accidental contact of brake fluid is suspected, seek medical attention immediately.**



**Prevent brake fluid coming into contact with the skin or eyes. If this occurs, rinse immediately with plenty of water. If eyes are still red, painful or uncomfortable, seek medical attention immediately.**

Check the brake fluid level every week. When checking, the vehicle shall be parked on level ground and the system must be in cold state.

The brake fluid level can be seen through the reservoir and should be maintained between the 'MAX' and 'MIN' mark.

**Note: DO NOT allow the brake fluid level to drop below the 'MIN' mark or rise above the 'MAX' mark.**



### IMPORTANT

Replace brake fluid regularly according to the Service Portfolio.

**Note:** Brake fluid will damage painted surfaces. If you accidentally spill the brake fluid on the painted surface, soak up any spillage with an absorbent cloth immediately and wash the area with water or car shampoo.

### Brake Fluid Specification

Use the brake fluid recommended and certified by the manufacturer. Refer to 'Recommended Fluids and Capacities' in 'Technical Data' chapter.

# SERVICE AND MAINTENANCE

---

## Tyre

### Overview

- New tyres may not have the best adhesive ability at the beginning. Therefore, driving your vehicle at moderate speed and in a prudent way at the first 500 km, which is also beneficial to the service life of the tyres.
- When passing kerbs or similar road sections, only drive at a slow speed, with the wheels and kerbs at right angle as much as possible.
- Regularly check tyres for signs of damage. **DO NOT** remove foreign objects such as screws or nails from the tyre. If a tyre shows any signs of damage, please ensure it is inspected by a reputable tyre fitter for advice.
- The valve dust cap must be fitted to prevent dust from entering the valve.
- If the tyre is to be removed, always mark the tyre/wheel orientation to ensure correct reinstallation.
- Store the removed wheel or tyre in a cool, dry and dark place.

The damage of a tyre or rim may happen unnoticeably. If abnormal vibration or deviation is experienced, that means

the tyre may have been damaged. If you suspect that a tyre is damaged, please slow down immediately, and stop your vehicle to check the tyre for damage. If you can't see the damage from the outside, continue driving the vehicle slowly to a nearest MG Authorised Repairer for inspection and service.

### Tyres with Directional Thread Patterns

Tyres with directional thread patterns have arrows on the side to mark the direction, and it is essential to use the tyres in this 'direction of rotation' (DOR). To maintain handling characteristics, tyre performance, high adhesion properties, low road noise and extend tyre life, tyres/wheels must always be fitted with indication arrow showing the correct 'DOR'.

### **Tyre Life**

Rational tyre pressure and moderate driving style can extend tyre life. Recommendations:

- Check the tyre pressures at least once a month, it should be carried out when the tyre is cold;
- Avoid cornering at excessive speeds;
- Check tyres frequently for abnormal wear;
- When the vehicle is to be parked for a long time, the vehicle should be moved at least once every two weeks to prevent permanent deformation of the tyres due to long-term stress.

The following factors affect the tyre life:

#### ***Tyre Pressures***

Incorrect pressure will cause the abnormal wear of the tyre, greatly shorten the service life, and have an adverse effect on the driving characteristics of the vehicle.

#### ***Driving Style***

Excessively harsh acceleration and braking whilst cornering will reduce tyre life.

### ***Wheel Balance***

Every new vehicle leaves the factory having had the wheels dynamically balanced. Out of balance wheels may be due to many factors.

If wheels are out of balance, shaking or vibration of the steering mechanism may occur and the tyres may start to wear excessively. It is important to restore wheel balance as quick as possible. Each wheel should be rebalanced after installing a new tyre or having a tyre repair.

### ***Wheel Alignment***

Incorrect wheel alignment can cause excessive tyre wear and affect vehicle safety. If the tyres show signs of abnormal wear, check the wheel alignment in time and seek advice from an MG Authorised repairer.

# SERVICE AND MAINTENANCE

---

## Caring for Your Tyres



**USE OF DEFECTIVE TYRES ARE DANGEROUS! DO NOT drive if any tyre is damaged, excessively worn, or inflated to an incorrect pressure.**



**It is recommended to install the tyres consistent with the original specifications. DO NOT replace the tyres with tyres of any other type. Alternative tyres, of a different specification, may adversely affect the vehicle's driving characteristics and safety. In order to retain the original safety characteristics, it is suggested that you consult an MG Authorised Repairer.**

Always drive with consideration for the condition of the tyres, and regularly inspect the tread and side walls for any sign of distortion (bulges), cuts or wear.

**Note: Prevent tyres from coming into contact with oil, grease and fuel.**

## Tyre Pressures



**Before a long distance journey, the tyre pressure must be checked.**

Check the pressures at least every month, when the tyres are cold.

If it is necessary to check the tyres when they are warm, you should expect the pressures to have increased by 30 ~ 40 kPa (i.e. 0.3 ~ 0.4 bar). In this circumstance, NEVER let air out of the tyres in order to match the recommended pressures (cold) in the technical data.

## Valves

Keep the valve caps firmly secured to prevent dirt from entering the valve. Check the valve for leaks (listen for a tell-tale hissing) when you check the tyre pressure.

## Punctured Tyres


Your vehicle is fitted with tyres which may not leak if penetrated by a sharp object, provided the object remains in the tyre. If you are aware of this occurring, reduce speed

immediately and drive with caution until the spare wheel can be fitted, or repairs undertaken.

**Note:** *If the sidewall of the tyre is damaged or distorted, replace the tyre immediately, do not attempt to repair it.*

### Tyre Wear Indicators

The tyres fitted as original equipment have 1.6 mm-high wear indicators at their tread pattern bottom, vertical with the wheel rolling direction and evenly distributed around the circumference. The mark on the tyre side such as capital letters TWI or triangular symbol shows the location of wear indicator.



When the tread has worn down to 1.6 mm or below, the indicators will come to the surface of the tread pattern, producing the effect of a continuous band of rubber across the width of the tyre.

#### IMPORTANT

A tyre **MUST** be replaced as soon as a wear mark becomes visible. Otherwise there may be a risk of accidents.

# SERVICE AND MAINTENANCE


---

## Tyre Rotation

It is recommended that you swap wheels at irregular intervals in order to equalise tyre wear.

When the tyres are worn seriously, it is recommended to swap the front and rear wheels as shown in illustration. This can prevent tyres from uneven wear, prolong the life span and balance tyre fatigue.

It is favorable to swap the driving wheels from front to rear and exchange non-driving wheels across.



**Note:** Directional tyres are marked with 'direction of rotation' (DOR). To maintain driving characteristics, tyres must always be fitted with indication arrow showing the correct 'DOR'. When the tyre tread pattern is directional, the wheels must not be exchanged diagonally or left to right but can be exchanged front to rear.

**Note:** TPMS coding is required after changing wheel positions, please consult a local MG Authorised Repairer for details.

## Tyre/Snow Chains

Unsuitable tyre/snow chains may damage the tyres, wheels, suspension, brakes or bodywork of your vehicle.

Please pay attention to the following requirements in the usage:

- The tyre/snow chains can only be fitted on the rear drive wheels;
- The thickness of tyre/snow chains shall not exceed 15 mm;
- Please always observe the installation and tension instructions for the tyre/snow chains, as well as the speed limitations of different roads;
- Do not drive faster than 50 km/h;

- To avoid the tyre damage and excessive wear of the tyre/snow chains, the tyre/snow chains must be removed while driving on the road without snow.

<b>Size and Specifications of Wheels and Tyres Supporting Tyre/Snow Chains for This Vehicle</b>		
Wheel Rim Size	8.0J×18	7.0J×17
Tyre size	235/45 R18	215/50 R17

**Note:** *If you often drive on the snowy and icy roads, it is recommended to use winter tyres. Consult an MG Authorised Repairer for details.*

# SERVICE AND MAINTENANCE

---

## Cleaning and Vehicle Care



*Observe all safety precautions on cleaning products; Do Not drink fluids and keep them away from the eyes.*

## Exterior

### Washing Your Car



*Do not clean the front compartment with high pressure water since it may damage the electrical system of the vehicle.*



*Some high pressure cleaning systems will penetrate door, window and sunroof seals, and damage lock mechanisms. DO NOT aim water jets directly at components that might be easily damaged. Ensure the vehicle power system is OFF when washing your car.*

In order to preserve the paint finish on your car, please observe the following care points:

- DO NOT use hot water to wash the car.
- DO NOT use detergents or washing up liquid.

- In hot weather, DO NOT wash the car in direct sunlight.
- When using a hose, DO NOT aim the water directly at window, door or sunroof seals, or through wheel apertures onto the brake components.

If the car is particularly dirty, use a hose to flush grime and grit from the bodywork, prior to washing. Then, wash the car using cold or lukewarm water containing a good quality wash and wax shampoo. Always use plenty of water to ensure that grit is flushed from the surface and not ground into the paintwork. After washing, rinse the bodywork with clean water and dry off with a chamois leather.

### Cleaning the underside



*Do not clean the front compartment with high pressure water since it may damage the electrical system of the vehicle.*

From time to time, but particularly during winter months when salt has been used on the roads, use a hose to wash the underside of the car. Flush away accumulations of mud and thoroughly clean those areas where debris can easily collect (wheel arches and panel seams, for example).

## SERVICE AND MAINTENANCE

### IMPORTANT

- Avoid cleaning the vehicle in direct sunlight.
- When cleaning the vehicle in winter avoid spraying water directly onto door locks and panel gaps due to risk of icing.
- Do not use rough sponges or cloth to clean the car, this will damage the paintwork finish.
- When cleaning the headlamps do not use a dry cloth or sponge, use only warm soapy water.

### **Cleaning with High Pressure Cleaner**

Always read the manufacturers operating instructions.

When using high pressure washers, always ensure there is adequate distance between the spray nozzle and any soft materials, decals or rubber seals.

**Note: DO NOT direct the pressure washer nozzle directly toward the high voltage charging points or high voltage battery connections on the underside of the vehicle.**

### IMPORTANT

- Please pay attention to the operating instructions of high pressure cleaner.
- Soft parts on the vehicle should be kept in a large enough distance from the high pressure cleaner.

### **Polishing the Paintwork**

Occasionally treat the paint surface with an approved polish containing the following properties:

- Very mild abrasives to remove surface contamination without removing or damaging the paint.
- Filling compounds that will fill scratches and reduce their visibility.
- Wax to provide a protective coating between the paint and the elements.

**Note: If possible, avoid applying polish or wax products to window glass and rubber seals.**

### **Wiper Blades**

Wash in warm soapy water. DO NOT use spirit or solvent based cleaners.

# SERVICE AND MAINTENANCE

---

## Windows and Mirrors

Regularly clean all windows, inside and out, using an approved glass cleaner.

**Windscreen:** In particular, clean the outside of the screen with glass cleaner after washing the car with wash and wax products, and before fitting new wiper blades.

**Rear screen:** Clean the inside with a soft cloth, using a side to side motion to avoid damaging the heating elements.

**Mirrors:** Wash with soapy water. Use a plastic scraper to remove ice. DO NOT use abrasive cleaning compounds or metal scraper.

## Plastic Components

Any plastic components should be cleaned using conventional cleaning methods and not be treated with abrasive materials.

## Paint Damage

Any paint damage or stonechips should be treated with suitable paint/lacquer materials immediately to avoid invalidating the Anti Corrosion Warranty.

## Weather Strips

Any weather strips or rubber aperture seals should be treated with suitable materials (silica gel) if they are cleaned using strong detergents, this should avoid any sticking and maintain the service life of the seal.

## Wheels



***When cleaning the wheels any materials or water that contact the brake.***

In order to ensure the wheels are kept in optimum condition they should be cleaned regularly.

Only use a recommended non-acidic proprietary wheel cleaner. Always read the instructions on the product.

### Cleaning the Interior

#### Plastic materials

Clean plastic-faced materials with diluted upholstery cleaner, then wipe with a damp cloth.

**Note: DO NOT polish dashboard components – these should remain non-reflective.**

#### Carpet and fabrics

Clean with diluted upholstery cleaner - test a concealed area first.

#### Leather

Clean leather trim with warm water and a non-detergent soap. Dry and polish the leather with a dry, clean, lint-free cloth.

**Note: DO NOT use petrol, detergents, furniture creams or polishes as cleaning agents.**

#### Instrument Pack, Infotainment Display

Clean with a dry cloth only. DO NOT use cleaning fluids or sprays.

### Airbag Module Covers



**DO NOT allow these areas to be flooded with liquid and DO NOT use petrol, detergent, furniture cream or polishes.**

To protect damage to the airbag SRS, the following areas should be cleaned sparingly with a damp cloth and upholstery cleaner ONLY:

- Steering wheel centre pad.
- Area of dashboard containing the passenger airbag.
- Area of roof lining and front pillar finishers which enclose the side head impact protection modules.

### Seat Belts



**DO NOT use bleaches, dyes or cleaning solvents on seat belts.**

Extend the belts, then use warm water and a non-detergent soap to clean. Allow the belts to dry naturally; DO NOT retract them or use the car until they are completely dry.



## **Technical Data**

---

*306 Technical Data Dimensions*

*308 Weights*

*310 Parameters of Traction Motor*

*311 Recommended Fluids and  
Capacities*


*312 Four-Wheel Alignment Parameter  
Table (Unladen)*

*313 Wheels and Tyres*

*314 Tyre Pressure (Cold)*

# TECHNICAL DATA

## Technical Data Dimensions



Item, Units	Parameter		
	51KWh COM\64KWh COM	64KWh 4WD	64KWh LUX\77KWh LUX
Overall length A , mm	4287		
Overall width B , mm	1836		
Overall height C ( unladen ) , mm	1504	1516	

## TECHNICAL DATA

Item, Units	Parameter		
	51KWh COM\64KWh COM	64KWh 4WD	64KWh LUX\77KWh LUX
Wheelbase D , mm	2705		
Front overhang E , mm	841		
Rear overhang F , mm	741		
Front wheel track, mm	1550		
Rear wheel track, mm	1550		
Minimum ground clearance, mm	117	132	132
Minimum Turning Diameter, m	10.6	11.7	10.6

**Note:** Vehicle length not including the license plate.

**Note:** Rearview mirrors and the deformed portion of tyre wall directly above the touchdown point are not included in the total width.

## TECHNICAL DATA

### Weights

Item, units	Parameter Values				
	51KWh COM	64KWh LUX	64KWh COM	64KWh 4WD	77KWh LUX
Person in cab, person	5				
Unladen vehicle weight (kerb), kg	1635	1672	1648	1800	1748
Gross vehicle weight, kg	2083	2123	2113	2261	2209
Unladen front axle weight, kg	798	816	804	918	853
Unladen rear axle weight, kg	837	856	844	882	895
Laden front axle weight, kg	920	940	935	1047	982
Laden rear axle weight, kg	1163	1183	1178	1214	1227

### Towing Weights

Item, Units	Parameters
Towing limit unbraked, kg	500
Towing limit braked, kg	500
Towing hitch load, kg	50

**Note:** When towing a trailer, the vehicle speed **MUST** not exceed 100 km/h.

**Note:** Prior to towing a trailer, please check the rear tyre pressures, inflate to at least 20 kPa ( 0.2 bar) above the recommended pressure - **DO NOT** allow the tyre pressure to exceed 300 kPa ( 3.0 bar), this can be dangerous.

## TECHNICAL DATA

---

### Parameters of Traction Motor

Item, Units	Rear traction motor ( 51kWh )	Rear traction motor ( 64kWh )	Rear traction motor ( 77kWh )	Front traction motor ( 64kWh )	Rear traction motor ( 64kWh )
Traction motor type	Three-phase permanent magnet synchronous motor				
Driving form	2WD	2WD	2WD	4WD	4WD
Continuous Power/Maximum NetPower, kW	54/125	68/150	90/180	68/150	84/170
Peak Torque, Nm	250	250	350	250	350
Rated Speed/Maximum Speed, rpm	8000/17000	8000/17000	9000/17000	8000/17000	8000/17000
Waterproof Grade	IP67	IP67	IP67	IP67	IP67

## Recommended Fluids and Capacities

Name	Grade	Capacity	
		2WD	4WD
High-voltage battery pack coolant, L	Glycol ( OAT )	4.0	
Electric drive transmission coolant, L		5.6	6.4
Front electric drive transmission oil, L	Shell E-Fluids E6 iX (SL2808)	—	1.1
Rear electric drive transmission oil ( 125kW&150kW ) , L		0.85	—
Rear electric drive transmission oil ( 170kW&180kW ) , L		0.9	
Brake fluid, L	DOT 4	0.8	
Washer fluid, L	ZY-VIII	2.5	
Air conditioning refrigerant, g	R-134a	580±20	

## TECHNICAL DATA

---

### Four-Wheel Alignment Parameter Table (Unladen)

Items		Parameters
Front Wheel	Camber	$-12 \pm 45 \phi$
	King Pin Caster Angle	$6^{\circ}50 \pm 45 \phi$
	Toe in (Total)	$6 \pm 12 \phi$
	King Pin Inclination	$12^{\circ}45 \pm 45 \phi$
Rear Wheel	Camber	$-1^{\circ} \pm 45 \phi$
	Toe in (Total)	$12 \pm 12 \phi$

## Wheels and Tyres

Wheel Rim Size	8.0JX18	7.0JX17
Tyre Size	235/45 R18	215/50 R17

## TECHNICAL DATA

---

### Tyre Pressure (Cold)

Wheels	Half-load	Laden
Front Wheels	250kPa/2.5bar/37psi	250kPa/2.5bar/37psi
Rear Wheels	250kPa/2.5bar/37psi	280kPa/2.8bar/41psi